

DMA-1100P

Digital Media Adapter

User's Guide

Version 1.00

11/2007

Edition 1



About This User's Guide

Intended Audience

This manual is intended for people who want to use and configure the DMA-1100P. You should have at least basic computer usage knowledge.

Related Documentation

- Quick Start Guide

The Quick Start Guide is designed to help you get up and running right away. It contains information on setting up your network and configuring for Internet access.

- Supporting Disk

Refer to the included CD for software and support documents.

- ZyXEL Web Site

Please refer to www.zyxel.com for additional support documentation and product certifications.

User Guide Feedback

Help us help you. Send all User Guide-related comments, questions or suggestions for improvement to the following address, or use e-mail instead. Thank you!

The Technical Writing Team,
ZyXEL Communications Corp.,
6 Innovation Road II,
Science-Based Industrial Park,
Hsinchu, 300, Taiwan.

E-mail: techwriters@zyxel.com.tw

Document Conventions

Warnings and Notes

These are how warnings and notes are shown in this User's Guide.



Warnings tell you about things that could harm you or your device.














Notes tell you other important information (for example, other things you may need to configure or helpful tips) or recommendations.

Syntax Conventions

- The DMA-1100P may be referred to as the “DMA”, the “device”, the “system” or the “product” in this User's Guide. Distinctions are made where needed.
- Product labels, screen names, field labels and field choices are all in **bold** font.
- A key stroke is denoted by square brackets and uppercase text, for example, [ENTER] means the “enter” or “return” key on your keyboard.
- “Enter” means for you to type one or more characters and then press the [ENTER] key. “Select” or “choose” means for you to use one of the predefined choices.
- A right angle bracket (>) within a screen name denotes a mouse click. For example, **Maintenance > Log > Log Setting** means you first click **Maintenance** in the navigation panel, then the **Log** sub menu and finally the **Log Setting** tab to get to that screen.
- Units of measurement may denote the “metric” value or the “scientific” value. For example, “k” for kilo may denote “1000” or “1024”, “M” for mega may denote “1000000” or “1048576” and so on.

Icons Used in Figures

Figures in this User's Guide may use the following generic icons. The DMA icon is not an exact representation of your device.

DMA 	DMA with Remote Control 	Notebook computer 
Computer 	Television (TV) 	USB Memory Stick 
Server 	Firewall 	Switch 
Router 	Powerline 	

Safety Warnings



For your safety, be sure to read and follow all warning notices and instructions.

- Do NOT use this product near water, for example, in a wet basement or near a swimming pool.
- Do NOT expose your device to dampness, dust or corrosive liquids.
- Do NOT store things on the device.
- Do NOT install, use, or service this device during a thunderstorm. There is a remote risk of electric shock from lightning.
- Connect ONLY suitable accessories to the device.
- Do NOT open the device or unit. Opening or removing covers can expose you to dangerous high voltage points or other risks. ONLY qualified service personnel should service or disassemble this device. Please contact your vendor for further information.
- Make sure to connect the cables to the correct ports.
- Place connecting cables carefully so that no one will step on them or stumble over them.
- Always disconnect all cables from this device before servicing or disassembling.
- Use ONLY an appropriate power adaptor or cord for your device. Connect it to the right supply voltage (for example, 110V AC in North America or 230V AC in Europe).
- Do NOT allow anything to rest on the power adaptor or cord and do NOT place the product where anyone can walk on the power adaptor or cord.
- Do NOT use the device if the power adaptor or cord is damaged as it might cause electrocution.
- If the power adaptor or cord is damaged, remove it from the device and the power source.
- Do NOT attempt to repair the power adaptor or cord. Contact your local vendor to order a new one.
- Do not use the device outside, and make sure all the connections are indoors. There is a remote risk of electric shock from lightning.
- If you wall mount your device, make sure that no electrical lines, gas or water pipes will be damaged.

This product is recyclable. Dispose of it properly.



Contents Overview

Introduction 21

 Introducing the DMA 23

 Hardware 25

Using the DMA 29

 DMA Menus 31

 VIDEO Menu 39

 MUSIC Menu 43

 PHOTO Menu 49

 Favorites (Playlists) 53

 SERVER Menu 57

 USB Menu 61

DMA Setup and Troubleshooting 63

 Configuring the DMA 65

 Media Server Software 81

 The ENCRYPT Button 83

 Troubleshooting 87

Appendices and Index 95

Table of Contents

About This User's Guide	3
Document Conventions.....	4
Safety Warnings.....	6
Contents Overview	9
Table of Contents.....	11
List of Figures	15
List of Tables.....	19
Part I: Introduction.....	21
Chapter 1	
Introducing the DMA.....	23
1.1 Overview	23
1.1.1 Play Movies, Music or Photos on Your TV	23
1.1.2 Play Files from Your Computer or on USB	23
1.1.3 Connect your DMA to Your Home (Powerline) Network	24
1.1.4 Use the Remote Control to Select From the On-Screen Menu	24
Chapter 2	
Hardware.....	25
2.1 Overview	25
2.2 Using the Remote Control	25
2.3 LEDs	27
Part II: Using the DMA	29
Chapter 3	
DMA Menus	31
3.1 Menus Overview	31
3.2 Menu Navigation	32
3.3 VIDEO, MUSIC and PHOTO Menus	33

3.4 VIDEO, MUSIC and PHOTO File Folders	34
3.5 The TOOL Button	34
3.5.1 VIDEO, MUSIC and PHOTO Menus: TOOL	35
3.5.2 Using the TOOL Menu From a File Album	35
3.5.3 Keyboard Input	36
Chapter 4	
VIDEO Menu	39
4.1 Playing a Video	39
4.1.1 A-B	41
4.1.2 Using the TOOL Menu During Video Playback	41
Chapter 5	
MUSIC Menu	43
5.1 MUSIC Menu	43
5.1.1 Using the TOOL Menu While Playing Music	44
5.2 Podcast (RSS)	45
5.3 Podcast Menu	45
5.3.1 Importing Podcasts	46
5.3.2 Adding Podcasts	46
Chapter 6	
PHOTO Menu	49
6.1 PHOTO Menu	49
6.2 Organizing Your Photos	50
6.3 Slideshow	50
6.3.1 Configuring Slideshow Settings	51
Chapter 7	
Favorites (Playlists)	53
7.1 Favorites (Playlists) Introduction	53
7.2 Adding a File to a Favorites Folder	53
7.3 Editing a Favorites Folder	54
7.3.1 Changing the Name of a Favorite Folder	54
7.3.2 Changing the Contents of a Favorites Folder	55
7.4 Favorites Playback	55
Chapter 8	
SERVER Menu	57
8.1 Accessing the SERVER Menu	57
8.2 SERVER Menu	57
Chapter 9	
USB Menu	61

9.1 USB Menu	61
Part III: DMA Setup and Troubleshooting	63
Chapter 10	
Configuring the DMA	65
10.1 Accessing the OPTION Menu	65
10.2 HomePlug Settings	66
10.2.1 Connecting to a Single Computer with HomePlug	66
10.2.2 Connecting to a Wired Home Network with Powerline	68
10.3 Network Settings	68
10.3.1 DNS Server Address	69
10.3.2 MAC Address	69
10.4 Network Settings Menu	69
10.5 Wired LAN Settings	69
10.6 Video Modes	71
10.7 TV Settings	71
10.8 Audio Settings	72
10.8.1 Audio Formats	73
10.9 Language Settings	74
10.10 Settings For Ease of Use	75
10.11 Reset Settings	75
10.12 Registration Code	76
10.13 Software Update	77
10.14 Device Information	78
10.15 Screen Saver	79
Chapter 11	
Media Server Software	81
11.1 Media Server Introduction	81
11.2 Media Server Tool	81
11.3 Configuring the Media Server Software	82
11.4 Windows Media Connect Server	82
Chapter 12	
The ENCRYPT Button	83
12.1 ENCRYPT Button Overview	83
12.2 Set Up a HomePlug AV Network with ENCRYPT	83
12.3 Setting Up Multiple Networks	85
Chapter 13	
Troubleshooting	87

13.1 Power, Hardware Connections, and LEDs	87
13.2 DMA Usage	88
13.3 Powerline Problems	91
13.4 ENCRYPT Button Problems	92
Part IV: Appendices and Index	95
Appendix A Product Specifications.....	97
Appendix B Setting up Your Computer's IP Address.....	107
Appendix C Windows Vista Media Server	129
Appendix D Open Software Announcements	137
Appendix E Legal Information	183
Appendix F Customer Support.....	187
Index.....	193

List of Figures

Figure 1 DMA with USB	23
Figure 2 Connect the DMA to Your Home Powerline Network	24
Figure 3 Remote Control	26
Figure 4 LEDs	27
Figure 5 HOME Menu	31
Figure 6 Main Menu Description	33
Figure 7 File Folder Menu Description	34
Figure 8 VIDEO: TOOL > Change View	35
Figure 9 VIDEO > File Album: TOOL	35
Figure 10 Keyboard Input	36
Figure 11 VIDEO Icon	39
Figure 12 VIDEO Menu	39
Figure 13 VIDEO > All Videos	40
Figure 14 VIDEO Playback Information Example	40
Figure 15 VIDEO > All Videos > File: TOOL	41
Figure 16 MUSIC Icon	43
Figure 17 MUSIC Menu	43
Figure 18 MUSIC > Album > File: TOOL	44
Figure 19 RSS Feed Icon	45
Figure 20 MUSIC > Podcast: TOOL	45
Figure 21 MUSIC > Podcast: TOOL: Add Podcast	47
Figure 22 MUSIC > Podcast: TOOL: Add Podcast: Keyboard Input.	47
Figure 23 PHOTO Icon	49
Figure 24 PHOTO Menu	49
Figure 25 PHOTO > Album: TOOL	50
Figure 26 PHOTO > Album > File: TOOL	51
Figure 27 Adding a Favorite Example.	53
Figure 28 Favorites: TOOL Menu	54
Figure 29 Favorites > Favorite folder: TOOL Menu	55
Figure 30 SERVER Icon	57
Figure 31 SERVER Menu > Server	58
Figure 32 SERVER Menu	58
Figure 33 SERVER > User Files	59
Figure 34 USB Icon	61
Figure 35 OPTION Icon	65
Figure 36 OPTION Menu	65
Figure 37 Connect Directly to a Computer with Powerline	66
Figure 38 Option > Homeplug Settings: NMK Setup	67

Figure 39	OPTION > Homeplug Settings: Keyboard Input	67
Figure 40	Connect to a Computer on Your Home (wired) Network	68
Figure 41	OPTION > Network Settings	69
Figure 42	OPTION > Network Settings > Wired LAN Settings	70
Figure 43	OPTION > TV Settings	71
Figure 44	OPTION > Audio Output Settings	72
Figure 45	OPTION > Language Settings	74
Figure 46	OPTION > Settings for Ease of Use	75
Figure 47	OPTION > Reset Settings	76
Figure 48	OPTION > DivX Registration Code.	77
Figure 49	OPTION > Software Update	78
Figure 50	OPTION > Device Information	79
Figure 51	Media Server Tool Icon	82
Figure 52	ENCRYPT Connection Procedure	84
Figure 53	Adding More Powerline Adapters to Your Network	84
Figure 54	One Existing Powerline Network	85
Figure 55	Two Separate Powerline Networks	85
Figure 56	Wall-mounting Example	104
Figure 57	Masonry Plug and M4 Tap Screw	104
Figure 58	WIndows 95/98/Me: Network: Configuration	108
Figure 59	Windows 95/98/Me: TCP/IP Properties: IP Address	109
Figure 60	Windows 95/98/Me: TCP/IP Properties: DNS Configuration	110
Figure 61	Windows XP: Start Menu	111
Figure 62	Windows XP: Control Panel	111
Figure 63	Windows XP: Control Panel: Network Connections: Properties	112
Figure 64	Windows XP: Local Area Connection Properties	112
Figure 65	Windows XP: Internet Protocol (TCP/IP) Properties	113
Figure 66	Windows XP: Advanced TCP/IP Properties	114
Figure 67	Windows XP: Internet Protocol (TCP/IP) Properties	115
Figure 68	Windows Vista: Start Menu	116
Figure 69	Windows Vista: Control Panel	116
Figure 70	Windows Vista: Network And Internet	116
Figure 71	Windows Vista: Network and Sharing Center	116
Figure 72	Windows Vista: Network and Sharing Center	117
Figure 73	Windows Vista: Local Area Connection Properties	117
Figure 74	Windows Vista: Internet Protocol Version 4 (TCP/IPv4) Properties	118
Figure 75	Windows Vista: Advanced TCP/IP Properties	119
Figure 76	Windows Vista: Internet Protocol Version 4 (TCP/IPv4) Properties	120
Figure 77	Macintosh OS 8/9: Apple Menu	121
Figure 78	Macintosh OS 8/9: TCP/IP	121
Figure 79	Macintosh OS X: Apple Menu	122
Figure 80	Macintosh OS X: Network	123
Figure 81	Red Hat 9.0: KDE: Network Configuration: Devices	124

Figure 82 Red Hat 9.0: KDE: Ethernet Device: General	124
Figure 83 Red Hat 9.0: KDE: Network Configuration: DNS	125
Figure 84 Red Hat 9.0: KDE: Network Configuration: Activate	125
Figure 85 Red Hat 9.0: Dynamic IP Address Setting in ifconfig-eth0	126
Figure 86 Red Hat 9.0: Static IP Address Setting in ifconfig-eth0	126
Figure 87 Red Hat 9.0: DNS Settings in resolv.conf	126
Figure 88 Red Hat 9.0: Restart Ethernet Card	126
Figure 89 Red Hat 9.0: Checking TCP/IP Properties	127
Figure 90 DMA with Windows Vista Computer	129
Figure 91 Start Windows Media Player	130
Figure 92 Start Windows Media Player	131
Figure 93 Windows Media Player Tools> Options	131
Figure 94 Library	131
Figure 95 Media Sharing	132
Figure 96 Network and Sharing Center	132
Figure 97 Set Network Location: Customize network settings	133
Figure 98 Set Network Location: Successfully set network settings	133
Figure 99 Network	134
Figure 100 Media Sharing	134
Figure 101 Media Sharing: Select DMA	135
Figure 102 Library	135
Figure 103 Add To Library	136
Figure 104 Add To Library > Advanced	136
Figure 105 Add To Library Search	136

List of Tables

Table 1 LEDs	27
Table 2 Menus Summary	31
Table 3 Main Menu Description	33
Table 4 File Folder Menu Description	34
Table 5 VIDEO > File Album: TOOL	36
Table 6 Keyboard Input	37
Table 7 VIDEO Playback Information	41
Table 8 VIDEO > All Videos > File: TOOL Menu	42
Table 9 MUSIC > Album > File: TOOL Menu	44
Table 10 MUSIC > Podcast: TOOL Menu	45
Table 11 PHOTO > Album > File: TOOL	51
Table 12 Favorite > TOOL Menu	54
Table 13 Favorites > Favorite folder: TOOL Menu	55
Table 14 OPTION > Network Settings	70
Table 15 OPTION > TV Settings	71
Table 16 OPTION > Audio Output Settings	72
Table 17 OPTION > Language Settings	74
Table 18 OPTION > Settings for Ease of Use	75
Table 19 OPTION > Reset Settings	76
Table 20 OPTION > Software Update	78
Table 21 OPTION > Device Information	79
Table 22 Hardware Specifications	97
Table 23 Software Specifications	98
Table 24 Standards Supported	98
Table 25 MPEG PS Video File Specifications	99
Table 26 MPEG-2 TS/TTS Video File Specifications	100
Table 27 WMV Video File Specifications	100
Table 28 AVI Video File Specifications	100
Table 29 MPEG4 Video File Specifications	101
Table 30 DVR-MS Video File Specifications	101
Table 31 IFO Video File Specifications	101
Table 32 Music File Specifications	102
Table 33 Photo File Specifications	103
Table 34 Ethernet Cable Pin Assignments	105

PART I

Introduction

Introducing the DMA (23)

Hardware (25)

Introducing the DMA

This chapter introduces the main applications and features of the DMA. See the Quick Start Guide for instructions on connecting the DMA.

1.1 Overview

The DMA lets you play DVD-quality movie, music and photo files on your television from your computer, USB memory stick or other file storage device. You can connect the DMA to your computer directly or to multiple computers on your home network. The DMA is HomePlug compatible, so you can also connect your DMA to other devices with a HomePlug connection using standard home electrical wiring. After you connect to your computer or other file storage device, select the files you want to play from the DMA menu that appears on your TV screen using the remote control included with the DMA.

1.1.1 Play Movies, Music or Photos on Your TV


The DMA supports a large number of file formats (see [Appendix A on page 99](#) for a list of supported file formats). It also supports HDMI (High Definition Multimedia Interface) for high quality digital video and audio output.

1.1.2 Play Files from Your Computer or on USB

Use standard LAN (Ethernet) cables to connect the DMA directly to your computer or file storage device, such as ZyXEL's NSA-220 network storage appliance. See the Quick Start Guide to install the included media server software on Windows XP computers to use them as media servers.

The DMA can also play media files stored on a USB device like a memory stick or hard drive.

Figure 1 DMA with USB




1.1.3 Connect your DMA to Your Home (Powerline) Network

You can connect the DMA to your wired home network to access multiple computers and file storage devices. See [Chapter 10 on page 68](#) for information on wired network settings.

You can use the DMA's powerline feature to connect your DMA to your home computer or file storage device on your home powerline network using the electrical wiring you have in your house. The DMA is HomePlug AV compatible, providing high speed data transfer rates over the range of an average house. See [Appendix A on page 97](#) for speeds and range currently supported.

The figure below shows the DMA connected to a home computer and file storage device on a home powerline network.

Figure 2 Connect the DMA to Your Home Powerline Network



1.1.4 Use the Remote Control to Select From the On-Screen Menu

Use the remote control that came in the package to make selections from the DMA menu that appears on your television screen. The remote control lets you easily browse and play your digital content files and configure the DMA's settings.

Hardware


2.1 Overview

This chapter describes the DMA's hardware: the remote control and the LEDs (lights).

2.2 Using the Remote Control

Use the remote control to navigate the menus, play files and configure the DMA. The following figure describes the function of each button on the remote control.

Point the remote control at the front of the DMA.


Figure 3 Remote Control

You cannot use the **SERVER**, **OPTION**, **PHOTO**, **MUSIC** or **VIDEO** buttons while a dialog box, popup screen or **TOOL** menu is displayed.

2.3 LEDs






The LEDs (lights) tell you about the current status of the DMA.

Figure 4 LEDs



The following table describes the DMA LEDs.

Table 1 LEDs

LED	COLOR	STATUS	DESCRIPTION
POWER 	Green	On	The DMA is receiving power and in operation mode (on).
	Red	On	The DMA is receiving power and in standby mode (off).
		Off	The DMA is not receiving power.
PLAY 	Blue	Blinking	The DMA is playing a file.
		Off	The DMA is not playing a file.
LAN 	Green	On	The DMA has a successful Ethernet connection.
		Blinking	The DMA is sending/receiving data on this port.
		Off	The DMA does not have a connection on this port.
USB 	Green	On	The DMA has a USB stick (or hard drive) connected.
		Off	The DMA does not have a USB stick connected.
HomePlug 	Green	On	The DMA has a powerline connection with a HomePlug AV compatible device.
		Blinking	The DMA is sending/receiving data on its powerline connection.
		Off	The DMA does not have a powerline connection with a HomePlug AV compatible device.

PART II

Using the DMA

DMA Menus (31)
VIDEO Menu (39)
MUSIC Menu (43)
PHOTO Menu (49)
Favorites (Playlists) (53)
SERVER Menu (57)
USB Menu (61)

DMA Menus

This chapter introduces the DMA's menus and how to navigate them.

3.1 Menus Overview

The DMA uses menus that display on your television screen. The **HOME** menu is the first menu you see when you turn on the DMA.

Figure 5 HOME Menu



This table describes the **HOME** menu.

Table 2 Menus Summary








MENU	DESCRIPTION
	This menu shows video files on the media server you are accessing. Video files on a USB stick that you add to a favorites folder also display here. See Chapter 4 on page 39 for details.
	This menu shows music files on the media server you are accessing. Music files on a USB stick that you add to a favorites folder also display here. See Chapter 5 on page 43 for details.

Table 2 Menu Summary

MENU	DESCRIPTION
	This menu shows photos on the media server you are accessing. Photos on a USB stick that you add to a favorites folder also display here. See Chapter 6 on page 49 for details.
	Select a media server with content files that you want to play. See Chapter 8 on page 57 for details.
	This menu displays the files on an attached USB device. See Chapter 9 on page 61 for details.
	Use this menu to change the DMA's settings. See Chapter 10 on page 65 for details.
	This is the number of media servers the DMA has detected. If it is two or more, use the SERVER menu to select the one you want to use. See Section 8.2 on page 57 for details.

3.2 Menu Navigation

Use the remote control's **OK**, **BACK** and arrow buttons to go through the menus, configure the DMA and play your files.




Use the remote control's arrow and **OK** buttons to select fields and field options.

3.3 VIDEO, MUSIC and PHOTO Menus

The **VIDEO**, **MUSIC** and **PHOTO** menu work in a similar way. (The specific features of the **VIDEO**, **MUSIC** and **PHOTO** menus are described in the VIDEO, MUSIC and PHOTO chapters in this User's Guide.) The **VIDEO** menu is shown below as an example.

Figure 6 Main Menu Description



This table describes the main **VIDEO**, **MUSIC** and **PHOTO** menus.

Table 3 Main Menu Description

AREA	DESCRIPTION
A	<p>This is a list of the file folders. The currently selected item is white. The arrows show that you can move up or down in the menu.</p> <p>The DMA categorizes files into album, artist and genre folders according to the information stored in your files. Files may not appear in the proper folders if they have missing, incorrect or incomplete information.</p> <p>Album - Search for videos, music or photos by album (VIDEO, MUSIC and PHOTO folders).</p> <p>Artist - Search for music by artist (MUSIC folder only).</p> <p>Genre - Search for videos or music by genre (VIDEO and MUSIC folders).</p> <p>All Music / All Videos / All Photos - All of the menu's files display here.</p> <p>Favorites - This section contains folders of the files you have marked as favorites. You can use a favorites folder to have the DMA play the entire list of files (this is also known as a playlist).</p>
B	<p>This shows which remote control buttons to use in the menu. For example, in this menu, use the remote control's arrow and OK buttons to select a folder to see the files sorted by that criteria. Or use the BACK button to go up in the menu structure (return to the HOME screen).</p>
C	<p>This displays the number of the selected menu item followed by the total number of items. In this example menu, the first of four items is selected.</p>


3.4 VIDEO, MUSIC and PHOTO File Folders

This section describes a file folder menu of videos, music or photos.

Select a folder (or sub-folder, if that is where your files are) in the **VIDEO**, **MUSIC** or **PHOTO** menus and click **OK** to reach a list of files. The file folder menu displays.

The **VIDEO > All Videos** menu is shown as an example. The **MUSIC** and **PHOTO** menu file folders work the same way.

Figure 7 File Folder Menu Description



This table describes a **VIDEO** file folder menu. **MUSIC** and **PHOTO** file folders have similar features.

Table 4 File Folder Menu Description

AREA	DESCRIPTION
A	Details about the currently selected file. TITLE - The name of the file. ARTIST - The name of the artist (MUSIC folder only). ALBUM - Which album the file belongs to. DATE - The date the file was created (or last modified). DURATION - The play time of the file in hours:minutes:seconds. SERVER - The name of the media server where the file is located.
B	This is a list of files in your file folder.

3.5 The TOOL Button

Use the **TOOL** button on your remote to set how you view files in the **VIDEO**, **MUSIC** and **PHOTO** menus and file folders. See the **VIDEO**, **MUSIC** and **PHOTO** sections for information on using the **TOOL** button while playing back files.

3.5.1 VIDEO, MUSIC and PHOTO Menus: TOOL

In the **VIDEO**, **MUSIC** or **PHOTO** menus, select **TOOL** > **Change View** to view files as a list and/or as thumbnails.


Figure 8 VIDEO: TOOL > Change View



3.5.2 Using the TOOL Menu From a File Album

In a **VIDEO**, **MUSIC** or **PHOTO** album, use the remote's **TOOL** button to set up file options.

Figure 9 VIDEO > File Album: TOOL



The following table describes the options in this menu.


Table 5 VIDEO > File Album: TOOL

LABEL	DESCRIPTION
Add Favorite	Use this to add the photo to a favorite photos list. Note: After adding to or editing a favorites list, use the remote control's Power button to turn the DMA off and then back on to save your change.
Change View	Use this to select how the files display in the favorites menu. You can have them display as a List , Thumbnails , or a List with Thumbnails .
Sorting	Use sorting to set whether the files display in ascending or descending order according to TITLE , GENRE , DATE ,.
Filtering	Use the filter to search for files by title (or part of a title). After you select this option and select OK , the on-screen keyboard displays (see Figure 10 on page 36). Use the on-screen keyboard to specify up to 16 characters of text that you want to search for in the file titles.
Continuous Playback	This option is for VIDEO folders only. Select this option to replay the file without stopping.
Slideshow Settings	Use this to configure how the slideshow changes from one photo file to the next and how long it displays each photo file. You can choose slide transition effects such as Auto , Fade to White , Fade to Black and None . You can set the viewing time for each photo from three seconds to one minute.
Detailed Information	Select this option to view detailed information about the highlighted file. Not available for music files in the file folder.
View Current Slideshow Music	You can play music while you navigate the DMA's menus and play photo files or slideshows. When a music file is playing, you can use this option to go to the music file that is playing.
Back	Use this to exit the menu.

3.5.3 Keyboard Input

When you use the **Change Name** option, you use an on-screen keyboard to edit the name.

Figure 10 Keyboard Input



The following table describes the options in this menu.

Table 6 Keyboard Input

TOOL MENU	DESCRIPTION
Favorite Name	This is the playlist name that you are editing. Use the fields below to edit the name in this field.
Number	Select this to change the text input mode to numbers. A check mark displays next to the selected input mode.
Lower	Select this to change the text input mode to lower-case letters. A check mark displays next to the selected input mode.
Upper	Select this to change the text input mode to upper-case letters. A check mark displays next to the selected input mode.
Symbol	Select this to change the text input mode to symbols. A check mark displays next to the selected input mode.
Text Input Characters	Select characters from the center section of the screen to display in the name field.
Delete	Select this option and press OK to back space (delete individual characters from the name starting on the right). Press the OK button once for each character you want to delete.
Clear	Select this option to delete the whole name.
Space	Select this option and press OK to add a space in the name. Press the OK button once for each space you want to add.
OK	Select this to save your changes back to the DMA.
CANCEL	Select this to exit this screen without saving your changes.

VIDEO Menu


This chapter shows how to use the VIDEO menu.

4.1 Playing a Video

The DMA automatically arranges the video files on the media server into folders in the **VIDEO** menu. Here is an example of how to play a video file in the **All Videos** file folder.

- 1 Press the **VIDEO** button on the remote control or use the arrow and **OK** buttons to select the **VIDEO** icon in the **HOME** menu.

Figure 11 VIDEO Icon




- 2 The **Video** menu opens. You can choose a video according to the **Album** (folder) it is in, its **Genre**, **All Videos**, or you can choose from your **Favorites**.

Figure 12 VIDEO Menu




- 3 Use the remote control's arrow and **OK** buttons to select the **All Videos** folder. A list of videos appears.

Figure 13 VIDEO > All Videos



- 4 Use the remote's arrow and **OK** buttons to select and play a video file.
 - During playback, use the remote control's buttons for fast forward, reverse and pause.
 - Press the remote control's **INFO** button to display information on the screen as shown in the following figure.

Figure 14 VIDEO Playback Information Example



The following table describes the information you can display during video playback.

Table 7 VIDEO Playback Information

AREA	DESCRIPTION
A	Current function.
B	Elapsed time.
C	Audio (Left, Right or Stereo).
D	The A-B function lets you repeat a certain section of a video or music file. This can be useful for language learners wanting to repeat a particular word or phrase. See Section 4.1.1 on page 41 for an example.
E	Repeat - Keep playing (looping) the file.

4.1.1 A-B


The following example use the A-B function to set the DMA to keep repeating a section of the video starting at ten seconds into the video and ending at 30 seconds into the video.

- 1 Play a video or music file.
- 2 Press **A-B** at 0:10. The “A-” part of the **A-B** icon on the screen lights up.
- 3 Press **A-B** at 0:30. The rest of the **A-B** icon on the screen lights up.
- 4 The video or music repeats playing from A to B (0:10 to 0:30).

4.1.2 Using the TOOL Menu During Video Playback

While a video file is playing, press the remote control’s **TOOL** button to open the **TOOL** menu.

Figure 15 VIDEO > All Videos > File: TOOL



The following table describes the options in this menu.

Table 8 VIDEO > All Videos > File: TOOL Menu

LABEL	DESCRIPTION
Add Favorite	Use this to add the video to a favorite videos list (which you can use as a playlist). Note: After adding to or editing a favorites list, use the remote control's Power button to turn the DMA off and back on to save your change.
Time Search	Select this to skip to a specific time in the video. After you select this, use the arrow and OK buttons to select the HOUR and MINUTES input boxes. Then press numbers and the OK button to enter the start time. Then use the arrow and OK buttons to select OK .
Back	Use this to exit the menu.

MUSIC Menu


This chapter covers how to use the **MUSIC** menus.

5.1 MUSIC Menu

The DMA automatically arranges the music files on the media server into folders in the **MUSIC** menu. Use the **MUSIC** menu to select music files to play.


To open the **MUSIC** menu, press the **MUSIC** button on the remote control or use the arrow and **OK** buttons to select the **MUSIC** icon in the **HOME** screen.

Figure 16 MUSIC Icon



The following menu appears on your screen. You can select music according to its **Album** (folder), **Artist**, **Genre**, or from **All Music** or your list of **Favorites** (see [Chapter 7 on page 53](#)). You can also play **Podcasts** (see [Section 5.2 on page 45](#)).

Figure 17 MUSIC Menu



Playing music files is similar to playing video files (see [Section 4.1 on page 39](#) for an example of how to play a video file).

You can also play music files while you use the DMA's menus or play photo files or slideshows (use the **TOOL** menu and the **View Current Slideshow Music** option to identify a music file that is playing).

5.1.1 Using the TOOL Menu While Playing Music

You can also use the TOOL button to make adjustments while playing music.

Figure 18 MUSIC > Album > File: TOOL



The following table describes the options available.

Table 9 MUSIC > Album > File: TOOL Menu

LABEL	DESCRIPTION
Add Favorite	Use this to add the song to a favorite songs list (which you can use as a playlist). Note: After adding to or editing a favorites list, use the remote control's Power button to turn the DMA off and back on to save your change.
Time Search	Select this to skip to a specific time in the song. 1. Use the OK button to highlight the minute box and/or the seconds box. 2. Then use the remote control to enter the time in the box you have highlighted. 3. Press the OK button on your remote control to set the start time you have entered. 4. Then use the arrow and OK buttons to select OK in the screen.
Auto Volume Control Strength	Select the music playback volume. Options are None , Small , Moderate and Strong .
Back	Use this to exit the menu.

5.2 Podcast (RSS)

Podcasting is a way of publishing frequently updated audio files on the Internet. You use an aggregator (also called a reader) to subscribe to podcasts. Subscribe to a podcast and you can access new audio files as they are added. You usually play the content on your computer or a portable music player like an iPod.

At the time of writing, the DMA servers as a reader for audio podcasts that use Really Simple Syndication (RSS 2.0) and iTunes RSS feeds. Websites with an RSS feed usually display an RSS icon (shown next). Add the podcast's URL in the DMA's **Podcast** menu to be able to play the feed's audio files.

Figure 19 RSS Feed Icon



5.3 Podcast Menu

Go to the **Podcast** menu within the **MUSIC** menu and press the remote control's **TOOL** button to open the **TOOL** menu. Use this menu to configure podcast and slideshow settings.

Figure 20 MUSIC > Podcast: TOOL



The following table describes the items related to podcast settings.

Table 10 MUSIC > Podcast: TOOL Menu

TOOL MENU	DESCRIPTION
Import	You can use your computer to import a podcast URL information from your USB memory stick. See Section 5.3.1 on page 46 for details.
Add Podcast	Use this to add the URL of an RSS feed that you want to listen to. See Section 5.3.2 on page 46 for details.

Table 10 MUSIC > Podcast: TOOL Menu

TOOL MENU	DESCRIPTION
Change Podcast	Do the following to edit a podcast URL entry. 1. Select a podcast URL entry in the MUSIC menu. 2. Open the TOOL menu. 3. Select Change Podcast to edit the podcast URL entry from the DMA.
Delete Podcast	Do the following to remove a podcast URL entry. 1. Select a podcast entry in the MUSIC menu. 2. Open the TOOL menu. 3. Select Delete Podcast to remove the podcast entry from the DMA.
Slideshow Settings	Use this to configure how the slideshow changes from one photo file to the next and how long it displays each photo file. You can choose slide transition effects such as Auto , Fade to White , Fade to Black and None . You can set the viewing time for each photo from three seconds to one minute.
View Current Slideshow Music	You can play music while you navigate the DMA's menus and play photo files or slideshows. When a music file is playing, you can use this option to go to the music file that is playing.
Back	Use this to exit the menu.

5.3.1 Importing Podcasts


You can import a song list from the iTunes Podcast website. You must have the iTunes program installed on your computer to do this.

- 1 Go to the iTunes Podcast website and select a song list.
- 2 Export the song list in opml format.
- 3 Copy the exported file onto a USB stick. Use the root (top) level, in the USB stick. Do not put the file in a folder.
- 4 Insert the USB stick into the DMA.
- 5 Press the remote control's **TOOL** button to open the **TOOLS** menu.
- 6 Select **Import**.

5.3.2 Adding Podcasts

You can also add a podcast by setting the DMA to play a podcast directly from an URL.

- 1 From MUSIC > Podcast > TOOL select **Add Podcast**. The following screen appears.

Figure 21 MUSIC > Podcast: TOOL: Add Podcast

Use arrows to make sure the URL field is highlighted, then press **OK** on your remote. use the following screen to input the correct URL for your podcast.

Figure 22 MUSIC > Podcast: TOOL: Add Podcast: Keyboard Input.

See [Section 3.5.3 on page 36](#) for information on how to use the on-screen keyboard.

PHOTO Menu


This chapter explains how to use the **PHOTO** menu.

6.1 PHOTO Menu

The DMA automatically arranges the photo files on the media server into folders in the **PHOTO** menu. Use the **PHOTO** menu to select photo files to view.

To open the **PHOTO** menu, press the **PHOTO** button on the remote control or use the arrow and **OK** buttons to select the **PHOTO** icon in the **HOME** screen.

Figure 23 PHOTO Icon



The following menu appears on your screen.

Figure 24 PHOTO Menu



6.2 Organizing Your Photos

The DMA automatically organizes your files by album according to their filenames and the folders in which they are stored.

- You can use your computer to arrange your photo files in folders to make them easier to browse.
- You can also use the **TOOL** menu to add photo files to favorites folders in the DMA to make them easier to find (see [Section 7.4 on page 55](#) for details).
- You can use the **TOOL** menu from within an album to change the way you view photo files.
 - Use **Change View** to view photos as a list and/or as thumbnails.
 - Use **Sorting** to specify how files are ordered. You can order them according to title and date, in ascending or descending order.
 - Use **Filter** to search for a file name.

Figure 25 PHOTO > Album: TOOL



6.3 Slideshow

Start a slideshow from within a **PHOTO** album (you may have to click through your folders more than once to reach your photos) by using the arrow buttons to choose a photo and then pressing the **Play** button. The photos display in clockwise order starting from the selected photo.

- During a slideshow, use the **Previous**, **Play**, **Next**, **Stop**, and **Pause** buttons to control the file playback.
- Press the **ROTATE** or **Fast Forward** button to rotate a photo 90 degrees clockwise.
- Use the **Reverse** button to rotate the photo 90 degrees counter-clockwise.

6.3.1 Configuring Slideshow Settings

During a slideshow, or in a photo album, press the remote's **TOOL** button to open the **TOOL** menu to configure the slideshow's settings.

Figure 26 PHOTO > Album > File: TOOL



The following table describes the options in this menu.

Table 11 PHOTO > Album > File: TOOL

LABEL	DESCRIPTION
Add Favorite	Use this to add the photo to a favorite photos list. Note: After adding to or editing a favorites list, use the remote control's Power button to turn the DMA off and back on to save your change.
Slideshow Music Settings	Select this to choose a music playlist (favorites list) to play during the slideshow.
Slideshow Settings	Use this to set how the slideshow changes from one photo file to the next and how long it displays each photo file. You can choose slide transition effects such as Auto , Fade to White , Fade to Black and None . You can set the viewing time for each photo from three seconds to one minute.
Back	Use this to exit the menu.

Favorites (Playlists)

This chapter introduces the DMA's favorites feature.

7.1 Favorites (Playlists) Introduction

You can have the DMA play video, music and photo files in a favorites folder. This is also known as a playlist.

- See [Section 7.2 on page 53](#) for how to add files to favorites folders.
- See [Section 7.3 on page 54](#) for how to edit a favorites folder.
- See [Section 7.4 on page 55](#) for how to play a favorites folder.

7.2 Adding a File to a Favorites Folder

You can add video, music or photo files to favorites folders during playback.

- 1 While playing a file press the TOOL button.
- 2 Select **Add Favorite** and click **OK** on your remote control.
- 3 Select a **Favorite group** to add your file to and click **OK** on the on-screen menu.

Figure 27 Adding a Favorite Example.



7.3 Editing a Favorites Folder


You can edit a favorites folder from within **Favorites** or from within the favorites folder you wish to edit.

7.3.1 Changing the Name of a Favorite Folder

From **Favorites** you can use the **TOOL** button to edit a playlist name.

- 1 From within **Favorites**, press the remote's **TOOL** button to open the **TOOL** menu.
- 2 Select **Change Name**.
- 3 The **Change Name** screen appears. Select the highlighted name field and click **OK** on your remote control.
- 4 Use the **Keyboard Input** screen to input a new name for your favorites folder.

Figure 28 Favorites: TOOL Menu



The following table describes the options in this menu.

Table 12 Favorite > TOOL Menu


TOOL MENU	DESCRIPTION
Change View	Use this to select how the files display in the favorites menu. You can have them display as a list, thumbnails, or a list with thumbnails.
Change Name	Use this to change the name of the currently selected playlist. After you select Change Name , select the folder's name and press OK to use an on-screen keyboard to edit the name. See Section 3.5.3 on page 36 for how to use the software keyboard. You can enter up to 21 characters.
Slideshow Settings	Use this to configure how a slideshow changes from one photo file to the next and how long it displays each photo file.
View Current Slideshow Music	You can play music while you navigate the DMA's menus and play photo files or slideshows. When a music file is playing, you can use this option to go to the music file that is playing.
Back	Use this to exit the menu.

7.3.2 Changing the Contents of a Favorites Folder

You can also move and remove files from a favorites folder.

In **Favorites**, open a favorites folder and click the **TOOL** button to display the following screen.

Figure 29 Favorites > Favorite folder: TOOL Menu



The following table describes the options in this menu.

Table 13 Favorites > Favorite folder: TOOL Menu

TOOL MENU	DESCRIPTION
Change View	Use this to select how the files display in the favorites menu. You can have them display as a list, thumbnails, or a list with thumbnails.
Move	Use this to move a file from a source location to a destination location.
Remove from Favorites	Use this to delete the currently selected file from the playlist.
Slideshow Settings	Use this to configure how a slideshow changes from one photo file to the next and how long it displays each photo file.
Detailed Information	Use this to view details about the currently selected file.
View Current Slideshow Music	You can play music while you navigate the DMA's menus and play photo files or slideshows. When a music file is playing, you can use this option to go to the music file that is playing.
Back	Use this to exit the menu.

7.4 Favorites Playback

In the **Favorites** folder, select a favorites folder (playlist) and press **OK** to go to that list.

- Press **Play** to start playing the play list.
- Select a file and press **OK** to play the individual file.

SERVER Menu

This chapter covers how to use the **SERVER** menu.


8.1 Accessing the SERVER Menu

If you have content files stored on more than one media server, use the **SERVER** menu to select the one you want to use.

To open the **SERVER** menu:

- Press the **SERVER** button on the remote control.
- or
- From the **HOME** menu, use the remote control's arrow and **OK** buttons to select the **SERVER** icon.

Figure 30 SERVER Icon




8.2 SERVER Menu

After you are in the **SERVER** menu, use the remote control's arrow and **OK** buttons to select the media server you want to use.


Figure 31 SERVER Menu > Server

After successfully connecting to a media server, the following screen displays.

Figure 32 SERVER Menu

Use the remote control to navigate to the files you want to play (or use the main menus to do so).

You can click on **User Files** to display the shared folders on your computer.

Figure 33 SERVER > User Files

USB Menu

This chapter covers how to use the USB menu.

9.1 USB Menu

Use the **USB** menu to browse the contents stored on a USB device connected to the DMA such as a USB memory stick or USB hard drive.

To open the **USB** menu:

- Press the **USB** button on the remote control.
- or
- Use the arrow and **OK** buttons to select the **USB** icon in the **HOME** menu.

Figure 34 USB Icon



The **USB** menu displays your USB devices. Select a USB device to browse through its folders for files to play. The USB device's folders and files may just display automatically if this is the same USB device that the DMA last accessed.

PART III

DMA Setup and Troubleshooting

Configuring the DMA (65)
Media Server Software (81)
The ENCRYPT Button (83)
Troubleshooting (87)


Configuring the DMA

This chapter explains how you use the remote control to configure the DMA.

10.1 Accessing the OPTION Menu


Use the **OPTION** menu to configure the DMA.

Figure 35 OPTION Icon



- 1 To open the **OPTION** menu, press the **OPTION** button on the remote control or use the arrow and **OK** buttons to select the **OPTION** icon in the **HOME** screen.

Figure 36 OPTION Menu



- 2 Use the remote's arrow and **OK** buttons to select an option sub-menu to configure.

10.2 HomePlug Settings

You can use your existing home electrical wiring to connect the DMA to a computer (or file storage device) directly, through your wired home network, or through a powerline HomePlug AV network.




Powerline refers to the wiring you can use to connect devices such as your computer on a network. HomePlug refers to the network standards which are used for this kind of networking. The DMA uses HomePlug AV, which is one kind of HomePlug standard used for powerline networks.

10.2.1 Connecting to a Single Computer with HomePlug

Follow the instructions below to connect your DMA to a single computer (or other file storage device) with powerline.

- 1 Connect your DMA directly to a power outlet.
- 2 You will need to use a powerline adapter such as ZyXEL's PLA-400 (A) to connect your computer to a power outlet.


Figure 37 Connect Directly to a Computer with Powerline



- 3 Set a new **Network name** on your powerline adapter. This is also known as the network password, NMK or Network Membership Key. Follow the instructions that came with your ZyXEL powerline adapter on setting the **Network name**.


- 4 Then change **Network name** the Go to **OPTION > Powerline** on your DMA's onscreen menu. The screen shown below displays.
- 5 Click **OK** with your remote control when the **Network name** field is highlighted, as shown in the screen below.

Figure 38 Option > Homeplug Settings: NMK Setup



- 6 The **Keyboard Input** screen appears. See [Figure 10 on page 36](#) for instructions on how to use this screen.
- 7 Enter the same **Network name** that you set on your computer's powerline adapter.

Figure 39 OPTION > Homeplug Settings: Keyboard Input





HomePlugAV is the default **Network name**. For better security choose a secure password for your powerline connection.

10.2.2 Connecting to a Wired Home Network with Powerline


You can also connect your DMA to your home wired network.

- 1 Connect your DMA directly to a power outlet.
- 2 Connect the router on your network (**A**) to a powerline adapter such as ZyXEL's PLA-400 (**B**) using an Ethernet cable.

If your router already has a powerline feature, you can connect your router directly to a power outlet without using a powerline adapter.

- 3 Follow the instructions given above for setting the **Network name** on both your router's powerline adapter and your DMA.

Figure 40 Connect to a Computer on Your Home (wired) Network



10.3 Network Settings

The DMA needs an IP address to communicate with the media servers on your network. The DMA can get an IP address automatically if you have a device on your network that gives them out. Or you can assign the DMA a static (fixed) IP address.

10.3.1 DNS Server Address

A DNS (Domain Name System) server maps domain names (like `www.zyxel.com`) to their corresponding IP addresses (`204.217.0.2` in the case of `www.zyxel.com`). This lets you use domain names to access web sites without having to know their IP addresses. The DMA can receive the IP address of a DNS server automatically (along with the DMA's own IP address). You can also manually enter a DNS server IP address in the DMA.

10.3.2 MAC Address

Every Ethernet device has a unique MAC (Media Access Control) address. The MAC address is assigned at the factory and consists of six pairs of hexadecimal characters, for example, `00:A0:C5:00:00:02`.

10.4 Network Settings Menu

Use this menu to configure your DMA's settings for connecting to your wired Ethernet network.

Select **OPTION** > **Network Settings** to open the following menu.

Figure 41 OPTION > Network Settings

The screenshot displays the 'OPTION' menu interface for a ZyXEL device. The title 'Wired LAN Settings' is centered. Below it, several configuration options are listed:

- Get IP Address:** A dropdown menu currently showing 'NO'.
- IP Address:** A numeric keypad showing the value 192.168.1.3.
- Subnet Mask:** A numeric keypad showing the value 255.255.255.0.
- Default Gateway:** A numeric keypad with empty fields.
- DNS Server:** A numeric keypad showing the value 172.23.5.1.
- MAC Address:** A text field displaying the hexadecimal value 00:40:CA:99:A2:3F.

At the bottom of the screen, there are five navigation buttons: 'OK', 'CANCEL', 'SELECT', 'ENTER', and 'BACK'. A small status bar at the very bottom shows a battery icon and the number '0'.

10.5 Wired LAN Settings

Use this menu to configure the DMA's wired LAN settings.

Figure 42 OPTION > Network Settings > Wired LAN Settings

Wired LAN Settings

Get IP Address **NO**

IP Address 192 . 168 . 1 . 3

Subnet Mask 255 . 255 . 255 . 0

Default Gateway

DNS Server 172 . 23 . 5 . 1

MAC Address 00:40:CA:99:A2:3F

OK CANCEL

SELECT ENTER BACK

The following table describes the fields in this menu.

Table 14 OPTION > Network Settings

LABEL	DESCRIPTION
Get IP Address	Use the arrow and OK buttons to select this field. Then use the arrow and OK buttons to select an option. Select YES to have the DMA get IP address information automatically. If no IP address information is assigned, the DMA uses Auto-IP to assign itself an IP address and subnet mask. For example, you could connect the DMA directly to your media server computer. If the computer is also set to get an IP address automatically, the computer and the DMA will choose addresses for themselves and be able to communicate. Select NO if you want to assign the DMA a static (fixed) IP address.
IP Address	Enter the IP address in this field if you selected NO in the Get IP Address field.
Subnet Mask	Enter the IP subnet mask in this field if you selected NO in the Get IP Address field.
Default gateway	Enter the gateway IP address in this field if you selected NO in the Get IP Address field.
DNS server	Enter the DNS server IP address (if your ISP gave you one) in this field if you selected NO in the Get IP Address field.
MAC Address	This field displays the MAC address of the DMA. The MAC (Media Access Control) or Ethernet address on a LAN (Local Area Network) is unique to your computer (six pairs of hexadecimal notation). A network interface card such as an Ethernet adapter has a hardwired address that is assigned at the factory. This address follows an industry standard that ensures no other adapter has a similar address.
OK	Select this to save your changes back to the DMA.
CANCEL	Select this to exit this screen without saving your changes.


10.6 Video Modes

The DMA supports 480i, 480p, 720p and 1080i video modes. 720p and 1080i are high definition television modes. 480i is used with most standard definition televisions. The number (“1080” for instance) stands for the number of lines of vertical resolution. The letter “i” stands for interlaced scan. The letter “p” stands for progressive scan. Progressive scan provides higher picture quality than interlaced but requires twice the bandwidth.

10.7 TV Settings

Use this menu to configure the video output that the DMA sends to your television. Select **OPTION > TV Settings** to open the following menu.

Figure 43 OPTION > TV Settings



The following table describes the fields in this menu.

Table 15 OPTION > TV Settings

LABEL	DESCRIPTION
Output Type	Select Digital if your television accepts digital input. Select Analog if your television only accepts analog input.
Screen Size	Select 16:9 if your television supports the 16:9 format (widescreen). Select 4:3 if your television supports the 4:3 format (traditional television).
Resolution	Select a video mode. Use the highest number that your television supports. Select from 480i , 480p , 720p and 1080i . You can also select Auto when the Output Type is set to Digital .
OK	Select this to save your changes back to the DMA.
CANCEL	Select this to exit this screen without saving your changes.

10.8 Audio Settings



The DMA only provides 2 channel (stereo) output. When the DMA plays 5.1 channel files, it downmixes the analog or digital input and provides 2 channel (stereo) analog or digital output.

Use this menu to configure the DMA's audio output for music playback. You can turn the S/PDIF connector's output (the DMA's digital output) on or off for individual audio formats. The analog output is always on. You can also select how much volume smoothing you want during audio file playback.

See [Section 10.8.1 on page 73](#) for details on the individual audio formats.

Select **OPTION > Audio Output Settings** to open the following menu.

Figure 44 OPTION > Audio Output Settings



The following table describes the fields in this menu.

Table 16 OPTION > Audio Output Settings

LABEL	DESCRIPTION
Analog Output	The DMA sends two channel (also called left and right or stereo) audio output through the LEFT and RIGHT audio connectors for music files.
S/PDIF Output	Use this column to turn the S/PDIF connector's output (the DMA's digital output) on or off for individual audio formats.
AAC	Select whether or not the DMA sends digital audio output through the S/PDIF audio connector for AAC music files. Select LPCM to turn on the channel digital output (also called left and right or stereo) for AAC music files. Select OFF to turn off the digital output for AAC music files.

Table 16 OPTION > Audio Output Settings (continued)

LABEL	DESCRIPTION
Dolby Digital	Select whether or not the DMA sends digital audio output through the S/PDIF audio connector for Dolby Digital music files. Select LPCM to turn on the channel digital output (also called left and right or stereo) for Dolby Digital music files. Select OFF to turn off the digital output for Dolby Digital music files.
WMA	Select whether or not the DMA sends digital audio output through the S/PDIF audio connector for WMA music files. Select LPCM to turn on the channel digital output (also called left and right or stereo) for WMA music files. Select OFF to turn off the digital output for WMA music files.
Auto Volume Control Strength	Automatic volume control averages the volume during music playback to help smooth out the sound level. Select the amount of volume smoothing you want for music playback. None provides no volume smoothing. Small provides a low degree of volume smoothing. Moderate provides some volume smoothing. Strong provides the greatest degree of volume smoothing.
OK	Select this to save your changes back to the DMA.
CANCEL	Select this to exit this screen without saving your changes.

10.8.1 Audio Formats

This section provides background information on audio formats mentioned in the previous section.

10.8.1.1 S/PDIF

S/PDIF (Sony/Philips Digital Interface Format) is also IEC 958 type II, part of IEC-60958. S/PDIF is a collection of low-level protocol and hardware specifications for carrying digital audio signals between devices and stereo equipment.

10.8.1.2 AAC

AAC (Advanced Audio Coding) is a standardized digital audio compression method. Sony, AT&T, Dolby, Nokia, Fraunhofer (FhG) and other companies cooperated to develop AAC to provide improved performance compared to MP3 (MPEG-1 Audio Layer 3). Various products including Apple's iTunes and iPod, the Sony PlayStation 3 and many cell phones support AAC playback. AAC has been promoted as the successor to MP3 although at the time of writing, MP3 still remains popular. AAC is also known as MPEG-4 AAC because it is included in the Moving Pictures Experts Group (MPEG) MPEG-4 standard.

10.8.1.3 Dolby Digital

Dolby Digital is one of several audio compression technologies (codecs) produced by Dolby Laboratories.

Dolby Digital (also called AC-3) is the most common version. It contains up to six discrete channels of sound. Five channels for normal-range speakers (right front, center, left front, right rear and left rear) and one channel for the subwoofer. This is often abbreviated as 5.1. The Dolby Digital format also supports mono and stereo usage.

Dolby Digital is also known as DD, DD 5.1, Dolby Surround AC-3 Digital, Dolby Stereo Digital, Dolby SR-Digital, SR-D, Adaptive Transform Coder 3, AC-3, Audio Codec 3, Advanced Codec 3, Acoustic Coder 3, ATSC A/52, and ATSC A/52 Rev. B.

10.8.1.4 WMA

WMA (Windows Media Audio) is Microsoft's proprietary audio compression format. Although WMA has not been nearly as popular as MP3, WMA Pro is part of Microsoft's Windows Media framework and is positioned as a competitor to AAC. Many consumer devices and media players support the playback of WMA files.

10.8.1.5 LPCM

LPCM (Linear Pulse Code Modulation) is a method for digitally encoding audio information. In LPCM an audio waveform is represented by a sequence of amplitude values recorded at a sequence of times. LPCM most commonly supports two audio channels (stereo).

10.9 Language Settings

Use this menu to select the language that the DMA menus use.

Select **OPTION > Language Settings** to open the following menu.

Figure 45 OPTION > Language Settings



The following table describes the fields in this menu.

Table 17 OPTION > Language Settings

LABEL	DESCRIPTION
Language Settings	Select the language that you want the DMA menus to use. A check mark appears next to the current display language.
OK	Select this to save your changes back to the DMA.
CANCEL	Select this to exit this screen without saving your changes.

10.10 Settings For Ease of Use

Use this menu to configure settings that control the DMA’s operation.
 Select **OPTION > Settings for Ease of Use** to open the following menu.

Figure 46 OPTION > Settings for Ease of Use



The following table describes the fields in this menu.

Table 18 OPTION > Settings for Ease of Use

LABEL	DESCRIPTION
Connect to last accessed server automatically	When the DMA starts up, this option has it automatically connect to the media server that you last used. A check mark appears next to the option if it is selected.
Connect to single server/USB automatically	When the DMA starts up, this option has it automatically connect to the media server or USB device that you last used. A check mark appears next to the option if it is selected.
Resume last screen from standby	If you were playing a file when you turned off the DMA, this option has the DMA automatically continue playback from where you left off when you turn the DMA back on. A check mark appears next to the option if it is selected.
Sound effect	Set how loud you want the DMA to beep when you press buttons on the remote control.
OK	Select this to save your changes back to the DMA.
CANCEL	Select this to exit this screen without saving your changes.

10.11 Reset Settings

Use this menu to set the DMA back to the factory default settings.



You will lose all of your changes when you reset to the default settings.

Select **OPTION** > **Reset Settings** to open the following menu.

Figure 47 OPTION > Reset Settings



The following table describes the fields in this menu.


Table 19 OPTION > Reset Settings

LABEL	DESCRIPTION
RESET	Select this to restore all of the DMA's settings to the factory defaults.
CANCEL	Select this to exit this screen without saving your changes.

10.12 Registration Code

Use this menu to display information about the DivX VOD Registration Code

Figure 48 OPTION > DivX Registration Code.




10.13 Software Update

Use this menu to upload new software to the DMA.



Only use software for your device's specific model. Refer to the label on the bottom of your DMA.

Select **OPTION > Software Update** to open the following menu.

Figure 49 OPTION > Software Update

The following table describes the fields in this menu.

Table 20 OPTION > Software Update

LABEL	DESCRIPTION
Update over Internet	Select this option and follow the on-screen instructions to have the DMA check for and download new software from a server. The DMA must be connected to the Internet in order to do this. A check mark appears next to the option if it is selected.
Update from USB	Select this option and follow the on-screen instructions to have the DMA download new software from a USB stick. You must first download the software file, unzip it and put the folder on a USB stick. Find software at www.zyxel.com in a file that (usually) uses the system model name with a .bin extension, for example, "DMA-1100P.bin". A check mark appears next to the option if it is selected.
OK	Select this to save your changes back to the DMA.
CANCEL	Select this to exit this screen without saving your changes.



Do not turn off the DMA while software upload is in progress!

The upload process may take up to two minutes. After a successful upload, the system will reboot. See [Section 10.14 on page 78](#) for how to check the software version to know if the new software upload was successful.

10.14 Device Information

Use this menu to display information about the DMA.

Select **OPTION > Device Information** to open the following menu.

Figure 50 OPTION > Device Information



The following table describes the fields in this menu.

Table 21 OPTION > Device Information

LABEL	DESCRIPTION
Device Name	This is the name of the series to which your device belongs.
Version	This is the version of the software currently on the DMA. See Section 10.13 on page 77 for how to update software when there is a new version.
Wired LAN MAC Address	This field displays the MAC address of the DMA's wired Ethernet interface.
OK	Select this to exit this screen.

10.15 Screen Saver

The DMA automatically displays a screen saver when it is on and you are not using it. Press any button on the remote control to return to the normal screens.

Media Server Software

This chapter introduces the media server software included on the CD.

11.1 Media Server Introduction

The DMA can play files on DLNA (Digital Living Network Alliance) compliant media servers. The DLNA is a group of leading personal computer and electronics companies that works to make products compatible and able to work in a home network in order to make digital living easy and seamless. The group's members include Nokia, Intel, Microsoft, Sony, Motorola, Philips, Samsung, Matsushita, and Hewlett-Packard.

Install the included DLNA-compliant media server software on your Windows XP computers to let the DMA play files stored on the computers.

- The software requires Windows XP.
- If you do not have Windows XP or do not want to install software, you can put your files on a USB stick. The USB stick connects directly to the DMA without need of the media server software
- You must install the media server software on each computer that you will use to share files with the DMA.
- See the Quick Start Guide for how to install the media server software and the requirement details.


The NSA-220 network storage appliance is also a media server.

11.2 Media Server Tool

Use the media server tool to configure the media server settings. Do one of the following to start the media server tool.

- Click **Start > All Programs > DigiOn > DiXiM Media Server Tool**.
- Double-click the DiXiM icon in the system tray (see the following figure).

Figure 51 Media Server Tool Icon



11.3 Configuring the Media Server Software

Refer to the Quick Start Guide and the help (**Start > All Programs > DigiOn > Help**) for details on how to configure and use the media server software.

11.4 Windows Media Connect Server

Windows Media Digital Rights Management (DRM) restricts the playback of protected files to computers which have a license key. To play a media file protected by Windows Media DRM:

- 1 Play the file on the same computer you use as your media server. This unlocks the file.
- 2 Use Windows Media Connect, which is included in Windows Media Player 11 (or higher), as your media server.

The ENCRYPT Button

Use the **ENCRYPT** button to automatically set up a secure powerline connection between your powerline devices.

12.1 ENCRYPT Button Overview

The ENCRYPT button allows you to set up a secure powerline connection with other HomePlug AV compliant powerline devices which also support the ENCRYPT feature. No other powerline setting changes are required to connect.


You can use the **ENCRYPT** button to:

- set up a new powerline network
- add a powerline device to the network
- separate an existing powerline network into multiple networks

12.2 Set Up a HomePlug AV Network with ENCRYPT

You can connect a number of devices on a powerline network, but you can use the ENCRYPT button on only two devices at a time. The DMA and PLA-400 v2 are shown below as examples.

- 1 Place a powerline device close to another powerline device so you have time to set up each one. After you set up the first powerline device, you have 120 seconds to set up the second powerline device.
- 2 You can disconnect them from your computer or modem (or other networking equipment) if you need to move them close to each other, but the powerline devices need to be plugged into power outlets.
- 3 Press the **ENCRYPT** button at the rear of your powerline device for more than 10 seconds until the HomePlug (■) turns off. This resets the network name to a random value and removes your device from any network it may belong to.
- 4 Press the **ENCRYPT** button at the rear of your powerline device for 1~2 seconds.


Figure 52 ENCRYPT Connection Procedure

- 5 Repeat step 4 in this section for the other powerline device you wish to connect. This must be done within 120 seconds of pressing the **ENCRYPT** button on the DMA. Wait for about one minute while your powerline devices connect.



If the HomePlug (■) lights on both powerline devices do not light up, the powerline devices are not connected. Repeat steps 4 and 5 in this section. If that doesn't work, see Section 13.3 on page 91 for suggestions.

- 6 To add more powerline devices to your network, press the **ENCRYPT** button on device C (shown below) for more than 10 seconds until the HomePlug (■) turns off.
- 7 Then repeat steps 4 and 5 in this section using any powerline device (A or B) you have connected using **ENCRYPT** and the powerline device you want to connect (C). You must use the **ENCRYPT** button on both devices.

Figure 53 Adding More Powerline Adapters to Your Network

- 8 If you disconnected your computer or modem (or any other networking product connected to your powerline device) in step 1 of this section, you can now reconnect them.


This sets up your powerline network between your powerline devices.

12.3 Setting Up Multiple Networks

You can use the **ENCRYPT** button to set up multiple powerline networks using your existing powerline network.


For example, you have already set up a powerline network in your home (**A**) which accesses a printer (**B**). Now you want a separate powerline network connection from your laptop to your printer (**C**).

Figure 54 One Existing Powerline Network



- 1 Click the **ENCRYPT** button on (**A**) for more than 10 seconds until the HomePlug (■) turns off. This disconnects (**A**) from (**B**).
- 2 Click the **ENCRYPT** button on (**A**) and (**C**) for 1~2 seconds and within two minutes of each other.
- 3 Wait for roughly one minute while (**A**) and (**C**) connect.
- 4 Check the LEDs on both (**A**) and (**C**). When the HomePlug (■) lights shine steadily, the devices are connected.

Figure 55 Two Separate Powerline Networks



Congratulations. You now have two separate powerline networks as shown above.



If the HomePlug (■) lights on both powerline devices do not light up, the powerline devices are not connected. Repeat the connection process, making certain you press the **ENCRYPT** buttons for the correct time and within two minutes of each other. If that does not work see Section 13.3 on page 91 for suggestions.

Troubleshooting

This chapter offers some suggestions to solve problems you might encounter. The potential problems are divided into the following categories.

- [Power, Hardware Connections, and LEDs](#)
- [DMA Usage](#)
- [Powerline Problems](#)

13.1 Power, Hardware Connections, and LEDs



None of the LEDs turn on.

- 1 Make sure the DMA is turned on.
- 2 Make sure you are using the power adaptor or cord included with the DMA.
- 3 Make sure the power adaptor or cord is connected to the DMA and plugged in to an appropriate power source. Make sure the power source is turned on.
- 4 Turn the DMA off and on using the power switch on the rear panel (instead of the **Power** button on the remote control).
- 5 If the problem continues, contact the vendor.



One of the LEDs does not behave as expected.

- 1 Make sure you understand the normal behavior of the LED (see [Section 2.3 on page 27](#)).
- 2 Check the hardware connections. See the Quick Start Guide and [Section 13.1 on page 87](#).
- 3 Inspect your cables for damage. Contact the vendor to replace any damaged cables.
- 4 Turn the DMA off and on using the power switch on the rear panel (instead of the **Power** button on the remote control).
- 5 If the problem continues, contact the vendor.

13.2 DMA Usage



I cannot see the DMA menus on the television screen.

- 1 Check the hardware connections, and make sure the LEDs are behaving as expected. See the Quick Start Guide and [Section 13.1 on page 87](#).
- 2 Make sure your television is set to display the DMA's input. If you used an HDMI connection between the television and the DMA, make sure the television input is set to HDMI.
- 3 Turn the DMA off and on using the power switch on the rear panel (instead of the **Power** button on the remote control).
- 4 If the problem continues, contact the vendor.



I cannot see or access the media server folders on the television screen.

- 1 If the server icon in the bottom right of the screen has a 0, try turning the DMA off and on using the power switch on the rear panel (instead of the **Power** button on the remote control).
- 2 Check the hardware connections, and make sure the LEDs are behaving as expected. See the Quick Start Guide and [Section 13.1 on page 87](#).
- 3 Make sure the media server computer is on and has an IP address in the same subnet as the DMA. (If you know that there are routers between your computer and the DMA, skip this step.)
- 4 Check the media server program's **Published Folder** and **Security** settings. If you have to change these settings, turn the DMA off and on again afterwards.
- 5 Check the security settings of any software firewalls on the media server computer. Make sure that any software firewalls on the media server computer are configured to allow the DMA to access the media server. See the [The DMA cannot access the media server](#). If you have to change any firewall settings, turn the DMA off and on again afterwards.



The DMA cannot access the media server.

Make sure that any software firewalls on the media server computers are configured to allow the DMA to access the media server.

The media server installation wizard can automatically configure the Windows XP firewall. See the media server help (**Start > All Programs > DigiOn > Help**) for instructions on how to manually configure the Windows XP firewall.

You need to configure any other software firewalls (like ZoneAlarm for example). Your software firewall may automatically prompt you when it detects the DMA's access attempts and give you the option to allow or deny access.

Use the following information to manually configure your software firewall's settings if the firewall does not automatically prompt you to allow or deny access.

APPLICATION	PROGRAM FILE NAME	FUNCTION	PORT NO.	PROTOCOL
DiXiM Media Server	dmsf.exe ^A	DiXiM SSDP ^B Discovery	1900	UDP
		DiXiM Media Server Device	30000	TCP
		DiXiM Media Server HTTP	30001	TCP

A. This file will be installed into the C:\Program Files\DigiOn\DiXiM Media Server folder by default during the installation.

B. The DMA uses SSDP (Simple Service Discovery Protocol) to find the media server.



The number of items in a list does not match the number of files in a media server folder.

- 1 Files with unsupported formats or codecs may not display in the list. See [Appendix A on page 99](#) for details on the supported file formats and codecs.
- 2 You may have Windows Media Center (WMC) and the DiXiM media server on the same computer and be sharing out the same folder. Either uninstall one of the media servers or set them to share out different folders.



Some of the files in my media server folder do not display in the list on the DMA.

Files with unsupported formats or codecs may not display in the list. See [Appendix A on page 99](#) for details on the supported file formats and codecs.



Some of the files in my DMA's list do not play or do not play properly.

- Files with unsupported formats or codecs may not play or may not play properly. See [Appendix A on page 99](#) for details on the supported file formats and codecs.
- Files which are digitally protected may not be playable. For files that have Windows Media Digital Rights Management (DRM) protection, first play the file on the same computer you use as your media server. This unlocks the file. Then use Windows Media Connect, which is included in Windows Media Player 11 (or higher), as your media server.



Some of my photo files do not display thumbnails.

Some files do not support thumbnails and thus will not display them.



I cannot see the files on my USB device.

- 1 Make sure you have the USB device properly connected to the USB port. See the Quick Start Guide for details.
- 2 Files with unsupported formats or codecs may not play or may not play properly. See [Section on page 99](#) for details on the supported file formats and codecs.
- 3 Turn the DMA off and on using the power switch on the rear panel (instead of the **Power** button on the remote control)
- 4 Try using a different USB stick.



The A-B function does not work on some files.

Some files do not have time tags and cannot support the A-B function.



My favorites settings were not saved.

After adding to or editing a favorites list, press the remote's **Power** button to make the DMA enter standby mode to save your change. Then press the **Power** button again to return to operation mode.



I connected the DMA to two televisions but it only displays on one.

The DMA only provides output through one connection at a time (either the HDMI connection or the S-Video connection). Not both at the same time.



The DMA menu display does not fill my television screen.

Check the DMA's video output settings (see [Section 10.7 on page 71](#)).



The content playback does not fill my television screen.

- 1 Check the DMA's video output settings (see [Section 10.7 on page 71](#)).
- 2 The content may be a different format from your television. For example, a 4:3 format video file will not fill the width of a 16:9 (widescreen) format television.



The audio on my 5.1 channel speakers does not sound right or I only hear audio from my rear left and right speakers.


When the DMA plays 5.1 channel files, it downmixes the analog or digital input and provides 2-channel (stereo) analog or digital output.

- On some 5.1 channel audio systems will only play on the rear left and right speakers.
- Some 5.1 channel audio systems can simulate the 2 channels to 5.1 channels, but the sound will not be as good as with original 5.1 channel output.

13.3 Powerline Problems



The HomePlug LED does not turn on.

- 1 Use the **PLA-4xx Series Configuration Utility** to detect all other ZyXEL HomePlug AV-compliant devices on your powerline network. Make sure that the network password is the same on all of your powerline adapters. Download the Utility from the ZyXEL website.
- 2 Check the DAK and MAC address for all powerline adapters are typed correctly.
- 3 Make sure that all your powerline adapters are HomePlug AV compliant. Check the package it came in or ask your vendor. This DMA can not detect earlier versions of HomePlug powerline adapters such as HomePlug 1.0 or 1.0.1. (Although they can coexist on the same electrical wiring without interfering with each other.)
- 4 Make sure that the powerline adapters on your network are all on the same electrical wiring. Connect another powerline adapter into an outlet close to your DMA's power outlet. They are probably now on the same electrical wiring. Check the **Link**  LED. If it now lights up your powerline adapter was probably previously on separate electrical wiring. Ask an electrician for more information on the electrical wiring in your building.
- 5 If your powerline network is using coaxial cable, check all powerline adapters are on the same coaxial cable.
- 6 If your powerline network is using electrical wiring (not coaxial cable), check you do not have a power meter between powerline adapters. Powerline signals cannot pass this.



The signal on my powerline network is weak.

- 1 Your powerline adapters may be connected to electrical surge protectors. Connect them to standard power outlets.
- 2 Your powerline adapters may be located close to large appliances such as refrigerators or air-conditioners that cause interference with the powerline signal. Move the adapters further away from such appliances to reduce interference.
- 3 Your powerline adapters may be placed close to electrical devices such as electrical insect-killers which produce radio waves. These may interfere with the powerline signals. Move the adapters further away from such electrical devices.
- 4 Your wiring may be old and/or low quality or with a long wiring path.

13.4 ENCRYPT Button Problems

This section applies only to DMAs with the **ENCRYPT** button.



The HomePlug light is already on, but I haven't pressed the ENCRYPT button yet.

Your device has already connected to another powerline device. Press the **ENCRYPT** button for more than 10 seconds to release the connection.



The HomePlug light does not turn on.

- Ensure you have pressed the **ENCRYPT** button on **both** devices.
- Wait for about a minute while the devices set up a connection.
- If that does not work, try again with both devices connected to a power strip next to each other. If they now connect, then the devices were not on the same electrical circuit before.



The POWER lights on both devices finished blinking, but only one device's HomePlug light is on.

One device may have connected to a third powerline device. To check device A is connected to device B and not another device, disconnect device B from its power source. Device A's HomePlug (■) light will turn off if the connection is with Device B. Press the **ENCRYPT** button on **both** devices for more than 10 seconds, then try to reconnect, pressing the **ENCRYPT** button for less than 3 seconds on both devices.



I pressed the ENCRYPT button for more than 10 seconds, but the HomePlug light is still on.

The HomePlug light is on, indicating it is still connected to another powerline device. Try again, pressing the **ENCRYPT** button for more than 10 seconds.

PART IV

Appendices and Index

Product Specifications (97)
Setting up Your Computer's IP Address (107)
Windows Vista Media Server (129)
Open Software Announcements (137)
Legal Information (183)
Customer Support (187)
Index (193)

Product Specifications

General Specifications

The following tables summarize the DMA's hardware and software features.

Table 22 Hardware Specifications

Dimensions	244 mm (W) x 165.44 mm (D) x 38.8 mm (H)
Device Weight	0.597 kg
Power Specification	100 - 240 V AC, 50/60 Hz
Ethernet Port	Auto-negotiating: 10 Mbps or 100 Mbps in either half-duplex or full-duplex mode.
Powerline Port	1 x 200 Mbps Powerline port compliant with HomePlug AV standard
Television Connectors	HDMI Composite Video RCA connector Left/Right Video RCA connectors S/PDIF coaxial RCA connector
Remote Control	Recommended operating range up to 5 m. Point the remote control at the front of the DMA at an angle of no less than 30 degrees.
USB Port	USB version 2.0, type A
Operation Environment	Temperature: 5° C ~ 45° C Humidity: 5% ~ 85% RH (Noncondensing)
Storage Environment	Temperature: 0° C ~ 65° C Humidity: 5% ~ 95% RH (Noncondensing)
Distance between the centers of the holes (for wall mounting) on the device's back.	137 mm
Recommended type of screws for wall-mounting	M4 Tap Screw, see Figure 57 on page 104 .
Certifications	Safety: CSA C22.2 No 60950-1, UL60950-1, EN60950-1 EMC: EN55022 Class B (1988), FCC Part 15 (Class B)

Table 23 Software Specifications

FEATURE	DESCRIPTION
Default IP Address	DHCP client. If no DHCP server is found, the DMA uses Auto-IP to choose an IP address in the 169.254.X.X subnet (where X is a number from 1 to 254).
Default Subnet Mask	DHCP client by default. If no DHCP server is found, the subnet mask defaults to 255.255.255.0 (24 bits).
Device Management	Make selections and configure settings on a (television) screen using the remote control. Use the PLA-4xx Series Configuration Utility to configure the DMA powerline settings.
Software Upgrade	Upload new software (when available) from the ZyXEL website. Or download the new software from the ZyXEL website and use a USB stick to put it on the DMA. Note: Only upload software for your specific model!
Configuration Reset	The DMA provides an option for restoring the default settings.
DHCP (Dynamic Host Configuration Protocol) Client	The DMA can receive IP addresses, an IP default gateway and DNS servers via DHCP.
Universal Plug and Play (UPnP)	A UPnP-enabled device can dynamically join a network, obtain an IP address and convey its capabilities to other devices on the network.
Media Sharing	DLNA compliant client.
Favorites (Playlist)	Set up lists of files to play.
Audio Input Formats Supported	Dolby Digital, DVD-Audio, MPEG-1 and MPEG-2 Layers I, II and III(MP3), MPEG-2 BC multi-channel Layers I, II and III, MPEG-2 and MPEG-4 AAC-LC, WMA9. See page 99 for details.
Podcast RSS Feeds Supported	RSS 2.0 and iTunes RSS
Video Input Formats Supported	MPEG-1, MPEG-2 MP@ML, MPEG-4 simple and advanced simple profile, MPEG-4 AVI files and WMV version 9. See page 99 for details.
Photo Input Formats Supported	TIFF, PNG, GIF, BMP, JPEG, and JPEG2000. See page 99 for details.
Video Output Formats	Digital, analog 4:3, 16:9 480i, 480p, 720p and 1080i
Audio Output Formats	two channel (stereo)

The following list, which is not exhaustive, illustrates the standards supported in the DMA.

Table 24 Standards Supported

STANDARD	DESCRIPTION
DLNA v1 Client	The DLNA (Digital Living Network Alliance) group of personal computer and electronics companies works to make products compatible and able to work in a home network in order to make digital living easy and seamless.
HDMI	HDMI (High Definition Multimedia Interface) is an interface that allows high quality, all-digital video and audio streams.

Table 24 Standards Supported (continued)

STANDARD	DESCRIPTION
USB 2.0	USB (Universal Serial Bus) version 2.0 allows for interfacing devices with data transfers rates of up to 480 Mbps.
HomePlug AV	<p>The HomePlug AV standard specifies how network devices communicate using standard electrical wiring.</p> <p>It supports a data transfer rate of up to 200Mbps.</p> <p>Data is encrypted using 128-bit AES (Advanced Encryption Standard).</p> <p>HomePlug AV compatible devices co-exist with HomePlug 1.0 devices but do not detect each other.</p> <p>The range of a HomePlug AV network is 300 meters/984 feet in optimal conditions.</p> <p>HomePlug AV is compatible with all OSs.</p> <p>The maximum number of powerline devices on a single network is 64.</p>
Windows Media Digital Rights Management (DRM)	This Windows standard restricts the playback of protected media to computers holding a license key for the media file.

Supported Content Formats and Codecs

The following describes the details about the files that the DMA can play. Files with specifications lower or higher than the listed ranges may not play or may not play properly. For the media server software included on the CD, refer to the help (**Start > All Programs > DigiOn > Help**) for a list of file formats that the media server software can play.

Video File Formats Supported

Table 25 MPEG PS Video File Specifications

Extensions	mpg mpeg mpe m2p
Video Stream	MPEG-1, MPEG-2 Profile Level: up to MP@HL Resolution: Maximum 1920 x 1080 Bit rate: VBR/CBR, Maximum 15 Mbps
Audio Stream	MPEG-1/2 Layer-II Sample Frequency: Maximum 48 kHz Channels: Maximum 2 Channels Bit rate: VBR/CBR, Maximum 384 kbps LPCM Sample Frequency: Maximum 48 kHz Bits per sample: Maximum 16 bit Channels: Maximum 2 Channels AC3 Sample Frequency: Maximum 48 kHz Channels: Maximum 6 Channels Bit rate: Maximum 640 kbps

Table 26 MPEG-2 TS/TTS Video File Specifications

Extensions	The DMA supports the playback of mpeg, mpg, and mpe MPEG-2 TS and TTS video files. The DMA cannot play MPEG-2 TTS files from a USB device. The DMA can play MPEG-2 TTS files shared on a media server that supports them (although the included media server software does not support them).
Video Stream	MPEG-2 Profile Level: up to MP@HL Resolution: Maximum 1920 x 1080 Bit rate: VBR/CBR, Maximum 25 Mbps
Audio Stream	MPEG-1/2 Layer-II Sample Frequency: Maximum 48 kHz Channels: Maximum 2 Channels Bit rate: VBR/CBR, Maximum 448 kbps AC3 Sample Frequency: Maximum 48 kHz Channels: Maximum 6 Channels Bit rate: Maximum 448 kbps MPEG-2/4 AAC LC Sample Frequency: Maximum 48 kHz Channels: Maximum 6 Channels Bit rate: VBR/CBR, Maximum 384 kbps

Table 27 WMV Video File Specifications

Extensions	asf wmv
Video Stream	WMV9 Profile Level: up to MP@HL Resolution: Maximum 1920 x 1080 Bit rate: VBR/CBR, Maximum 10 Mbps
Audio Stream	WMA8 Sample Frequency: Maximum 48 kHz Channels: Maximum 2 Channels Bit rate: Maximum 320 kbps WMA9, WMA9 Professional (WMA Lossless and Voice formats are not supported.) Sample Frequency: Maximum 48 kHz Channels: Maximum 6 Channels Bit rate: VBR/CBR, Maximum 768 kbps
Notes	Combination of WMV HD and WMA Pro may result in frames being dropped. Depending on some WMV HD contents, noise may be generated in the audio signal when starting playback or during the seek operation. Contents with a Complex decoder complexity are not supported.

Table 28 AVI Video File Specifications

Extensions	avi
------------	-----

Table 28 AVI Video File Specifications

Video Stream	XviD, 3ivx Resolution: Maximum 1280 x 720
Audio Stream	MPEG-1/2 Layer-III Sample Frequency: Maximum 48 kHz Channels: Maximum 2 Channels Bit rate: VBR/CBR, Maximum 320 kbps AC3 Sample Frequency: Maximum 48 kHz Channels: Maximum 6 Channels Bit rate: Maximum 640 kbps

Table 29 MPEG4 Video File Specifications

Extensions	mp4
Video Stream	MPEG-4 ASP Resolution: Maximum 1920 x 1080 Bit rate: VBR/CBR, Maximum 5 mbps
Audio Stream	MPEG-4 AAC LC Sample Frequency: Maximum 48 kHz Channels: Maximum 6 Channels Bit rate: Maximum 448 kbps

Table 30 DVR-MS Video File Specifications

Supports content recorded by Windows Media Center Edition 2005. The DMA cannot play DVR-MS files from a USB device. The DMA can play DVR-MS files shared by the included media server software.

Table 31 IFO Video File Specifications

Supports IFO defined by DLNA 1.0 Errata. The DMA cannot play IFO files from a USB device. The DMA can play IFO files shared on a media server that supports them (although the included media server software does not support them).

Music File Formats Supported

Table 32 Music File Specifications

TYPE	EXTENSIONS	DETAILS
MP3	mp3	<p>Audio Stream: MPEG-1/2 Layer-III</p> <p>Sample Frequency: Maximum 48 kHz</p> <p>Channels: Maximum 2 Channels</p> <p>Bit rate: VBR/CBR, Maximum 320 kbps</p> <p>ID3 tag: ID3 version 1.x, 2.2, 2.3, 2.4 tags</p> <p>MP3 file ID3 tags provide information like the title, name of the artist, album name, and track number. The USB browse screens can retrieve and display English language ID3 tag information. The retrieval and display of non-English language tag information is not supported.</p>
LPCM	lpcm	<p>The DMA cannot play LPCM files from a USB device. The DMA can play LPCM files shared on a media server that supports them. The included media server software does not share LPCM files by default. To share LPCM files, you would need to add a published file type using "lpcm" as the file extension and "audio/L16" as the MIME-TYPE.</p> <p>Audio Stream: LPCM</p> <p>Sample Frequency: Min. 8 kHz, Maximum 64 kHz</p> <p>Bits per sample: Maximum 16 bit</p> <p>Channels: Maximum 2 Channels</p>
WAV	wav	<p>Audio Stream: PCM</p> <p>Sample Frequency: Min. 8 kHz, Maximum 64 kHz</p> <p>Bits per sample: Maximum 16 bit</p> <p>Channels: Maximum 2 Channels</p>
WMA	asf wma	<p>Audio Stream: WMA8</p> <p>Sample Frequency: Maximum 48 kHz</p> <p>Channels: Maximum 2 Channels</p> <p>Bit rate: Maximum 320 kbps</p> <p>Audio Stream: WMA9, WMA9 Professional (Contents with a Complex decoder complexity are not supported.)</p> <p>Sample Frequency: Maximum 48 kHz</p> <p>Channels: Maximum 6 Channels</p> <p>Bit rate: VBR/CBR, Maximum 768 kbps</p> <p>With EM8620, L2 profile WMA content must meet the following conditions.</p> <p>Bit rate: 48 kbps ~ 192 kbps</p> <p>Sample Rate: 32 kHz ~ 48 kHz</p>
Ogg	ogg	<p>Audio Stream: Vorbis</p> <p>Sample Frequency: Maximum 48 kHz</p> <p>Channels: Maximum 2 Channels</p> <p>Bit rate: ABR/CBR, Maximum 496 kbps</p>
M4A	m4a	<p>Audio Stream: MPEG-2/4 AAC LC</p> <p>Sample Frequency: Maximum 48 kHz</p> <p>Channels: Maximum 5.1 Channels</p> <p>Bit rate: CBR/VBR, Maximum 640 kbps</p>

Photo File Formats Supported

Table 33 Photo File Specifications

TYPE	EXTENSIONS	DETAILS
JPEG	jpg jpeg	Maximum Resolution: 67174416 pixels (8196 × 8196) When displaying JPEG images that meet the conditions below, the max resolution is 67108864 pixels (8192 × 8192.) It may get smaller when the following conditions are not met. Color Space: YCbCr Not progressive mode The format is YUV420, YUV422 or YUV444 When a JPEG image's color space is RGB or grayscale, the max resolution is 983040 pixels (1280 × 768).
BMP	bmp	Maximum Resolution: Unlimited
PNG	png	Maximum Resolution: 2097152 pixels (2048 × 1024) Although transparent PNG files can be played, they will be displayed as non-transparent images.
TIFF	tif tiff	Maximum Resolution: 2097152 pixels (2048 × 1024) Compression: No compression, ZIP, LZW, Packbits, Huffman RLE, CCITT Fax 3, CCITT Fax 4
GIF	gif	Maximum Resolution: 2097152 pixels (2048 × 1024) Animation GIF formats are not supported.

Wall-mounting Instructions

Complete the following steps to hang your DMA on a wall.



See [Table 22 on page 97](#) for the size of screws to use and how far apart to place them.

- 1 Select a high position on a sturdy wall that is free of obstructions.
- 2 Drill two holes for the screws. The distance between the centers of the holes is listed in the product specifications appendix.




Be careful to avoid damaging pipes or cables located inside the wall when drilling holes for the screws.

- 3 Do not insert the screws all the way into the wall. Leave a small gap of about 0.5 cm between the heads of the screws and the wall.
- 4 Make sure the screws are snugly fastened to the wall. They need to hold the weight of the DMA with the connection cables.


- 5 Align the holes on the back of the DMA with the screws on the wall. Hang the DMA on the screws.

Figure 56 Wall-mounting Example



The following are dimensions of an M4 tap screw and masonry plug used for wall mounting. All measurements are in millimeters (mm).

Figure 57 Masonry Plug and M4 Tap Screw



Cable Pin Assignments

Table 34 Ethernet Cable Pin Assignments

LAN ETHERNET CABLE PIN LAYOUT			
Straight-through			
(Switch)		(Adapter)	
1	IRD +	1	OTD +
2	IRD -	2	OTD -
3	OTD +	3	IRD +
6	OTD -	6	IRD -

Setting up Your Computer's IP Address

All computers must have a 10M or 100M Ethernet adapter card and TCP/IP installed.

Windows 95/98/Me/NT/2000/XP, Macintosh OS 7 and later operating systems and all versions of UNIX/LINUX include the software components you need to install and use TCP/IP on your computer. Windows 3.1 requires the purchase of a third-party TCP/IP application package.


TCP/IP should already be installed on computers using Windows NT/2000/XP, Macintosh OS 7 and later operating systems.

After the appropriate TCP/IP components are installed, configure the TCP/IP settings in order to "communicate" with your network.

If you manually assign IP information instead of using dynamic assignment, make sure that your computers have IP addresses that place them in the same subnet as the DMA's LAN port.

Windows 95/98/Me

Click **Start**, **Settings**, **Control Panel** and double-click the **Network** icon to open the **Network** window.

Figure 58 WIndows 95/98/Me: Network: Configuration

Installing Components

The **Network** window **Configuration** tab displays a list of installed components. You need a network adapter, the TCP/IP protocol and Client for Microsoft Networks.

If you need the adapter:

- 1 In the **Network** window, click **Add**.
- 2 Select **Adapter** and then click **Add**.
- 3 Select the manufacturer and model of your network adapter and then click **OK**.

If you need TCP/IP:

- 1 In the **Network** window, click **Add**.
- 2 Select **Protocol** and then click **Add**.
- 3 Select **Microsoft** from the list of **manufacturers**.
- 4 Select **TCP/IP** from the list of network protocols and then click **OK**.


If you need Client for Microsoft Networks:

- 1 Click **Add**.
- 2 Select **Client** and then click **Add**.
- 3 Select **Microsoft** from the list of manufacturers.
- 4 Select **Client for Microsoft Networks** from the list of network clients and then click **OK**.
- 5 Restart your computer so the changes you made take effect.

Configuring


- 1 In the **Network** window **Configuration** tab, select your network adapter's TCP/IP entry and click **Properties**
- 2 Click the **IP Address** tab.
 - If your IP address is dynamic, select **Obtain an IP address automatically**.
 - If you have a static IP address, select **Specify an IP address** and type your information into the **IP Address** and **Subnet Mask** fields.

Figure 59 Windows 95/98/Me: TCP/IP Properties: IP Address



- 3 Click the **DNS Configuration** tab.
 - If you do not know your DNS information, select **Disable DNS**.
 - If you know your DNS information, select **Enable DNS** and type the information in the fields below (you may not need to fill them all in).

Figure 60 Windows 95/98/Me: TCP/IP Properties: DNS Configuration



- 4 Click the **Gateway** tab.
 - If you do not know your gateway's IP address, remove previously installed gateways.
 - If you have a gateway IP address, type it in the **New gateway field** and click **Add**.
- 5 Click **OK** to save and close the **TCP/IP Properties** window.
- 6 Click **OK** to close the **Network** window. Insert the Windows CD if prompted.
- 7 Turn on your DMA and restart your computer when prompted.


Verifying Settings

- 1 Click **Start** and then **Run**.
- 2 In the **Run** window, type "winipcfg" and then click **OK** to open the **IP Configuration** window.
- 3 Select your network adapter. You should see your computer's IP address, subnet mask and default gateway.


Windows 2000/NT/XP

The following example figures use the default Windows XP GUI theme.


- 1 Click **start** (**Start** in Windows 2000/NT), **Settings**, **Control Panel**.

Figure 61 Windows XP: Start Menu


- 2 In the **Control Panel**, double-click **Network Connections** (Network and Dial-up Connections in Windows 2000/NT).

Figure 62 Windows XP: Control Panel


- 3 Right-click **Local Area Connection** and then click **Properties**.

Figure 63 Windows XP: Control Panel: Network Connections: Properties

- 4 Select **Internet Protocol (TCP/IP)** (under the **General** tab in Win XP) and then click **Properties**.

Figure 64 Windows XP: Local Area Connection Properties


- 5 The **Internet Protocol TCP/IP Properties** window opens (the **General** tab in Windows XP).
 - If you have a dynamic IP address click **Obtain an IP address automatically**.
 - If you have a static IP address click **Use the following IP Address** and fill in the **IP address**, **Subnet mask**, and **Default gateway** fields.
 - Click **Advanced**.

Figure 65 Windows XP: Internet Protocol (TCP/IP) Properties

- 6** If you do not know your gateway's IP address, remove any previously installed gateways in the **IP Settings** tab and click **OK**.

Do one or more of the following if you want to configure additional IP addresses:


- In the **IP Settings** tab, in IP addresses, click **Add**.
- In **TCP/IP Address**, type an IP address in **IP address** and a subnet mask in **Subnet mask**, and then click **Add**.
- Repeat the above two steps for each IP address you want to add.
- Configure additional default gateways in the **IP Settings** tab by clicking **Add** in **Default gateways**.
- In **TCP/IP Gateway Address**, type the IP address of the default gateway in **Gateway**. To manually configure a default metric (the number of transmission hops), clear the **Automatic metric** check box and type a metric in **Metric**.
- Click **Add**.
- Repeat the previous three steps for each default gateway you want to add.
- Click **OK** when finished.

Figure 66 Windows XP: Advanced TCP/IP Properties

7 In the **Internet Protocol TCP/IP Properties** window (the **General** tab in Windows XP):

- Click **Obtain DNS server address automatically** if you do not know your DNS server IP address(es).
- If you know your DNS server IP address(es), click **Use the following DNS server addresses**, and type them in the **Preferred DNS server** and **Alternate DNS server** fields.

If you have previously configured DNS servers, click **Advanced** and then the **DNS** tab to order them.

Figure 67 Windows XP: Internet Protocol (TCP/IP) Properties

- 8** Click **OK** to close the **Internet Protocol (TCP/IP) Properties** window.
- 9** Click **Close** (**OK** in Windows 2000/NT) to close the **Local Area Connection Properties** window.
- 10** Close the **Network Connections** window (**Network and Dial-up Connections** in Windows 2000/NT).
- 11** Turn on your DMA and restart your computer (if prompted).

Verifying Settings


- 1** Click **Start**, **All Programs**, **Accessories** and then **Command Prompt**.
- 2** In the **Command Prompt** window, type "ipconfig" and then press [ENTER]. You can also open **Network Connections**, right-click a network connection, click **Status** and then click the **Support** tab.

Windows Vista

This section shows screens from Windows Vista Enterprise Version 6.0.


- 1** Click the **Start** icon, **Control Panel**.

Figure 68 Windows Vista: Start Menu




2 In the **Control Panel**, double-click **Network and Internet**.

Figure 69 Windows Vista: Control Panel




3 Click **Network and Sharing Center**.

Figure 70 Windows Vista: Network And Internet



4 Click **Manage network connections**.

Figure 71 Windows Vista: Network and Sharing Center




- 5 Right-click **Local Area Connection** and then click **Properties**.




During this procedure, click **Continue** whenever Windows displays a screen saying that it needs your permission to continue.

Figure 72 Windows Vista: Network and Sharing Center




- 6 Select **Internet Protocol Version 4 (TCP/IPv4)** and click **Properties**.

Figure 73 Windows Vista: Local Area Connection Properties



- 7** The **Internet Protocol Version 4 (TCP/IPv4) Properties** window opens (the **General** tab).
- If you have a dynamic IP address click **Obtain an IP address automatically**.
 - If you have a static IP address click **Use the following IP address** and fill in the **IP address**, **Subnet mask**, and **Default gateway** fields.
 - Click **Advanced**.


Figure 74 Windows Vista: Internet Protocol Version 4 (TCP/IPv4) Properties



- 8** If you do not know your gateway's IP address, remove any previously installed gateways in the **IP Settings** tab and click **OK**.

Do one or more of the following if you want to configure additional IP addresses:

- In the **IP Settings** tab, in IP addresses, click **Add**.
- In **TCP/IP Address**, type an IP address in **IP address** and a subnet mask in **Subnet mask**, and then click **Add**.
- Repeat the above two steps for each IP address you want to add.
- Configure additional default gateways in the **IP Settings** tab by clicking **Add** in **Default gateways**.
- In **TCP/IP Gateway Address**, type the IP address of the default gateway in **Gateway**. To manually configure a default metric (the number of transmission hops), clear the **Automatic metric** check box and type a metric in **Metric**.
- Click **Add**.
- Repeat the previous three steps for each default gateway you want to add.
- Click **OK** when finished.


Figure 75 Windows Vista: Advanced TCP/IP Properties

9 In the **Internet Protocol Version 4 (TCP/IPv4) Properties** window, (the **General** tab):

- Click **Obtain DNS server address automatically** if you do not know your DNS server IP address(es).
- If you know your DNS server IP address(es), click **Use the following DNS server addresses**, and type them in the **Preferred DNS server** and **Alternate DNS server** fields.

If you have previously configured DNS servers, click **Advanced** and then the **DNS** tab to order them.

Figure 76 Windows Vista: Internet Protocol Version 4 (TCP/IPv4) Properties




- 10** Click **OK** to close the **Internet Protocol Version 4 (TCP/IPv4) Properties** window.
- 11** Click **Close** to close the **Local Area Connection Properties** window.
- 12** Close the **Network Connections** window.
- 13** Turn on your DMA and restart your computer (if prompted).

Verifying Settings


- 1** Click **Start**, **All Programs**, **Accessories** and then **Command Prompt**.
- 2** In the **Command Prompt** window, type "ipconfig" and then press [ENTER]. You can also open **Network Connections**, right-click a network connection, click **Status** and then click the **Support** tab.

Macintosh OS 8/9

- 1** Click the **Apple** menu, **Control Panel** and double-click **TCP/IP** to open the **TCP/IP Control Panel**.

Figure 77 Macintosh OS 8/9: Apple Menu

- 2 Select **Ethernet built-in** from the **Connect via** list.

Figure 78 Macintosh OS 8/9: TCP/IP

- 3 For dynamically assigned settings, select **Using DHCP Server** from the **Configure:** list.
- 4 For statically assigned settings, do the following:
 - From the **Configure** box, select **Manually**.

- Type your IP address in the **IP Address** box.
 - Type your subnet mask in the **Subnet mask** box.
 - Type the IP address of your DMA in the **Router address** box.
- 5** Close the **TCP/IP Control Panel**.
 - 6** Click **Save** if prompted, to save changes to your configuration.
 - 7** Turn on your DMA and restart your computer (if prompted).


Verifying Settings

Check your TCP/IP properties in the **TCP/IP Control Panel** window.


Macintosh OS X

- 1** Click the **Apple** menu, and click **System Preferences** to open the **System Preferences** window.

Figure 79 Macintosh OS X: Apple Menu



- 2** Click **Network** in the icon bar.
 - Select **Automatic** from the **Location** list.
 - Select **Built-in Ethernet** from the **Show** list.
 - Click the **TCP/IP** tab.
- 3** For dynamically assigned settings, select **Using DHCP** from the **Configure** list.

Figure 80 Macintosh OS X: Network

- 4 For statically assigned settings, do the following:
 - From the **Configure** box, select **Manually**.
 - Type your IP address in the **IP Address** box.
 - Type your subnet mask in the **Subnet mask** box.
 - Type the IP address of your DMA in the **Router address** box.
- 5 Click **Apply Now** and close the window.
- 6 Turn on your DMA and restart your computer (if prompted).

Verifying Settings

Check your TCP/IP properties in the **Network** window.

Linux

This section shows you how to configure your computer's TCP/IP settings in Red Hat Linux 9.0. Procedure, screens and file location may vary depending on your Linux distribution and release version.




Make sure you are logged in as the root administrator.

Using the K Desktop Environment (KDE)

Follow the steps below to configure your computer IP address using the KDE.

- 1 Click the Red Hat button (located on the bottom left corner), select **System Setting** and click **Network**.

Figure 81 Red Hat 9.0: KDE: Network Configuration: Devices




- 2 Double-click on the profile of the network card you wish to configure. The **Ethernet Device General** screen displays as shown.


Figure 82 Red Hat 9.0: KDE: Ethernet Device: General



- If you have a dynamic IP address, click **Automatically obtain IP address settings with** and select **dhcp** from the drop down list.
 - If you have a static IP address, click **Statically set IP Addresses** and fill in the **Address**, **Subnet mask**, and **Default Gateway Address** fields.
- 3 Click **OK** to save the changes and close the **Ethernet Device General** screen.
 - 4 If you know your DNS server IP address(es), click the **DNS** tab in the **Network Configuration** screen. Enter the DNS server information in the fields provided.

Figure 83 Red Hat 9.0: KDE: Network Configuration: DNS

- 5 Click the **Devices** tab.
- 6 Click the **Activate** button to apply the changes. The following screen displays. Click **Yes** to save the changes in all screens.

Figure 84 Red Hat 9.0: KDE: Network Configuration: Activate

- 7 After the network card restart process is complete, make sure the **Status** is **Active** in the **Network Configuration** screen.

Using Configuration Files

Follow the steps below to edit the network configuration files and set your computer IP address.

- 1 Assuming that you have only one network card on the computer, locate the `ifconfig-eth0` configuration file (where `eth0` is the name of the Ethernet card). Open the configuration file with any plain text editor.
 - If you have a dynamic IP address, enter **dhcp** in the `BOOTPROTO=` field. The following figure shows an example.

Figure 85 Red Hat 9.0: Dynamic IP Address Setting in ifconfig-eth0

```
DEVICE=eth0
ONBOOT=yes
BOOTPROTO=dhcp
USERCTL=no
PEERDNS=yes
TYPE=Ethernet
```

- If you have a static IP address, enter **static** in the **BOOTPROTO=** field. Type **IPADDR=** followed by the IP address (in dotted decimal notation) and type **NETMASK=** followed by the subnet mask. The following example shows an example where the static IP address is 192.168.1.10 and the subnet mask is 255.255.255.0.

Figure 86 Red Hat 9.0: Static IP Address Setting in ifconfig-eth0

```
DEVICE=eth0
ONBOOT=yes
BOOTPROTO=static
IPADDR=192.168.1.10
NETMASK=255.255.255.0
USERCTL=no
PEERDNS=yes
TYPE=Ethernet
```

- 2 If you know your DNS server IP address(es), enter the DNS server information in the `resolv.conf` file in the `/etc` directory. The following figure shows an example where two DNS server IP addresses are specified.

Figure 87 Red Hat 9.0: DNS Settings in resolv.conf

```
nameserver 172.23.5.1
nameserver 172.23.5.2
```

- 3 After you edit and save the configuration files, you must restart the network card. Enter `./network restart` in the `/etc/rc.d/init.d` directory. The following figure shows an example.

Figure 88 Red Hat 9.0: Restart Ethernet Card

```
[root@localhost init.d]# network restart

Shutting down interface eth0:           [OK]
Shutting down loopback interface:       [OK]
Setting network parameters:            [OK]
Bringing up loopback interface:         [OK]
Bringing up interface eth0:             [OK]
```

Verifying Settings

Enter `ifconfig` in a terminal screen to check your TCP/IP properties.

Figure 89 Red Hat 9.0: Checking TCP/IP Properties

```
[root@localhost]# ifconfig
eth0      Link encap:Ethernet  HWaddr 00:50:BA:72:5B:44
          inet addr:172.23.19.129  Bcast:172.23.19.255  Mask:255.255.255.0
          UP BROADCAST RUNNING MULTICAST  MTU:1500  Metric:1
          RX packets:717 errors:0 dropped:0 overruns:0 frame:0
          TX packets:13 errors:0 dropped:0 overruns:0 carrier:0
          collisions:0 txqueuelen:100
          RX bytes:730412 (713.2 Kb)  TX bytes:1570 (1.5 Kb)
          Interrupt:10 Base address:0x1000
[root@localhost]#
```


Windows Vista Media Server




This appendix is provided for your information only. The DMA is not Vista certified.

Playing Media Files From Your Windows Vista Computer

This appendix covers using the media server included in Windows Vista to let the DMA play media files on the computer. This way you do not need to install media server software. In the following figure, the DMA and your Windows Vista computer (A) are both connected to your home network.

Figure 90 DMA with Windows Vista Computer



This appendix walks you through the following tasks:

- Starting the Windows Media Player
- Setting Your Computer to Trust Your Network
- Setting Your Computer to Share Files With the DMA
- Selecting Files to Share

Complete the sections in sequence. The DMA and the computer must be on the same home network (private LAN). This appendix shows screens from Windows Vista Enterprise Version 6.0.

Starting the Windows Media Player Network Sharing Service

If you are using Windows Vista, do the following to turn on the Windows Media Player.


- 1 Follow the Quick Start Guide Instructions to connect the DMA to your computer.
- 2 Right-click the **Computer** icon and click **Manage**.



During this procedure, click Continue whenever Windows displays a screen saying that it needs your permission to continue.

- 3 In the following screen, click **Services and Applications > Services > Windows Media Player Network Sharing Service > Start**.


Figure 91 Start WIndows Media Player




Setting Your Computer to Trust Your Network

The DMA and your computer are both on your home network, so you use this section to configure your computer to treat the network connection as a trusted private network. Make sure the DMA has a network connection to your computer before using this section.

- 1 Click the **Windows Media Player** icon in the system tray.

Figure 92 Start Windows Media Player


2 Right-click in the menu bar and click **Tools > Options**.

Figure 93 Windows Media Player Tools> Options


3 In the **Library** tab, click **Configure Sharing**.

Figure 94 Library


4 Click **Networking**.

Figure 95 Media Sharing

- 5 Windows searches for your network connections and displays them in the following window. Click **Customize**.

Figure 96 Network and Sharing Center


- 6 Select **Private** and click **Next** to have the computer trust the network connection to the DMA.

Figure 97 Set Network Location: Customize network settings


Setting Your Computer to Share Files With the DMA

This section covers how to set Windows Media Player to allow the DMA to play media files.


- 1 Click **View computers and devices on the network**.

Figure 98 Set Network Location: Successfully set network settings


- 2 Right-click the DMA icon and click **Open Media Sharing**.

Figure 99 Network

3 Select **Share my media** and click **OK**.

Figure 100 Media Sharing


4 Identify the device that the computer should share media files with. Select the DMA icon and click **Allow** > **OK**.

Figure 101 Media Sharing: Select DMA


Selecting Files to Share

This section covers how to select the media files that the DMA is allowed to play.


- 1 In the **Library** tab, click **Monitor Folders**.

Figure 102 Library


- 2 Click **Advanced Options**.

Figure 103 Add To Library

3 Select the folders to share and click **OK** when you are done.

Figure 104 Add To Library > Advanced

4 Click **OK** after the computer finds the files to share.

Figure 105 Add To Library Search

Open Software Announcements

Notice

Information herein is subject to change without notice. Companies, names, and data used in examples herein are fictitious unless otherwise noted. No part may be reproduced or transmitted in any form or by any means, electronic or mechanical, for any purpose, except the express written permission of ZyXEL Communications Corporation.

This DMA-1100P product included Third Party Software with the license conditions as specified below.

DiXiM DMA application is proprietary of DigiOn except:

Below GPL modules by GUN General Public License.

*busybox 1.0.0
original:
busybox-1.00.tar.bz2

patch:
busybox-1.00+autoip.060915.patch

*uClinux 2.4.22
original:
linux-2.4.22.tar.bz2
uClinux-2.4.22-uc0.diff.bz2

patch:
linux-2.4.22-patches.tar.bz2

Sigma SDK provided by Sigma Designs covering below third party license

MRUA Package

Software included in the MRUA package is proprietary Sigma Designs except:

Jpeg library:

All the files in MRUA_src/rmlibjpeg/src/libjpeg Custom license

Png library:

All the files in MRUA_src/rmlibpng/src/libpng Custom license

Gif library:

All the files in MRUA_src/rmlibungif/src/libungi Custom license

http library:

MRUA_src/rmlibhttp/src/common.c

MRUA_src/rmlibhttp/src/http.c

Custom license

Vera.ttf:

MRUA_src/samples/Vera.ttf

bin/Vera.ttf

Custom license

VeraMono.ttf:

File located in MRUA_src/samples/VeraMono.ttf File located in bin/VeraMono.ttf

Custom license

UPnP Library:

MRUA_src/rmupnp/upnp_stack/_MediaServerControlPointStack/MmsCp.h MRUA_src/
rmupnp/upnp_stack/_MediaServerControlPointStack/MmsCp.c MRUA_src/rmupnp/
upnp_stack/_Utility/MyString.c

MRUA_src/rmupnp/upnp_stack/_Utility/MyString.h

MRUA_src/rmupnp/upnp_stack/_ControlPointCoreStack/ILibSSDPClient.c

MRUA_src/rmupnp/upnp_stack/_ControlPointCoreStack/ILibParsers.c

MRUA_src/rmupnp/upnp_stack/_ControlPointCoreStack/ILibWebClient.h

MRUA_src/rmupnp/upnp_stack/_ControlPointCoreStack/MSCP_ControlPoint.c

MRUA_src/rmupnp/upnp_stack/_ControlPointCoreStack/ILibParsers.h

MRUA_src/rmupnp/upnp_stack/_ControlPointCoreStack/ILibWebServer.c

MRUA_src/rmupnp/upnp_stack/_ControlPointCoreStack/ILibWebServer.h

MRUA_src/rmupnp/upnp_stack/_ControlPointCoreStack/ILibSSDPClient.h

MRUA_src/rmupnp/upnp_stack/_ControlPointCoreStack/UPnPControlPointStructs.h

MRUA_src/rmupnp/upnp_stack/_ControlPointCoreStack/BrowseOnly-Posix.upnpsg

MRUA_src/rmupnp/upnp_stack/_ControlPointCoreStack/ILibAsyncServerSocket.h

MRUA_src/rmupnp/upnp_stack/_ControlPointCoreStack/ILibWebClient.c

MRUA_src/rmupnp/upnp_stack/_ControlPointCoreStack/ILibAsyncSocket.h

MRUA_src/rmupnp/upnp_stack/_ControlPointCoreStack/ILibAsyncSocket.c

MRUA_src/rmupnp/upnp_stack/_ControlPointCoreStack/ILibAsyncServerSocket.c

MRUA_src/rmupnp/upnp_stack/_ControlPointCoreStack/MSCP_ControlPoint.h

Intel license

Mambolfb (Linux Frame Buffer Driver):

em86xxfb-2_6.c

vfb.c

GPL License (see ARMUtils package)

JPEG License LEGAL ISSUES

In plain English:

1. We don't promise that this software works. (But if you find any bugs, please let us know!)
2. You can use this software for whatever you want. You don't have to pay us.
3. You may not pretend that you wrote this software. If you use it in a program, you must acknowledge somewhere in your documentation that you've used the IJG code.

In legalese:

The authors make NO WARRANTY or representation, either express or implied, with respect to this software, its quality, accuracy, merchantability, or fitness for a particular purpose. This software is provided "AS IS", and you, its user, assume the entire risk as to its quality and accuracy.

This software is copyright (C) 1991-1998, Thomas G. Lane. All Rights Reserved except as specified below.

Permission is hereby granted to use, copy, modify, and distribute this software (or portions thereof) for any purpose, without fee, subject to these conditions:

(1) If any part of the source code for this software is distributed, then this README file must be included, with this copyright and no-warranty notice unaltered; and any additions, deletions, or changes to the original files must be clearly indicated in accompanying documentation.

(2) If only executable code is distributed, then the accompanying documentation must state that "this software is based in part on the work of the Independent JPEG Group".

(3) Permission for use of this software is granted only if the user accepts full responsibility for any undesirable consequences; the authors accept NO LIABILITY for damages of any kind.

These conditions apply to any software derived from or based on the IJG code, not just to the unmodified library. If you use our work, you ought to acknowledge us.

Permission is NOT granted for the use of any IJG author's name or company name in advertising or publicity relating to this software or products derived from it. This software may be referred to only as "the Independent JPEG Group's software".

We specifically permit and encourage the use of this software as the basis of commercial products, provided that all warranty or liability claims are assumed by the product vendor.

PNG License

- * libpng version 1.2.5 - October 3, 2002
- * Copyright (c) 1998-2002 Glenn Randers-Pehrson
- * (Version 0.96 Copyright (c) 1996, 1997 Andreas Dilger)
- * (Version 0.88 Copyright (c) 1995, 1996 Guy Eric Schalnat, Group 42, Inc.)
- *
- * Authors and maintainers:
- * libpng versions 0.71, May 1995, through 0.88, January 1996: Guy Schalnat
- * libpng versions 0.89c, June 1996, through 0.96, May 1997: Andreas Dilger
- * libpng versions 0.97, January 1998, through 1.2.5 - October 3, 2002: Glenn
- * See also "Contributing Authors", below.
- *
- * Note about libpng version numbers:
- *
- * Due to various miscommunications, unforeseen code incompatibilities
- * and occasional factors outside the authors' control, version numbering
- * on the library has not always been consistent and straightforward.
- * The following table summarizes matters since version 0.89c, which was
- * the first widely used release:
- *
- * source png.h png.h shared-lib
- * version string int version
- *
- * 0.89c "1.0 beta 3" 0.89 89 1.0.89
- * 0.90 "1.0 beta 4" 0.90 90 0.90 [should have been 2.0.90]
- * 0.95 "1.0 beta 5" 0.95 95 0.95 [should have been 2.0.95]
- * 0.96 "1.0 beta 6" 0.96 96 0.96 [should have been 2.0.96]
- * 0.97b "1.00.97 beta 7" 1.00.97 97 1.0.1 [should have been 2.0.97]
- * 0.97c 0.97 97 2.0.97
- * 0.98 0.98 98 2.0.98
- * 0.99 0.99 98 2.0.99
- * 0.99a-m 0.99 99 2.0.99
- * 1.00 1.00 100 2.1.0 [100 should be 10000]
- * 1.0.0 (from here on, the 100 2.1.0 [100 should be 10000]
- * 1.0.1 png.h string is 10001 2.1.0
- * 1.0.1a-e identical to the 10002 from here on, the shared library

- * 1.0.2 source version) 10002 is 2.V where V is the source code
- * 1.0.2a-b 10003 version, except as noted.
- * 1.0.3 10003
- * 1.0.3a-d 10004
- * 1.0.4 10004
- * 1.0.4a-f 10005
- * 1.0.5 (+ 2 patches) 10005
- * 1.0.5a-d 10006
- * 1.0.5e-r 10100 (not source compatible)
- * 1.0.5s-v 10006 (not binary compatible)
- * 1.0.6 (+ 3 patches) 10006 (still binary incompatible)
- * 1.0.6d-f 10007 (still binary incompatible)
- * 1.0.6g 10007
- * 1.0.6h 10007 10.6h (testing xy.z so-numbering)
- * 1.0.6i 10007 10.6i
- * 1.0.6j 10007 2.1.0.6j (incompatible with 1.0.0)
- * 1.0.7beta11-14 DLLNUM 10007 2.1.0.7beta11-14 (binary compatible)
- * 1.0.7beta15-18 1 10007 2.1.0.7beta15-18 (binary compatible)
- * 1.0.7rc1-2 1 10007 2.1.0.7rc1-2 (binary compatible)
- * 1.0.7 1 10007 (still compatible)
- * 1.0.8beta1-4 1 10008 2.1.0.8beta1-4
- * 1.0.8rc1 1 10008 2.1.0.8rc1
- * 1.0.8 1 10008 2.1.0.8
- * 1.0.9beta1-6 1 10009 2.1.0.9beta1-6
- * 1.0.9rc1 1 10009 2.1.0.9rc1
- * 1.0.9beta7-10 1 10009 2.1.0.9beta7-10
- * 1.0.9rc2 1 10009 2.1.0.9rc2
- * 1.0.9 1 10009 2.1.0.9
- * 1.0.10beta1 1 10010 2.1.0.10beta1
- * 1.0.10rc1 1 10010 2.1.0.10rc1
- * 1.0.10 1 10010 2.1.0.10
- * 1.0.11beta1-3 1 10011 2.1.0.11beta1-3
- * 1.0.11rc1 1 10011 2.1.0.11rc1
- * 1.0.11 1 10011 2.1.0.11
- * 1.0.12beta1-2 2 10012 2.1.0.12beta1-2
- * 1.0.12rc1 2 10012 2.1.0.12rc1

- * 1.0.12 2 10012 2.1.0.12
- * 1.1.0a-f - 10100 2.1.1.0a-f (branch abandoned)
- * 1.2.0beta1-2 2 10200 2.1.2.0beta1-2
- * 1.2.0beta3-5 3 10200 3.1.2.0beta3-5
- * 1.2.0rc1 3 10200 3.1.2.0rc1
- * 1.2.0 3 10200 3.1.2.0
- * 1.2.1beta1-4 3 10201 3.1.2.1beta1-4
- * 1.2.1rc1-2 3 10201 3.1.2.1rc1-2
- * 1.2.1 3 10201 3.1.2.1
- * 1.2.2beta1-6 12 10202 12.so.0.1.2.2beta1-6
- * 1.0.13beta1 10 10013 10.so.0.1.0.13beta1
- * 1.0.13rc1 10 10013 10.so.0.1.0.13rc1
- * 1.2.2rc1 12 10202 12.so.0.1.2.2rc1
- * 1.0.13 10 10013 10.so.0.1.0.13
- * 1.2.2 12 10202 12.so.0.1.2.2
- * 1.2.3rc1-6 12 10203 12.so.0.1.2.3rc1-6
- * 1.2.3 12 10203 12.so.0.1.2.3
- * 1.2.4beta1-3 13 10204 12.so.0.1.2.4beta1-3
- * 1.0.14rc1 13 10014 10.so.0.1.0.14rc1
- * 1.2.4rc1 13 10204 12.so.0.1.2.4rc1
- * 1.0.14 10 10014 10.so.0.1.0.14
- * 1.2.4 13 10204 12.so.0.1.2.4
- * 1.2.5beta1-2 13 10205 12.so.0.1.2.5beta1-2
- * 1.0.15rc1-3 10 10015 10.so.0.1.0.15rc1-3
- * 1.2.5rc1-3 13 10205 12.so.0.1.2.5rc1-3
- * 1.0.15 10 10015 10.so.0.1.0.15
- * 1.2.5 13 10205 12.so.0.1.2.5
- *
- * Henceforth the source version will match the shared-library major
- * and minor numbers; the shared-library major version number will be
- * used for changes in backward compatibility, as it is intended. The
- * PNG_LIBPNG_VER macro, which is not used within libpng but is available
- * for applications, is an unsigned integer of the form xyyzz corresponding
- * to the source version x.y.z (leading zeros in y and z). Beta versions
- * were given the previous public release number plus a letter, until
- * version 1.0.6j; from then on they were given the upcoming public

* release number plus "betaNN" or "rcN".

*

* Binary incompatibility exists only when applications make direct access

* to the info_ptr or png_ptr members through png.h, and the compiled

* application is loaded with a different version of the library.

*

* DLLNUM will change each time there are forward or backward changes

* in binary compatibility (e.g., when a new feature is added).

*

* See libpng.txt or libpng.3 for more information. The PNG specification

* is available as RFC 2083 <<ftp://ftp.uu.net/graphics/png/documents/>>

* and as a W3C Recommendation <<http://www.w3.org/TR/REC.png.html>>

*/

/*

* COPYRIGHT NOTICE, DISCLAIMER, and LICENSE:

*

* If you modify libpng you may insert additional notices immediately following

* this sentence.

*

* libpng versions 1.0.7, July 1, 2000, through 1.2.5, October 3, 2002, are

* Copyright (c) 2000-2002 Glenn Randers-Pehrson, and are

* distributed according to the same disclaimer and license as libpng-1.0.6

* with the following individuals added to the list of Contributing Authors

*

* Simon-Pierre Cadieux

* Eric S. Raymond

* Gilles Vollant

*

* and with the following additions to the disclaimer:

*

* There is no warranty against interference with your enjoyment of the

* library or against infringement. There is no warranty that our

* efforts or the library will fulfill any of your particular purposes

* or needs. This library is provided with all faults, and the entire

* risk of satisfactory quality, performance, accuracy, and effort is with

* the user.

- *
- * libpng versions 0.97, January 1998, through 1.0.6, March 20, 2000, are
- * Copyright (c) 1998, 1999, 2000 Glenn Randers-Pehrson
- * Distributed according to the same disclaimer and license as libpng-0.96,
- * with the following individuals added to the list of Contributing Authors:
- *
- * Tom Lane
- * Glenn Randers-Pehrson
- * Willem van Schaik
- *
- * libpng versions 0.89, June 1996, through 0.96, May 1997, are
- * Copyright (c) 1996, 1997 Andreas Dilger
- * Distributed according to the same disclaimer and license as libpng-0.88,
- * with the following individuals added to the list of Contributing Authors:
- *
- * John Bowler
- * Kevin Bracey
- * Sam Bushell
- * Magnus Holmgren
- * Greg Roelofs
- * Tom Tanner
- *
- * libpng versions 0.5, May 1995, through 0.88, January 1996, are
- * Copyright (c) 1995, 1996 Guy Eric Schalnat, Group 42, Inc.
- *
- * For the purposes of this copyright and license, "Contributing Authors"
- * is defined as the following set of individuals:
- *
- * Andreas Dilger
- * Dave Martindale
- * Guy Eric Schalnat
- * Paul Schmidt
- * Tim Wegner
- *
- * The PNG Reference Library is supplied "AS IS". The Contributing Authors
- * and Group 42, Inc. disclaim all warranties, expressed or implied,

* including, without limitation, the warranties of merchantability and of
 * fitness for any purpose. The Contributing Authors and Group 42, Inc.
 * assume no liability for direct, indirect, incidental, special, exemplary,
 * or consequential damages, which may result from the use of the PNG
 * Reference Library, even if advised of the possibility of such damage.
 *

* Permission is hereby granted to use, copy, modify, and distribute this * source code, or
 portions hereof, for any purpose, without fee, subject * to the following restrictions:
 *

- * 1. The origin of this source code must not be misrepresented.
*
- * 2. Altered versions must be plainly marked as such and
* must not be misrepresented as being the original source.
*
- * 3. This Copyright notice may not be removed or altered from * any source or altered source
distribution.
*

* The Contributing Authors and Group 42, Inc. specifically permit, without * fee, and
 encourage the use of this source code as a component to
 * supporting the PNG file format in commercial products. If you use this * source code in a
 product, acknowledgment is not required but would be
 * appreciated.
 */
 /*

* A "png_get_copyright" function is available, for convenient use in "about" * boxes and the
 like:
 *

```

* printf("%s",png_get_copyright(NULL));
*

```

* Also, the PNG logo (in PNG format, of course) is supplied in the
 * files "pngbar.png" and "pngbar.jpg (88x31) and "pngnow.png" (98x31).
 */
 /*

* Libpng is OSI Certified Open Source Software. OSI Certified is a
 * certification mark of the Open Source Initiative.
 */
 /*

* The contributing authors would like to thank all those who helped * with testing, bug fixes,
 and patience. This wouldn't have been * possible without all of you.
 *

```
* Thanks to Frank J. T. Wojcik for helping with the documentation.
*/
/*
* Y2K compliance in libpng:
* =====
*
* October 3, 2002
*
* Since the PNG Development group is an ad-hoc body, we can't make
* an official declaration.
*
* This is your unofficial assurance that libpng from version 0.71 and
* upward through 1.2.5 are Y2K compliant. It is my belief that earlier
* versions were also Y2K compliant.
*
* Libpng only has three year fields. One is a 2-byte unsigned integer
* that will hold years up to 65535. The other two hold the date in text
* format, and will hold years up to 9999.
*
* The integer is
* "png_uint_16 year" in png_time_struct.
*
* The strings are
* "png_charp time_buffer" in png_struct and
* "near_time_buffer", which is a local character string in png.c.
*
* There are seven time-related functions:
* png.c: png_convert_to_rfc_1123() in png.c
* (formerly png_convert_to_rfc_1152() in error)
* png_convert_from_struct_tm() in pngwrite.c, called in pngwrite.c
* png_convert_from_time_t() in pngwrite.c
* png_get_tIME() in pngget.c
* png_handle_tIME() in pngutil.c, called in pngread.c
* png_set_tIME() in pngset.c
* png_write_tIME() in pngutil.c, called in pngwrite.c
*
* All handle dates properly in a Y2K environment. The
```

```

* png_convert_from_time_t() function calls gmtime() to convert from system
* clock time, which returns (year - 1900), which we properly convert to
* the full 4-digit year. There is a possibility that applications using
* libpng are not passing 4-digit years into the png_convert_to_rfc_1123()
* function, or that they are incorrectly passing only a 2-digit year
* instead of "year - 1900" into the png_convert_from_struct_tm() function,
* but this is not under our control. The libpng documentation has always
* stated that it works with 4-digit years, and the APIs have been
* documented as such.
*
* The tIME chunk itself is also Y2K compliant. It uses a 2-byte unsigned
* integer to hold the year, and can hold years as large as 65535.
*
* zlib, upon which libpng depends, is also Y2K compliant. It contains
* no date-related code.
*
* Glenn Randers-Pehrson
* libpng maintainer
* PNG Development Group
*/

```

GIF License

The GIFLIB distribution is Copyright (c) 1997 Eric S. Raymond

Permission is hereby granted, free of charge, to any person obtaining a copy of this software and associated documentation files (the "Software"), to deal in the Software without restriction, including without limitation the rights to use, copy, modify, merge, publish, distribute, sublicense, and/or sell copies of the Software, and to permit persons to whom the Software is furnished to do so, subject to the following conditions:

The above copyright notice and this permission notice shall be included in all copies or substantial portions of the Software.

THE SOFTWARE IS PROVIDED "AS IS", WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT. IN NO EVENT SHALL THE AUTHORS OR COPYRIGHT HOLDERS BE LIABLE FOR ANY CLAIM, DAMAGES OR OTHER LIABILITY, WHETHER IN AN ACTION OF CONTRACT, TORT OR OTHERWISE,

ARISING FROM,
OUT OF OR IN CONNECTION WITH THE SOFTWARE OR THE USE OR OTHER
DEALINGS IN
THE SOFTWARE.

libHTTP License

```
/*_  
 * Copyright (c) 2000-2004 Dag-Erling Coˆdan Smˆrgrav * All rights reserved.  
 *  
 * Redistribution and use in source and binary forms, with or without * modification, are  
 * permitted provided that the following conditions * are met:  
 * 1. Redistributions of source code must retain the above copyright  
 * notice, this list of conditions and the following disclaimer  
 * in this position and unchanged.  
 * 2. Redistributions in binary form must reproduce the above copyright  
 * notice, this list of conditions and the following disclaimer in the  
 * documentation and/or other materials provided with the distribution.  
 * 3. The name of the author may not be used to endorse or promote products  
 * derived from this software without specific prior written permission.  
 *  
 * THIS SOFTWARE IS PROVIDED BY THE AUTHOR ``AS IS" AND ANY EXPRESS OR  
 * IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED  
 * WARRANTIES  
 * OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE  
 * DISCLAIMED.  
 * IN NO EVENT SHALL THE AUTHOR BE LIABLE FOR ANY DIRECT, INDIRECT,  
 * INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES  
 * (INCLUDING, BUT  
 * NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS  
 * OF USE,  
 * DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND  
 * ON ANY  
 * THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT  
 * (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE  
 * USE OF  
 * THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.  
 */  
/*_  
 * The following copyright applies to the base64 code:  
 *  
 */
```

* Copyright 1997 Massachusetts Institute of Technology
 *
 * Permission to use, copy, modify, and distribute this software and
 * its documentation for any purpose and without fee is hereby
 * granted, provided that both the above copyright notice and this
 * permission notice appear in all copies, that both the above
 * copyright notice and this permission notice appear in all
 * supporting documentation, and that the name of M.I.T. not be used
 * in advertising or publicity pertaining to distribution of the
 * software without specific, written prior permission. M.I.T. makes
 * no representations about the suitability of this software for any
 * purpose. It is provided "as is" without express or implied
 * warranty.
 *
 * THIS SOFTWARE IS PROVIDED BY M.I.T. ``AS IS". M.I.T. DISCLAIMS
 * ALL EXPRESS OR IMPLIED WARRANTIES WITH REGARD TO THIS SOFTWARE,
 * INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF
 * MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. IN NO
 * EVENT
 * SHALL M.I.T. BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL,
 * SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT
 * NOT
 * LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF
 * USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED
 * AND
 * ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY,
 * OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY
 * OUT
 * OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF
 * SUCH DAMAGE.
 */

Vera.ttf License

{ Copyright (c) 2003 by Bitstream, Inc. All Rights Reserved. Bitstream Vera
 Sans Bitstream Vera Sans-Roman Release 1.10 Copyright (c) 2003 by Bitstream, Inc. All Rights
 Reserved.

Bitstream Vera is a trademark of Bitstream, Inc.

Permission is hereby granted, free of charge, to any person obtaining a copy of the fonts accompanying this license ("Fonts") and associated documentation files (the "Font Software"), to reproduce and distribute the Font Software, including without limitation the rights to use, copy, merge, publish, distribute, and/or sell copies of the Font Software, and to permit persons to whom the Font Software is furnished to do so, subject to the following conditions:

The above copyright and trademark notices and this permission notice shall be included in all copies of one or more of the Font Software typefaces.

The Font Software may be modified, altered, or added to, and in particular the designs of glyphs or characters in the Fonts may be modified and additional glyphs or characters may be added to the Fonts, only if the fonts are renamed to names not containing either the words "Bitstream" or the word "Vera".

This License becomes null and void to the extent applicable to Fonts or Font Software that has been modified and is distributed under the "Bitstream Vera" names.

The Font Software may be sold as part of a larger software package but no copy of one or more of the Font Software typefaces may be sold by itself.

THE FONT SOFTWARE IS PROVIDED "AS IS", WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO ANY WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT OF COPYRIGHT, PATENT, TRADEMARK, OR OTHER RIGHT. IN NO EVENT SHALL BITSTREAM OR THE GNOME FOUNDATION BE LIABLE FOR ANY CLAIM, DAMAGES OR OTHER LIABILITY, INCLUDING ANY GENERAL, SPECIAL, INDIRECT, INCIDENTAL, OR CONSEQUENTIAL DAMAGES, WHETHER IN AN ACTION OF CONTRACT, TORT OR OTHERWISE, ARISING FROM, OUT OF THE USE OR INABILITY TO USE THE FONT SOFTWARE OR FROM OTHER DEALINGS IN THE FONT SOFTWARE.

Except as contained in this notice, the names of Gnome, the Gnome Foundation, and Bitstream Inc., shall not be used in advertising or otherwise to promote the sale, use or other dealings in this Font Software without prior written authorization from the Gnome Foundation or Bitstream Inc., respectively. For further information, contact: fonts at gnome dot org.http://www.bitstream.com_

VeraMono.ttf License

-Copyright (c) 2003 by Bitstream, Inc. All Rights Reserved.Bitstream Vera Sans MonoBitstreamVeraSansMono-RomanRelease 1.10Copyright (c) 2003 by Bitstream, Inc.

All Rights Reserved.

Bitstream Vera is a trademark of Bitstream, Inc.

Permission is hereby granted, free of charge, to any person obtaining a copy of the fonts accompanying this license ("Fonts") and associated documentation files (the "Font Software"), to reproduce and distribute the Font Software, including without limitation the rights to use, copy, merge, publish, distribute, and/or sell copies of the Font Software, and to permit persons to whom the Font Software is furnished to do so, subject to the following conditions:

The above copyright and trademark notices and this permission notice shall be included in all copies of one or more of the Font Software typefaces.

The Font Software may be modified, altered, or added to, and in particular the designs of glyphs or characters in the Fonts may be modified and additional glyphs or characters may be added to the Fonts, only if the fonts are renamed to names not containing either the words "Bitstream" or the word "Vera".

This License becomes null and void to the extent applicable to Fonts or Font Software that has been modified and is distributed under the "Bitstream Vera" names.

The Font Software may be sold as part of a larger software package but no copy of one or more of the Font Software typefaces may be sold by itself.

THE FONT SOFTWARE IS PROVIDED "AS IS", WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO ANY WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT OF COPYRIGHT, PATENT, TRADEMARK, OR OTHER RIGHT. IN NO EVENT SHALL BITSTREAM OR THE GNOME FOUNDATION BE LIABLE FOR ANY CLAIM, DAMAGES OR OTHER LIABILITY, INCLUDING ANY GENERAL, SPECIAL, INDIRECT, INCIDENTAL, OR CONSEQUENTIAL DAMAGES, WHETHER IN AN ACTION OF CONTRACT, TORT OR OTHERWISE, ARISING FROM, OUT OF THE USE OR INABILITY TO USE THE FONT SOFTWARE OR FROM OTHER DEALINGS IN THE FONT SOFTWARE.

Except as contained in this notice, the names of Gnome, the Gnome Foundation, and Bitstream Inc., shall not be used in advertising or otherwise to promote the sale, use or other dealings in this Font Software without prior written authorization from the Gnome Foundation or Bitstream Inc., respectively. For further information, contact: fonts at gnome dot org.http://www.bitstream.com_

Intel license (UPnP Library)

INTEL SOFTWARE SOURCE CODE LICENSE AGREEMENT IMPORTANT - READ BEFORE COPYING, INSTALLING OR USING

Do not use or load this software and any associated materials (collectively, the "Software") until you have carefully read the following terms and conditions. By loading or using the Software, you agree to the terms of this Agreement. If you do not wish to so agree, do not install or use the Software.

DEFINITIONS. "Licensed Product" means UPnP Forum compliant software developed by Licensee that incorporates the Intel Software in whole or in part, in source code or object code form, within Licensee's product offering.

LICENSE. Subject to the terms and conditions of this Agreement, Intel hereby grants to Licensee under Intel's copyrights in the Intel Software as delivered a nonexclusive, nontransferable, non sub-licensable worldwide, perpetual (subject to revocation for material breach of this license grant), royalty free license to copy, modify and create derivative works of the source code of the Intel Software solely for the purpose of developing Licensed Products.

OWNERSHIP OF SOFTWARE AND COPYRIGHTS. Title to all copies of the Software remains with Intel or its suppliers. The Software is copyrighted and protected by the laws of the United States and other countries, and international treaty provisions. You may not remove any copyright notices from the Software. Intel may make changes to the Software, or to items referenced therein, at any time without notice, but is not obligated to support or update the Software. Except as otherwise expressly provided, Intel grants no express or implied right under Intel patents, copyrights, trademarks, or other intellectual property rights. You may transfer the Software only if the recipient agrees to be fully bound by these terms and if you retain no copies of the Software.

ATTRIBUTION. Licensee shall provide reasonable attribution to Intel in any software that it creates using the Intel Source or Object Code providing under this Agreement. In the case of source code, Licensee agrees that Intel headers shall not be modified. Licensed Products shall display "Portions Copyright ?2004 Intel Corporation" in "About" boxes or provide such similar attribution.

LIMITED MEDIA WARRANTY. If the Software has been delivered by Intel on physical media, Intel warrants the media to be free from material physical defects for a period of ninety days after delivery by Intel. If such a defect is found, return the media to Intel for replacement or alternate delivery of the Software as Intel may select.

EXCLUSION OF OTHER WARRANTIES. EXCEPT AS PROVIDED ABOVE, THE SOFTWARE IS PROVIDED "AS IS" WITHOUT ANY EXPRESS OR IMPLIED WARRANTY OF ANY KIND INCLUDING WARRANTIES OF MERCHANTABILITY, NONINFRINGEMENT, OR FITNESS FOR A PARTICULAR PURPOSE. Intel does not warrant or assume responsibility for the accuracy or completeness of any information, text, graphics, links or other items contained within the Software.

LIMITATION OF LIABILITY. IN NO EVENT SHALL INTEL OR ITS SUPPLIERS BE LIABLE FOR ANY DAMAGES WHATSOEVER (INCLUDING, WITHOUT LIMITATION, LOST PROFITS, BUSINESS INTERRUPTION, OR LOST INFORMATION) ARISING OUT OF THE USE OF OR INABILITY TO USE THE SOFTWARE, EVEN IF INTEL HAS BEEN

ADVISED OF THE POSSIBILITY OF SUCH DAMAGES. SOME JURISDICTIONS PROHIBIT EXCLUSION OR LIMITATION OF LIABILITY FOR IMPLIED WARRANTIES OR CONSEQUENTIAL OR INCIDENTAL DAMAGES, SO THE ABOVE LIMITATION MAY NOT APPLY TO YOU. YOU MAY ALSO HAVE OTHER LEGAL RIGHTS THAT VARY FROM JURISDICTION TO JURISDICTION.

TERMINATION OF THIS AGREEMENT. Intel may terminate this Agreement at any time if you violate its terms. Upon termination, you will immediately destroy the Software or return all copies of the Software to Intel.

APPLICABLE LAWS. Claims arising under this Agreement shall be governed by the laws of Delaware, excluding its principles of conflict of laws and the United Nations Convention on Contracts for the Sale of Goods. You may not export the Software in violation of applicable export laws and regulations. Intel is not obligated under any other agreements unless they are in writing and signed by an authorized representative of Intel.

Curacao Package

Software included in the Curacao package is proprietary Sigma Designs except:

Tinyxml library:

Custom license

/*

www.sourceforge.net/projects/tinyxml Original file by Yves Berquin.

This software is provided 'as-is', without any express or implied warranty. In no event will the authors be held liable for any damages arising from the use of this software.

Permission is granted to anyone to use this software for any purpose, including commercial applications, and to alter it and redistribute it freely, subject to the following restrictions:

1. The origin of this software must not be misrepresented; you must not claim that you wrote the original software. If you use this software in a product, an acknowledgment in the product documentation would be appreciated but is not required.
2. Altered source versions must be plainly marked as such, and must not be misrepresented as being the original software.
3. This notice may not be removed or altered from any source distribution.

*/

ARMUTILS Package

Software included with the ARM utilities package (as inferred from the list of Makefiles):

binutils:

binutils-2.11.2

GPL

<ftp://sources.redhat.com/pub/binutils/releases>

busybox:

busybox-1.00-pre3 and busybox-1.00

GPL

<http://www.busybox.net/downloads>

ccache:

ccache-2.3

GPL

<http://ccache.samba.org/ftp/ccache/>

cdrtools:

cdrtools-2.00.3

GPL

<http://www.fokus.gmd.de/research/cc/gclone/employees/joerg.schilling/private/cdrecord.html>

elf2flt:

elf2flt-20020214 and elf2flt-20030314

GPL

<http://www.uclinux.org/pub/uClinux/utilities/>

gcc:

gcc-2.95.3

GPL

<http://gcc.gnu.org>

ext2root:

genext2fs-1.3

GPL

<http://packages.debian.org/unstable/admin/genext2fs>

genromfs:

genromfs-0.5.1

GPL

<http://www.uclinux.org/pub/uClinux/utilities/>

linux:

linux-2.4.22

GPL

<http://www.kernel.org/pub/linux/kernel/v2.4>

uClinux-2.4.22-uc0

GPL

<http://www.uclinux.org/pub/uClinux/uClinux-2.4.x>

microwin:

microwindows-src-snapshot-013004

MPL (Mozilla Public License) -OR- GPL <ftp://ftp.microwindows.org/pub/microwindows>

madwifi:

madwifi-cvs20040331

Dual license:

a) Custom license - source redistribution OK - see
- OR -

b) GPL

<http://madwifi.org/pub/linux/snapshot/tars>

mtd:

mtd-20040901

GPL

<ftp://ftp.uk.linux.org/pub/people/dwmw2/mtd/cvs>

ncurses:

ncurses-5.2

GPL

<http://ftp.gnu.org/pub/gnu/ncurses>

openssl:

openssl-0.9.7d

Dual license:

a) OpenSSL license
- AND -

b) SSLeay license

The resulting license is a copyleft free software license (cf <http://www.gnu.org/licenses/license-list.html#OpenSSL>)

<http://www.openssl.org/source>

prism54:

prism54-cvs20040318

GPL

<http://prism54.org/pub/linux/snapshot/tars> Software issue at <http://www.prism54.org/software/>

STLport:

STLport-4.5.3

Custom license - source redistribution OK - see

<http://www.stlport.org/archive>

tinylogin:

tinylogin-1.4

GPL -AND- Shadow utilities license (BSD-style) -PLUS- derived work from code licensed under the Eindhoven University of Technology license

<http://tinylogin.busybox.net/downloads>

uclibc:

uClibc-0.9.21 and uClibc-0.9.26

LGPL

<http://www.uclibc.org/downloads>

udhcp:

udhcp-0.9.8

GPL

<http://udhcp.busybox.net/downloads/>

wtools:

wireless_tools.26

GPL

<http://pcmcia-cs.sourceforge.net/ftp/contrib/>

A copy of the GPL is always available at

<http://www.gnu.org/licenses/gpl.html>

A copy of the LGPL is always available at

<http://www.gnu.org/copyleft/lesser.html>

A copy of the MPL is always available at <http://www.mozilla.org/MPL/>

GNU GENERAL PUBLIC LICENSE

Version 2, June 1991

Copyright (C) 1989, 1991 Free Software Foundation, Inc.
59 Temple Place, Suite 330, Boston, MA 02111-1307 USA
Everyone is permitted to copy and distribute verbatim copies
of this license document, but changing it is not allowed.

Preamble

The licenses for most software are designed to take away your freedom to share and change it. By contrast, the GNU General Public License is intended to guarantee your freedom to share and change free software--to make sure the software is free for all its users. This General Public License applies to most of the Free Software Foundation's software and to any other program whose authors commit to using it. (Some other Free Software Foundation software is covered by the GNU Library General Public License instead.) You can apply it to your programs, too.

When we speak of free software, we are referring to freedom, not price. Our General Public Licenses are designed to make sure that you have the freedom to distribute copies of free software (and charge for this service if you wish), that you receive source code or can get it if you want it, that you can change the software or use pieces of it in new free programs; and that you know you can do these things.

To protect your rights, we need to make restrictions that forbid anyone to deny you these rights or to ask you to surrender the rights. These restrictions translate to certain responsibilities for you if you distribute copies of the software, or if you modify it.

For example, if you distribute copies of such a program, whether gratis or for a fee, you must give the recipients all the rights that you have. You must make sure that they, too, receive or can get the source code. And you must show them these terms so they know their rights.

We protect your rights with two steps: (1) copyright the software, and

(2) offer you this license which gives you legal permission to copy, distribute and/or modify the software.

Also, for each author's protection and ours, we want to make certain that everyone understands that there is no warranty for this free software. If the software is modified by someone else and passed on, we want its recipients to know that what they have is not the original, so that any problems introduced by others will not reflect on the original authors' reputations.

Finally, any free program is threatened constantly by software patents. We wish to avoid the danger that redistributors of a free program will individually obtain patent licenses, in effect making the program proprietary. To prevent this, we have made it clear that any patent must be licensed for everyone's free use or not licensed at all.

The precise terms and conditions for copying, distribution and modification follow.

GNU GENERAL PUBLIC LICENSE

TERMS AND CONDITIONS FOR COPYING, DISTRIBUTION AND MODIFICATION

0. This License applies to any program or other work which contains a notice placed by the copyright holder saying it may be distributed under the terms of this General Public License. The "Program", below, refers to any such program or work, and a "work based on the Program" means either the Program or any derivative work under copyright law: that is to say, a work containing the Program or a portion of it, either verbatim or with modifications and/or translated into another language. (Hereinafter, translation is included without limitation in the term "modification".) Each licensee is addressed as "you".

Activities other than copying, distribution and modification are not covered by this License; they are outside its scope. The act of running the Program is not restricted, and the output from the Program is covered only if its contents constitute a work based on the Program (independent of having been made by running the Program). Whether that is true depends on what the Program does.

1. You may copy and distribute verbatim copies of the Program's source code as you receive it, in any medium, provided that you conspicuously and appropriately publish on each copy an appropriate copyright notice and disclaimer of warranty; keep intact all the notices that refer to this License and to the absence of any warranty; and give any other recipients of the Program a copy of this License along with the Program.

You may charge a fee for the physical act of transferring a copy, and you may at your option offer warranty protection in exchange for a fee.

2. You may modify your copy or copies of the Program or any portion of it, thus forming a work based on the Program, and copy and distribute such modifications or work under the terms of Section 1 above, provided that you also meet all of these conditions:

- a) You must cause the modified files to carry prominent notices stating that you changed the files and the date of any change.
- b) You must cause any work that you distribute or publish, that in whole or in part contains or is derived from the Program or any part thereof, to be licensed as a whole at no charge to all third parties under the terms of this License.
- c) If the modified program normally reads commands interactively when run, you must cause it, when started running for such interactive use in the most ordinary way, to print or display an announcement including an appropriate copyright notice and a notice that there is no warranty (or else, saying that you provide a warranty) and that users may redistribute the program under

these conditions, and telling the user how to view a copy of this License. (Exception: if the Program itself is interactive but does not normally print such an announcement, your work based on the Program is not required to print an announcement.)

These requirements apply to the modified work as a whole. If identifiable sections of that work are not derived from the Program, and can be reasonably considered independent and separate works in themselves, then this License, and its terms, do not apply to those sections when you distribute them as separate works. But when you distribute the same sections as part of a whole which is a work based on the Program, the distribution of the whole must be on the terms of this License, whose permissions for other licensees extend to the entire whole, and thus to each and every part regardless of who wrote it.

Thus, it is not the intent of this section to claim rights or contest your rights to work written entirely by you; rather, the intent is to exercise the right to control the distribution of derivative or collective works based on the Program.

In addition, mere aggregation of another work not based on the Program with the Program (or with a work based on the Program) on a volume of a storage or distribution medium does not bring the other work under the scope of this License.

3. You may copy and distribute the Program (or a work based on it, under Section 2) in object code or executable form under the terms of Sections 1 and 2 above provided that you also do one of the following:

a) Accompany it with the complete corresponding machine-readable source code, which must be distributed under the terms of Sections 1 and 2 above on a medium customarily used for software interchange; or,

b) Accompany it with a written offer, valid for at least three years, to give any third party, for a charge no more than your cost of physically performing source distribution, a complete machine-readable copy of the corresponding source code, to be distributed under the terms of Sections 1 and 2 above on a medium customarily used for software interchange; or,

c) Accompany it with the information you received as to the offer to distribute corresponding source code. (This alternative is allowed only for noncommercial distribution and only if you received the program in object code or executable form with such an offer, in accord with Subsection b above.)

The source code for a work means the preferred form of the work for making modifications to it. For an executable work, complete source code means all the source code for all modules it contains, plus any associated interface definition files, plus the scripts used to control compilation and installation of the executable. However, as a special exception, the source code distributed need not include anything that is normally distributed (in either source or binary form) with the major components (compiler, kernel, and so on) of the operating system on which the executable runs, unless that component itself accompanies the executable.

If distribution of executable or object code is made by offering access to copy from a designated place, then offering equivalent access to copy the source code from the same place counts as distribution of the source code, even though third parties are not compelled to copy the source along with the object code.

4. You may not copy, modify, sublicense, or distribute the Program except as expressly provided under this License. Any attempt otherwise to copy, modify, sublicense or distribute the Program is void, and will automatically terminate your rights under this License. However, parties who have received copies, or rights, from you under this License will not have their licenses terminated so long as such parties remain in full compliance.

5. You are not required to accept this License, since you have not signed it. However, nothing else grants you permission to modify or distribute the Program or its derivative works. These actions are prohibited by law if you do not accept this License. Therefore, by modifying or distributing the Program (or any work based on the Program), you indicate your acceptance of this License to do so, and all its terms and conditions for copying, distributing or modifying the Program or works based on it.

6. Each time you redistribute the Program (or any work based on the Program), the recipient automatically receives a license from the original licensor to copy, distribute or modify the Program subject to these terms and conditions. You may not impose any further restrictions on the recipients' exercise of the rights granted herein. You are not responsible for enforcing compliance by third parties to this License.

7. If, as a consequence of a court judgment or allegation of patent infringement or for any other reason (not limited to patent issues), conditions are imposed on you (whether by court order, agreement or otherwise) that contradict the conditions of this License, they do not excuse you from the conditions of this License. If you cannot distribute so as to satisfy simultaneously your obligations under this License and any other pertinent obligations, then as a consequence you may not distribute the Program at all. For example, if a patent license would not permit royalty-free redistribution of the Program by all those who receive copies directly or indirectly through you, then the only way you could satisfy both it and this License would be to refrain entirely from distribution of the Program.

If any portion of this section is held invalid or unenforceable under any particular circumstance, the balance of the section is intended to apply and the section as a whole is intended to apply in other circumstances.

It is not the purpose of this section to induce you to infringe any patents or other property right claims or to contest validity of any such claims; this section has the sole purpose of protecting the integrity of the free software distribution system, which is implemented by public license practices. Many people have made generous contributions to the wide range of software distributed through that system in reliance on consistent application of that system; it is up to the author/donor to decide if he or she is willing to distribute software through any other system and a licensee cannot impose that choice.

This section is intended to make thoroughly clear what is believed to be a consequence of the rest of this License.

8. If the distribution and/or use of the Program is restricted in certain countries either by patents or by copyrighted interfaces, the original copyright holder who places the Program under this License may add an explicit geographical distribution limitation excluding those countries, so that distribution is permitted only in or among countries not thus excluded. In such case, this License incorporates the limitation as if written in the body of this License.

9. The Free Software Foundation may publish revised and/or new versions of the General Public License from time to time. Such new versions will be similar in spirit to the present version, but may differ in detail to address new problems or concerns.

Each version is given a distinguishing version number. If the Program specifies a version number of this License which applies to it and "any later version", you have the option of following the terms and conditions either of that version or of any later version published by the Free Software Foundation. If the Program does not specify a version number of this License, you may choose any version ever published by the Free Software Foundation.

10. If you wish to incorporate parts of the Program into other free programs whose distribution conditions are different, write to the author to ask for permission. For software which is copyrighted by the Free Software Foundation, write to the Free Software Foundation; we sometimes make exceptions for this. Our decision will be guided by the two goals of preserving the free status of all derivatives of our free software and of promoting the sharing and reuse of software generally.

NO WARRANTY

11. BECAUSE THE PROGRAM IS LICENSED FREE OF CHARGE, THERE IS NO WARRANTY FOR THE PROGRAM, TO THE EXTENT PERMITTED BY APPLICABLE LAW. EXCEPT WHEN OTHERWISE STATED IN WRITING THE COPYRIGHT HOLDERS AND/OR OTHER PARTIES PROVIDE THE PROGRAM "AS IS" WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESSED OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. THE ENTIRE RISK AS TO THE QUALITY AND PERFORMANCE OF THE PROGRAM IS WITH YOU. SHOULD THE PROGRAM PROVE DEFECTIVE, YOU ASSUME THE COST OF ALL NECESSARY SERVICING, REPAIR OR CORRECTION.

12. IN NO EVENT UNLESS REQUIRED BY APPLICABLE LAW OR AGREED TO IN WRITING WILL ANY COPYRIGHT HOLDER, OR ANY OTHER PARTY WHO MAY MODIFY AND/OR REDISTRIBUTE THE PROGRAM AS PERMITTED ABOVE, BE LIABLE TO YOU FOR DAMAGES, INCLUDING ANY GENERAL, SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES ARISING OUT OF THE USE OR INABILITY TO USE THE PROGRAM (INCLUDING BUT NOT LIMITED TO LOSS OF DATA OR DATA BEING RENDERED INACCURATE OR LOSSES SUSTAINED BY

YOU OR THIRD PARTIES OR A FAILURE OF THE PROGRAM TO OPERATE WITH ANY OTHER PROGRAMS), EVEN IF SUCH HOLDER OR OTHER PARTY HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

END OF TERMS AND CONDITIONS

How to Apply These Terms to Your New Programs

If you develop a new program, and you want it to be of the greatest possible use to the public, the best way to achieve this is to make it free software which everyone can redistribute and change under these terms.

To do so, attach the following notices to the program. It is safest to attach them to the start of each source file to most effectively convey the exclusion of warranty; and each file should have at least the "copyright" line and a pointer to where the full notice is found.

<one line to give the program's name and a brief idea of what it does.> Copyright (C) <year>
<name of author>

This program is free software; you can redistribute it and/or modify it under the terms of the GNU General Public License as published by the Free Software Foundation; either version 2 of the License, or (at your option) any later version.

This program is distributed in the hope that it will be useful, but WITHOUT ANY WARRANTY; without even the implied warranty of MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE. See the GNU General Public License for more details.

You should have received a copy of the GNU General Public License along with this program; if not, write to the Free Software Foundation, Inc., 59 Temple Place, Suite 330, Boston, MA 02111-1307 USA

Also add information on how to contact you by electronic and paper mail. If the program is interactive, make it output a short notice like this when it starts in an interactive mode:

Gnomovision version 69, Copyright (C) year name of author
Gnomovision comes with ABSOLUTELY NO WARRANTY; for details type `show w'. This is free software, and you are welcome to redistribute it under certain conditions; type `show c' for details.

The hypothetical commands `show w' and `show c' should show the appropriate parts of the General Public License. Of course, the commands you use may be called something other than `show w' and `show c'; they could even be mouse-clicks or menu items--whatever suits your program.

You should also get your employer (if you work as a programmer) or your school, if any, to sign a "copyright disclaimer" for the program, if necessary. Here is a sample; alter the names:

Yoyodyne, Inc., hereby disclaims all copyright interest in the program `Gnomovision' (which makes passes at compilers) written by James Hacker.

<signature of Ty Coon>, 1 April 1989

Ty Coon, President of Vice

This General Public License does not permit incorporating your program into proprietary programs. If your program is a subroutine library, you may consider it more useful to permit linking proprietary applications with the library. If this is what you want to do, use the GNU Library General Public License instead of this License.

GNU LESSER GENERAL PUBLIC LICENSE

Version 2.1, February 1999

Copyright (C) 1991, 1999 Free Software Foundation, Inc.

59 Temple Place, Suite 330, Boston, MA 02111-1307 USA

Everyone is permitted to copy and distribute verbatim copies of this license document, but changing it is not allowed.

[This is the first released version of the Lesser GPL. It also counts as the successor of the GNU Library Public License, version 2, hence the version number 2.1.]

Preamble

The licenses for most software are designed to take away your freedom to share and change it. By contrast, the GNU General Public Licenses are intended to guarantee your freedom to share and change free software--to make sure the software is free for all its users.

This license, the Lesser General Public License, applies to some specially designated software packages--typically libraries--of the Free Software Foundation and other authors who decide to use it. You can use it too, but we suggest you first think carefully about whether this license or the ordinary General Public License is the better strategy to use in any particular case, based on the explanations below.

When we speak of free software, we are referring to freedom of use, not price. Our General Public Licenses are designed to make sure that you have the freedom to distribute copies of free software (and charge for this service if you wish); that you receive source code or can get it if you want it; that you can change the software and use pieces of it in new free programs; and that you are informed that you can do these things.

To protect your rights, we need to make restrictions that forbid distributors to deny you these rights or to ask you to surrender these rights. These restrictions translate to certain responsibilities for you if you distribute copies of the library or if you modify it.

For example, if you distribute copies of the library, whether gratis or for a fee, you must give the recipients all the rights that we gave you. You must make sure that they, too, receive or can get the source code. If you link other code with the library, you must provide complete object files to the recipients, so that they can relink them with the library after making changes to the library and recompiling it. And you must show them these terms so they know their rights.

We protect your rights with a two-step method: (1) we copyright the library, and (2) we offer you this license, which gives you legal permission to copy, distribute and/or modify the library.

To protect each distributor, we want to make it very clear that there is no warranty for the free library. Also, if the library is modified by someone else and passed on, the recipients should know that what they have is not the original version, so that the original author's reputation will not be affected by problems that might be introduced by others.

Finally, software patents pose a constant threat to the existence of any free program. We wish to make sure that a company cannot effectively restrict the users of a free program by obtaining a restrictive license from a patent holder. Therefore, we insist that any patent license obtained for a version of the library must be consistent with the full freedom of use specified in this license.

Most GNU software, including some libraries, is covered by the ordinary GNU General Public License. This license, the GNU Lesser General Public License, applies to certain designated libraries, and is quite different from the ordinary General Public License. We use this license for certain libraries in order to permit linking those

libraries into non-free programs.

When a program is linked with a library, whether statically or using a shared library, the combination of the two is legally speaking a combined work, a derivative of the original library. The ordinary General Public License therefore permits such linking only if the entire combination fits its criteria of freedom. The Lesser General Public License permits more lax criteria for linking other code with the library.

We call this license the "Lesser" General Public License because it does Less to protect the user's freedom than the ordinary General Public License. It also provides other free software developers Less of an advantage over competing non-free programs. These disadvantages are the reason we use the ordinary General Public License for many libraries. However, the Lesser license provides advantages in certain special circumstances.

For example, on rare occasions, there may be a special need to encourage the widest possible use of a certain library, so that it becomes a de-facto standard. To achieve this, non-free programs must be allowed to use the library. A more frequent case is that a free library does the same job as widely used non-free libraries. In this case, there is little to gain by limiting the free library to free software only, so we use the Lesser General Public License.

In other cases, permission to use a particular library in non-free programs enables a greater number of people to use a large body of free software. For example, permission to use the GNU C Library in non-free programs enables many more people to use the whole GNU operating system, as well as its variant, the GNU/Linux operating system.

Although the Lesser General Public License is Less protective of the users' freedom, it does ensure that the user of a program that is linked with the Library has the freedom and the wherewithal to run that program using a modified version of the Library.

The precise terms and conditions for copying, distribution and modification follow. Pay close attention to the difference between a "work based on the library" and a "work that uses the library". The former contains code derived from the library, whereas the latter must be combined with the library in order to run.

GNU LESSER GENERAL PUBLIC LICENSE

TERMS AND CONDITIONS FOR COPYING, DISTRIBUTION AND MODIFICATION

0. This License Agreement applies to any software library or other program which contains a notice placed by the copyright holder or other authorized party saying it may be distributed under the terms of this Lesser General Public License (also called "this License"). Each licensee is addressed as "you".

A "library" means a collection of software functions and/or data prepared so as to be conveniently linked with application programs (which use some of those functions and data) to form executables.

The "Library", below, refers to any such software library or work which has been distributed under these terms. A "work based on the Library" means either the Library or any derivative work under

copyright law: that is to say, a work containing the Library or a portion of it, either verbatim or with modifications and/or translated straightforwardly into another language. (Hereinafter, translation is included without limitation in the term "modification".)

"Source code" for a work means the preferred form of the work for making modifications to it. For a library, complete source code means all the source code for all modules it contains, plus any associated interface definition files, plus the scripts used to control compilation and installation of the library.

Activities other than copying, distribution and modification are not covered by this License; they are outside its scope. The act of running a program using the Library is not restricted, and output from such a program is covered only if its contents constitute a work based on the Library (independent of the use of the Library in a tool for writing it). Whether that is true depends on what the Library does and what the program that uses the Library does.

1. You may copy and distribute verbatim copies of the Library's complete source code as you receive it, in any medium, provided that you conspicuously and appropriately publish on each copy an appropriate copyright notice and disclaimer of warranty; keep intact all the notices that refer to this License and to the absence of any warranty; and distribute a copy of this License along with the Library.

You may charge a fee for the physical act of transferring a copy, and you may at your option offer warranty protection in exchange for a fee.

2. You may modify your copy or copies of the Library or any portion of it, thus forming a work based on the Library, and copy and distribute such modifications or work under the terms of Section 1 above, provided that you also meet all of these conditions:

a) The modified work must itself be a software library. b) You must cause the files modified to carry prominent notices stating that you changed the files and the date of any change.

c) You must cause the whole of the work to be licensed at no charge to all third parties under the terms of this License.

d) If a facility in the modified Library refers to a function or a table of data to be supplied by an application program that uses the facility, other than as an argument passed when the facility is invoked, then you must make a good faith effort to ensure that, in the event an application does not supply such function or table, the facility still operates, and performs whatever part of its purpose remains meaningful.

(For example, a function in a library to compute square roots has a purpose that is entirely well-defined independent of the application. Therefore, Subsection 2d requires that any application-supplied function or table used by this function must be optional: if the application does not supply it, the square root function must still compute square roots.)

These requirements apply to the modified work as a whole. If identifiable sections of that work are not derived from the Library, and can be reasonably considered independent and separate works in themselves, then this License, and its terms, do not apply to those sections when you distribute them as separate works. But when you distribute the same sections as part of a whole which is a work based on the Library, the distribution of the whole must be on the terms of this License, whose permissions for other licensees extend to the entire whole, and thus to each and every part regardless of who wrote it.

Thus, it is not the intent of this section to claim rights or contest your rights to work written entirely by you; rather, the intent is to exercise the right to control the distribution of derivative or collective works based on the Library.

In addition, mere aggregation of another work not based on the Library with the Library (or with a work based on the Library) on a volume of a storage or distribution medium does not bring the other work under the scope of this License.

3. You may opt to apply the terms of the ordinary GNU General Public License instead of this License to a given copy of the Library. To do this, you must alter all the notices that refer to this License, so that they refer to the ordinary GNU General Public License, version 2, instead of to this License. (If a newer version than version 2 of the ordinary GNU General Public License has appeared, then you can specify that version instead if you wish.) Do not make any other change in these notices.

Once this change is made in a given copy, it is irreversible for that copy, so the ordinary GNU General Public License applies to all subsequent copies and derivative works made from that copy.

This option is useful when you wish to copy part of the code of the Library into a program that is not a library.

4. You may copy and distribute the Library (or a portion or derivative of it, under Section 2) in object code or executable form under the terms of Sections 1 and 2 above provided that you accompany it with the complete corresponding machine-readable source code, which must be distributed under the terms of Sections 1 and 2 above on a medium customarily used for software interchange.

If distribution of object code is made by offering access to copy from a designated place, then offering equivalent access to copy the source code from the same place satisfies the requirement to distribute the source code, even though third parties are not compelled to copy the source along with the object code.

5. A program that contains no derivative of any portion of the Library, but is designed to work with the Library by being compiled or linked with it, is called a "work that uses the Library". Such a work, in isolation, is not a derivative work of the Library, and therefore falls outside the scope of this License.

However, linking a "work that uses the Library" with the Library creates an executable that is a derivative of the Library (because it contains portions of the Library), rather than a "work that uses the library". The executable is therefore covered by this License. Section 6 states terms for distribution of such executables.

When a "work that uses the Library" uses material from a header file that is part of the Library, the object code for the work may be a derivative work of the Library even though the source code is not. Whether this is true is especially significant if the work can be linked without the Library, or if the work is itself a library. The threshold for this to be true is not precisely defined by law.

If such an object file uses only numerical parameters, data structure layouts and accessors, and small macros and small inline functions (ten lines or less in length), then the use of the object file is unrestricted, regardless of whether it is legally a derivative work. (Executables containing this object code plus portions of the Library will still fall under Section 6.)

Otherwise, if the work is a derivative of the Library, you may distribute the object code for the work under the terms of Section 6. Any executables containing that work also fall under Section 6, whether or not they are linked directly with the Library itself.

6. As an exception to the Sections above, you may also combine or link a "work that uses the Library" with the Library to produce a work containing portions of the Library, and distribute that work under terms of your choice, provided that the terms permit modification of the work for the customer's own use and reverse engineering for debugging such modifications.

You must give prominent notice with each copy of the work that the Library is used in it and that the Library and its use are covered by this License. You must supply a copy of this License. If the work during execution displays copyright notices, you must include the copyright notice for the Library among them, as well as a reference directing the user to the copy of this License. Also, you must do one of these things:

a) Accompany the work with the complete corresponding

machine-readable source code for the Library including whatever changes were used in the work (which must be distributed under Sections 1 and 2 above); and, if the work is an executable linked with the Library, with the complete machine-readable "work that

uses the Library", as object code and/or source code, so that the user can modify the Library and then relink to produce a modified executable containing the modified Library. (It is understood

that the user who changes the contents of definitions files in the Library will not necessarily be able to recompile the application to use the modified definitions.)

b) Use a suitable shared library mechanism for linking with the Library. A suitable mechanism is one that (1) uses at run time a copy of the library already present on the user's computer system, rather than copying library functions into the executable, and (2) will operate properly with a modified version of the library, if the user installs one, as long as the modified version is

interface-compatible with the version that the work was made with.

c) Accompany the work with a written offer, valid for at least three years, to give the same user the materials specified in Subsection 6a, above, for a charge no more than the cost of performing this distribution.

d) If distribution of the work is made by offering access to copy from a designated place, offer equivalent access to copy the above specified materials from the same place.

e) Verify that the user has already received a copy of these materials or that you have already sent this user a copy.

For an executable, the required form of the "work that uses the Library" must include any data and utility programs needed for reproducing the executable from it. However, as a special exception, the materials to be distributed need not include anything that is normally distributed (in either source or binary form) with the major components (compiler, kernel, and so on) of the operating system on which the executable runs, unless that component itself accompanies the executable.

It may happen that this requirement contradicts the license restrictions of other proprietary libraries that do not normally accompany the operating system. Such a contradiction means you cannot use both them and the Library together in an executable that you distribute.

7. You may place library facilities that are a work based on the Library side-by-side in a single library together with other library facilities not covered by this License, and distribute such a combined library, provided that the separate distribution of the work based on the Library and of the other library facilities is otherwise permitted, and provided that you do these two things:

a) Accompany the combined library with a copy of the same work based on the Library, uncombined with any other library facilities. This must be distributed under the terms of the Sections above.

b) Give prominent notice with the combined library of the fact that part of it is a work based on the Library, and explaining where to find the accompanying uncombined form of the same work.

8. You may not copy, modify, sublicense, link with, or distribute the Library except as expressly provided under this License. Any attempt otherwise to copy, modify, sublicense, link with, or distribute the Library is void, and will automatically terminate your rights under this License. However, parties who have received copies, or rights, from you under this License will not have their licenses terminated so long as such parties remain in full compliance.

9. You are not required to accept this License, since you have not signed it. However, nothing else grants you permission to modify or

distribute the Library or its derivative works. These actions are prohibited by law if you do not accept this License. Therefore, by modifying or distributing the Library (or any work based on the Library), you indicate your acceptance of this License to do so, and all its terms and conditions for copying, distributing or modifying the Library or works based on it.

10. Each time you redistribute the Library (or any work based on the Library), the recipient automatically receives a license from the original licensor to copy, distribute, link with or modify the Library subject to these terms and conditions. You may not impose any further restrictions on the recipients' exercise of the rights granted herein. You are not responsible for enforcing compliance by third parties with this License.

11. If, as a consequence of a court judgment or allegation of patent infringement or for any other reason (not limited to patent issues), conditions are imposed on you (whether by court order, agreement or otherwise) that contradict the conditions of this License, they do not excuse you from the conditions of this License. If you cannot distribute so as to satisfy simultaneously your obligations under this License and any other pertinent obligations, then as a consequence you may not distribute the Library at all. For example, if a patent license would not permit royalty-free redistribution of the Library by all those who receive copies directly or indirectly through you, then the only way you could satisfy both it and this License would be to refrain entirely from distribution of the Library.

If any portion of this section is held invalid or unenforceable under any particular circumstance, the balance of the section is intended to apply, and the section as a whole is intended to apply in other circumstances.

It is not the purpose of this section to induce you to infringe any patents or other property right claims or to contest validity of any such claims; this section has the sole purpose of protecting the integrity of the free software distribution system which is implemented by public license practices. Many people have made generous contributions to the wide range of software distributed through that system in reliance on consistent application of that system; it is up to the author/donor to decide if he or she is willing to distribute software through any other system and a licensee cannot impose that choice.

This section is intended to make thoroughly clear what is believed to be a consequence of the rest of this License.

12. If the distribution and/or use of the Library is restricted in certain countries either by patents or by copyrighted interfaces, the original copyright holder who places the Library under this License may add an explicit geographical distribution limitation excluding those countries, so that distribution is permitted only in or among countries not thus excluded. In such case, this License incorporates the limitation as if written in the body of this License.

13. The Free Software Foundation may publish revised and/or new versions of the Lesser General Public License from time to time. Such new versions will be similar in spirit to the present version, but may differ in detail to address new problems or concerns.

Each version is given a distinguishing version number. If the Library specifies a version number of this License which applies to it and "any later version", you have the option of following the terms and conditions either of that version or of any later version published by the Free Software Foundation. If the Library does not specify a license version number, you may choose any version ever published by the Free Software Foundation.

14. If you wish to incorporate parts of the Library into other free programs whose distribution conditions are incompatible with these, write to the author to ask for permission. For software which is copyrighted by the Free Software Foundation, write to the Free Software Foundation; we sometimes make exceptions for this. Our decision will be guided by the two goals of preserving the free status of all derivatives of our free software and of promoting the sharing and reuse of software generally.

NO WARRANTY

15. BECAUSE THE LIBRARY IS LICENSED FREE OF CHARGE, THERE IS NO WARRANTY FOR THE LIBRARY, TO THE EXTENT PERMITTED BY APPLICABLE LAW. EXCEPT WHEN OTHERWISE STATED IN WRITING THE COPYRIGHT HOLDERS AND/OR OTHER PARTIES PROVIDE THE LIBRARY "AS IS" WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESSED OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. THE ENTIRE RISK AS TO THE QUALITY AND PERFORMANCE OF THE LIBRARY IS WITH YOU. SHOULD THE LIBRARY PROVE DEFECTIVE, YOU ASSUME THE COST OF ALL NECESSARY SERVICING, REPAIR OR CORRECTION.

16. IN NO EVENT UNLESS REQUIRED BY APPLICABLE LAW OR AGREED TO IN WRITING WILL ANY COPYRIGHT HOLDER, OR ANY OTHER PARTY WHO MAY MODIFY AND/OR REDISTRIBUTE THE LIBRARY AS PERMITTED ABOVE, BE LIABLE TO YOU FOR DAMAGES, INCLUDING ANY GENERAL, SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES ARISING OUT OF THE USE OR INABILITY TO USE THE LIBRARY (INCLUDING BUT NOT LIMITED TO LOSS OF DATA OR DATA BEING RENDERED INACCURATE OR LOSSES SUSTAINED BY YOU OR THIRD PARTIES OR A FAILURE OF THE LIBRARY TO OPERATE WITH ANY OTHER SOFTWARE), EVEN IF SUCH HOLDER OR OTHER PARTY HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

END OF TERMS AND CONDITIONS

How to Apply These Terms to Your New Libraries

If you develop a new library, and you want it to be of the greatest possible use to the public, we recommend making it free software that everyone can redistribute and change. You can do so by permitting redistribution under these terms (or, alternatively, under the terms of the ordinary General Public License).

To apply these terms, attach the following notices to the library. It is safest to attach them to the start of each source file to most effectively convey the exclusion of warranty; and each file should have at least the "copyright" line and a pointer to where the full notice is found.

<one line to give the library's name and a brief idea of what it does.> Copyright (C) <year>
<name of author>

This library is free software; you can redistribute it and/or modify it under the terms of the GNU Lesser General Public License as published by the Free Software Foundation; either version 2.1 of the License, or (at your option) any later version.

This library is distributed in the hope that it will be useful, but WITHOUT ANY WARRANTY; without even the implied warranty of MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE. See the GNU Lesser General Public License for more details.

You should have received a copy of the GNU Lesser General Public License along with this library; if not, write to the Free Software Foundation, Inc., 59 Temple Place, Suite 330, Boston, MA 02111-1307 USA

Also add information on how to contact you by electronic and paper mail. You should also get your employer (if you work as a programmer) or your school, if any, to sign a "copyright disclaimer" for the library, if necessary. Here is a sample; alter the names:

Yoyodyne, Inc., hereby disclaims all copyright interest in the library `Frob' (a library for tweaking knobs) written by James Random Hacker.

<signature of Ty Coon>, 1 April 1990

Ty Coon, President of Vice

That's all there is to it!

STLPort License

* README file for STLport 4.5 *

* *

*

This directory contains STLport-4.5 release. What's inside :

README - this file

INSTALL - installation instructions

stlport - main STLport include directory

src - source and makefiles for iostreams implementation

lib - installation directory for STLport library (if you use STLport iostreams only)

test/regression - regression test, using wrapper iostreams

test/eh - exception handling test using STLport iostreams

etc - miscellaneous files (ChangeLog, TODO, scripts, etc.)

GETTING STLPORT

To download the latest version of STLport, please be sure to visit <http://www.stlport.com/download.html>

LEGALESE

This software is being distributed under the following terms :

*

*

* Copyright (c) 1994

* Hewlett-Packard Company

*

* Copyright (c) 1996-1999

* Silicon Graphics Computer Systems, Inc.

*

* Copyright (c) 1997

* Moscow Center for SPARC Technology

*

* Copyright (c) 1999, 2000, 2001

* Boris Fomitchev

*

* This material is provided "as is", with absolutely no warranty expressed * or implied. Any use is at your own risk.

*

* Permission to use or copy this software for any purpose is hereby granted

* without fee, provided the above notices are retained on all copies.

* Permission to modify the code and to distribute modified code is granted,

* provided the above notices are retained, and a notice that the code was

* modified is included with the above copyright notice.

*

Madwifi License

All files contained in this distribution are covered by the following copyright unless explicitly identified otherwise.

/*_

* Copyright (c) 2002-2004 Sam Leffler, Errno Consulting * All rights reserved.

*

* Redistribution and use in source and binary forms, with or without * modification, are permitted provided that the following conditions * are met:

* 1. Redistributions of source code must retain the above copyright

* notice, this list of conditions and the following disclaimer,
 * without modification.

* 2. Redistributions in binary form must reproduce at minimum a disclaimer
 * similar to the "NO WARRANTY" disclaimer below ("Disclaimer") and any
 * redistribution must be conditioned upon including a substantially
 * similar Disclaimer requirement for further binary redistribution.

* 3. Neither the names of the above-listed copyright holders nor the names
 * of any contributors may be used to endorse or promote products derived
 * from this software without specific prior written permission.

*

* Alternatively, this software may be distributed under the terms of the * GNU General Public
 License ("GPL") version 2 as published by the Free * Software Foundation.

*

* NO WARRANTY

* THIS SOFTWARE IS PROVIDED BY THE COPYRIGHT HOLDERS AND
 CONTRIBUTORS

* ``AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT
 * LIMITED TO, THE IMPLIED WARRANTIES OF NONINFRINGEMENT,
 MERCHANTABILITY

* AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT
 SHALL

* THE COPYRIGHT HOLDERS OR CONTRIBUTORS BE LIABLE FOR SPECIAL,
 EXEMPLARY,

* OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO,
 PROCUREMENT OF

* SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR
 BUSINESS * INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF
 LIABILITY, WHETHER

* IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR
 OTHERWISE) * ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE,
 EVEN IF ADVISED OF

* THE POSSIBILITY OF SUCH DAMAGES.

*

* \$Id: COPYRIGHT,v 1.4 2004/01/13 18:05:41 samleffler Exp \$

*/

Microwindows License

The Microwindows, Nano-X, and BOGL software are licensed under the MPL, as specified below. Alternatively, the software can be converted to the GNU General Public License, Version 2.

/*

* The contents of this file are subject to the Mozilla Public License * Version 1.1 (the "License"); you may not use this file except in * compliance with the License. You may obtain a copy of the License at * <http://www.mozilla.org/MPL/>

*

* Software distributed under the License is distributed on an "AS IS" * basis, WITHOUT WARRANTY OF ANY KIND, either express or implied. See the * License for the specific language governing rights and limitations * under the License.

*

* The Original Code is Microwindows.

*

* The Initial Developer of the Original Code is Greg Haerr.

* Portions created by Greg Haerr are Copyright (C) 1999, 2000, 2001, 2002, 2003 * Greg Haerr <greg@censoft.com>. All Rights Reserved.

*

* Contributor(s):

*

* Alternatively, the contents of this file may be used under the terms * of the GNU General Public license (the "[GNU] License"), in which case the * provisions of [GNU] License are applicable instead of those * above. If you wish to allow use of your version of this file only * under the terms of the [GNU] License and not to allow others to use * your version of this file under the MPL, indicate your decision by * deleting the provisions above and replace them with the notice and * other provisions required by the [GNU] License. If you do not delete * the provisions above, a recipient may use your version of this file * under either the MPL or the [GNU] License.

*/

/*

* Portions contributed by Koninklijke Philips Electronics N.V.
* These portions are Copyright 2002 Koninklijke Philips Electronics
* N.V. All Rights Reserved. These portions are licensed under the
* terms of the Mozilla Public License, version 1.1, or, at your
* option, the GNU General Public License version 2.0. Please see
* the file "ChangeLog" for documentation regarding these
* contributions.

*/

OpenSSL License

Copyright (c) 1998-2000 The OpenSSL Project. All rights reserved. Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

1. Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
2. Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.
3. All advertising materials mentioning features or use of this software must display the following acknowledgment: This product includes software developed by the OpenSSL Project for use in the OpenSSL Toolkit.
(<http://www.openssl.org>)
4. The names "OpenSSL Toolkit" and "OpenSSL Project" must not be used to endorse or promote products derived from this software without prior written permission. For written permission, please contact opensslcore@openssl.org
5. Products derived from this software may not be called "OpenSSL" nor may "OpenSSL" appear in their names without prior written permission of the OpenSSL Project.
6. Redistributions of any form whatsoever must retain the following acknowledgment: "This product includes software developed by the OpenSSL Project for use in the OpenSSL Toolkit (<http://www.openssl.org>)"

THIS SOFTWARE IS PROVIDED BY THE OpenSSL PROJECT ``AS IS" AND ANY EXPRESSED OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE OpenSSL PROJECT OR ITS CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE. This product includes cryptographic software written by Eric Young (ey@cryptsoft.com). This product includes software written by Tim Hudson (tjh@cryptsoft.com).

SSLeay license

Copyright (C) 1995-1998 Eric Young (eay@cryptsoft.com) All rights reserved. This package is an SSL implementation written by Eric Young (eay@cryptsoft.com). The implementation was written so as to conform with Netscape's SSL. This library is free for commercial and non-commercial use as long as the following conditions are adhered to. The following conditions apply to all code found in this distribution, be it the RC4, RSA, lhash, DES, etc., code; not just the SSL code. The SSL documentation included with this distribution is covered by the same copyright terms except that the holder is Tim Hudson (tjh@cryptsoft.com).

Copyright remains Eric Young's, and as such any Copyright notices in the code are not to be removed. If this package is used in a product, Eric Young should be given attribution as the author of the parts of the library used. This can be in the form of a textual message at program startup or in documentation (online or textual) provided with the package. Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

1. Redistributions of source code must retain the copyright notice, this list of conditions and the following disclaimer.
2. Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.
3. All advertising materials mentioning features or use of this software must display the following acknowledgement: "This product includes cryptographic software written by Eric Young (eay@cryptsoft.com)". The word 'cryptographic' can be left out if the routines from the library being used are not cryptographic related :-).
4. If you include any Windows specific code (or a derivative thereof) from the apps directory (application code) you must include an acknowledgement: "This product includes software written by Tim Hudson (tjh@cryptsoft.com)"

THIS SOFTWARE IS PROVIDED BY ERIC YOUNG ``AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE AUTHOR OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE

POSSIBILITY

OF SUCH DAMAGE. The licence and distribution terms for any publically available version or derivative of this code cannot be changed. i.e. this code cannot simply be copied and put under another distribution licence [including the GNU Public Licence.

Sash License

```
/*
 * Copyright (c) 2004 by David I. Bell
 * Permission is granted to use, distribute, or modify this source,
 * provided that this copyright notice remains intact.
 *
 */
```

The shadow utilities license

This software is copyright 1988 - 1994, Julianne Frances Haugh. All rights reserved.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

1. Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
2. Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.
3. Neither the name of Julianne F. Haugh nor the names of its contributors may be used to endorse or promote products derived from this software without specific prior written permission.

THIS SOFTWARE IS PROVIDED BY JULIE HAUGH AND CONTRIBUTORS ``AS IS"
AND

ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO,
THE

IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A
PARTICULAR PURPOSE

ARE DISCLAIMED. IN NO EVENT SHALL JULIE HAUGH OR CONTRIBUTORS BE
LIABLE

FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR
CONSEQUENTIAL

DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE
GOODS

OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION)

HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN
CONTRACT, STRICT

LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

This source code is currently archived on ftp.uu.net in the comp.sources.misc portion of the USENET archives. You may also contact the author, Julianne F. Haugh, at <jockgrrl@austin.rr.com> if you have any questions regarding this package.

THIS SOFTWARE IS BEING DISTRIBUTED AS-IS. THE AUTHORS DISCLAIM ALL LIABILITY FOR ANY CONSEQUENCES OF USE. THE USER IS SOLELY RESPONSIBLE FOR THE MAINTENANCE OF THIS SOFTWARE PACKAGE. THE AUTHORS ARE UNDER NO OBLIGATION TO PROVIDE MODIFICATIONS OR IMPROVEMENTS. THE USER IS ENCOURAGED TO TAKE ANY AND ALL STEPS NEEDED TO PROTECT AGAINST ACCIDENTAL LOSS OF INFORMATION OR MACHINE RESOURCES.

Special thanks are due to Chip Rosenthal for his fine testing efforts; to Steve Simmons for his work in porting this code to BSD; and to Bill Kennedy for his contributions of LaserJet printer time and energies.

Also, thanks for Dennis L. Mumaugh for the initial shadow password information and to Tony Walton (olapw@olgb1.oliv.co.uk) for the System V Release 4 changes. Effort in porting to SunOS has been contributed by Dr. Michael Newberry (miken@cs.adfa.oz.au) and Micheal J. Miller, Jr. (mke@kaber.d.rain.com). Effort in porting to AT&T UNIX System V Release 4 has been provided by Andrew Herbert (andrew@werple.pub.uu.oz.au). Special thanks to Marek Michalkiewicz (marekm@i17linuxb.ists.pwr.wroc.pl) for taking over the Linux port of this software.

/***

* Copyright 1995 by Wietse Venema. All rights reserved. Individual files
* may be covered by other copyrights (as noted in the file itself.)
*

* This material was originally written and compiled by Wietse Venema at * Eindhoven
University of Technology, The Netherlands, in 1990, 1991, * 1992, 1993, 1994 and 1995.
*

* Redistribution and use in source and binary forms are permitted
* provided that this entire copyright notice is duplicated in all such * copies.
*

* This software is provided "as is" and without any expressed or implied * warranties,
including, without limitation, the implied warranties of * merchantability and fitness for any
particular purpose.

***/

This software is copyright 1988 - 1994, Julianne Frances Haugh. All rights reserved.

NOTE: Some components of the DMA-1100P incorporate source code covered under GPL or GPL like licenses. To obtain the source code covered under those Licenses, please contact ZyXEL Communications Corporation at: ZyXEL Technical Support.

End-User License Agreement for “DMA-1100P”

WARNING: ZyXEL Communications Corp. IS WILLING TO LICENSE THE ENCLOSED SOFTWARE TO YOU ONLY UPON THE CONDITION THAT YOU ACCEPT ALL OF THE TERMS CONTAINED IN THIS LICENSE AGREEMENT. PLEASE READ THE TERMS CAREFULLY BEFORE COMPLETING THE INSTALLATION PROCESS AS INSTALLING THE SOFTWARE WILL INDICATE YOUR ASSENT TO THEM. IF YOU DO NOT AGREE TO THESE TERMS, THEN ZyXEL, INC. IS UNWILLING TO LICENSE THE SOFTWARE TO YOU, IN WHICH EVENT YOU SHOULD RETURN THE UNINSTALLED SOFTWARE AND PACKAGING TO THE PLACE FROM WHICH IT WAS ACQUIRED, AND YOUR MONEY WILL BE REFUNDED.

1. Grant of License for Personal Use

ZyXEL Communications Corp. ("ZyXEL") grants you a non-exclusive, non-sublicense, non-transferable license to use the program with which this license is distributed (the "Software"), including any documentation files accompanying the Software ("Documentation"), for internal business use only, for up to the number of users specified in sales order and invoice. You have the right to make one backup copy of the Software and Documentation solely for archival, back-up or disaster recovery purposes. You shall not exceed the scope of the license granted hereunder. Any rights not expressly granted by ZyXEL to you are reserved by ZyXEL, and all implied licenses are disclaimed.

2. Ownership

You have no ownership rights in the Software. Rather, you have a license to use the Software as long as this License Agreement remains in full force and effect. Ownership of the Software, Documentation and all intellectual property rights therein shall remain at all times with ZyXEL. Any other use of the Software by any other entity is strictly forbidden and is a violation of this License Agreement.

3. Copyright

The Software and Documentation contain material that is protected by United States Copyright Law and trade secret law, and by international treaty provisions. All rights not granted to you herein are expressly reserved by ZyXEL. You may not remove any proprietary notice of ZyXEL or any of its licensors from any copy of the Software or Documentation.

4. Restrictions

You may not publish, display, disclose, sell, rent, lease, modify, store, loan, distribute, or create derivative works of the Software, or any part thereof. You may not assign, sublicense, convey or otherwise transfer, pledge as security or otherwise encumber the rights and licenses granted hereunder with respect to the Software. You may not copy, reverse engineer, decompile, reverse compile, translate, adapt, or disassemble the Software, or any part thereof, nor shall you attempt to create the source code from the object code for the Software. You may not market, co-brand, private label or otherwise permit third parties to link to the Software, or any part thereof. You may not use the Software, or any part thereof, in the operation of a service bureau or for the benefit of any other person or entity. You may not cause, assist or permit any third party to do any of the foregoing.

5. Confidentiality

You acknowledge that the Software contains proprietary trade secrets of ZyXEL and you hereby agree to maintain the confidentiality of the Software using at least as great a degree of care as you use to maintain the confidentiality of your own most confidential information. You agree to reasonably communicate the terms and conditions of this License Agreement to those persons employed by you who come into contact with the Software, and to use reasonable best efforts to ensure their compliance with such terms and conditions, including, without limitation, not knowingly permitting such persons to use any portion of the Software for the purpose of deriving the source code of the Software.

6. No Warranty

THE SOFTWARE IS PROVIDED "AS IS." TO THE MAXIMUM EXTENT PERMITTED BY LAW, ZyXEL DISCLAIMS ALL WARRANTIES OF ANY KIND, EITHER EXPRESSED OR IMPLIED, INCLUDING, WITHOUT LIMITATION, IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. ZyXEL DOES NOT WARRANT THAT THE FUNCTIONS CONTAINED IN THE SOFTWARE WILL MEET ANY REQUIREMENTS OR NEEDS YOU MAY HAVE, OR THAT THE SOFTWARE WILL OPERATE ERROR FREE, OR IN AN UNINTERRUPTED FASHION, OR THAT ANY DEFECTS OR ERRORS IN THE SOFTWARE WILL BE CORRECTED, OR THAT THE SOFTWARE IS COMPATIBLE WITH ANY PARTICULAR PLATFORM. SOME JURISDICTIONS DO NOT ALLOW THE WAIVER OR EXCLUSION OF IMPLIED WARRANTIES SO THEY MAY NOT APPLY TO YOU. IF THIS EXCLUSION IS HELD TO BE UNENFORCEABLE BY A COURT OF COMPETENT JURISDICTION, THEN ALL EXPRESS AND IMPLIED WARRANTIES SHALL BE LIMITED IN DURATION TO A PERIOD OF THIRTY (30) DAYS FROM THE DATE OF PURCHASE OF THE SOFTWARE, AND NO WARRANTIES SHALL APPLY AFTER THAT PERIOD.

7. Limitation of Liability

IN NO EVENT WILL ZyXEL BE LIABLE TO YOU OR ANY THIRD PARTY FOR ANY INCIDENTAL OR CONSEQUENTIAL DAMAGES (INCLUDING, WITHOUT LIMITATION, INDIRECT, SPECIAL, PUNITIVE, OR EXEMPLARY DAMAGES FOR LOSS OF BUSINESS, LOSS OF PROFITS, BUSINESS INTERRUPTION, OR LOSS OF BUSINESS INFORMATION) ARISING OUT OF THE USE OF OR INABILITY TO USE THE PROGRAM, OR FOR ANY CLAIM BY ANY OTHER PARTY, EVEN IF ZyXEL

HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES. ZyXEL'S AGGREGATE LIABILITY WITH RESPECT TO ITS OBLIGATIONS UNDER THIS AGREEMENT OR OTHERWISE WITH RESPECT TO THE SOFTWARE AND DOCUMENTATION OR OTHERWISE SHALL BE EQUAL TO THE PURCHASE PRICE, BUT SHALL IN NO EVENT EXCEED \$1,000. BECAUSE SOME STATES/COUNTRIES DO NOT ALLOW THE EXCLUSION OR LIMITATION OF LIABILITY FOR CONSEQUENTIAL OR INCIDENTAL DAMAGES, THE ABOVE LIMITATION MAY NOT APPLY TO YOU.

8.Export Restrictions

THIS LICENSE AGREEMENT IS EXPRESSLY MADE SUBJECT TO ANY APPLICABLE LAWS, REGULATIONS, ORDERS, OR OTHER RESTRICTIONS ON THE EXPORT OF THE SOFTWARE OR INFORMATION ABOUT SUCH SOFTWARE WHICH MAY BE IMPOSED FROM TIME TO TIME. YOU SHALL NOT EXPORT THE SOFTWARE, DOCUMENTATION OR INFORMATION ABOUT THE SOFTWARE AND DOCUMENTATION WITHOUT COMPLYING WITH SUCH LAWS, REGULATIONS, ORDERS, OR OTHER RESTRICTIONS. YOU AGREE TO INDEMNIFY ZyXEL AGAINST ALL CLAIMS, LOSSES, DAMAGES, LIABILITIES, COSTS AND EXPENSES, INCLUDING REASONABLE ATTORNEYS' FEES, TO THE EXTENT SUCH CLAIMS ARISE OUT OF ANY BREACH OF THIS SECTION 8.

9.Audit Rights

ZyXEL SHALL HAVE THE RIGHT, AT ITS OWN EXPENSE, UPON REASONABLE PRIOR NOTICE, TO PERIODICALLY INSPECT AND AUDIT YOUR RECORDS TO ENSURE YOUR COMPLIANCE WITH THE TERMS AND CONDITIONS OF THIS LICENSE AGREEMENT.

10.Termination

This License Agreement is effective until it is terminated. You may terminate this License Agreement at any time by destroying or returning to ZyXEL all copies of the Software and Documentation in your possession or under your control. ZyXEL may terminate this License Agreement for any reason, including, but not limited to, if ZyXEL finds that you have violated any of the terms of this License Agreement. Upon notification of termination, you agree to destroy or return to ZyXEL all copies of the Software and Documentation and to certify in writing that all known copies, including backup copies, have been destroyed. All provisions relating to confidentiality, proprietary rights, and non-disclosure shall survive the termination of this Software License Agreement.

12.General

This License Agreement shall be construed, interpreted and governed by the laws of Republic of China without regard to conflicts of laws provisions thereof. The exclusive forum for any disputes arising out of or relating to this License Agreement shall be an appropriate court or Commercial Arbitration Association sitting in ROC, Taiwan. This License Agreement shall constitute the entire Agreement between the parties hereto. This License Agreement, the rights granted hereunder, the Software and Documentation shall not be assigned by you

without the prior written consent of ZyXEL. Any waiver or modification of this License Agreement shall only be effective if it is in writing and signed by both parties hereto. If any part of this License Agreement is found invalid or unenforceable by a court of competent jurisdiction, the remainder of this License Agreement shall be interpreted so as to reasonably effect the intention of the parties.

Legal Information

Copyright

Copyright © 2007 by ZyXEL Communications Corporation.

The contents of this publication may not be reproduced in any part or as a whole, transcribed, stored in a retrieval system, translated into any language, or transmitted in any form or by any means, electronic, mechanical, magnetic, optical, chemical, photocopying, manual, or otherwise, without the prior written permission of ZyXEL Communications Corporation.

Published by ZyXEL Communications Corporation. All rights reserved.

Disclaimer

ZyXEL does not assume any liability arising out of the application or use of any products, or software described herein. Neither does it convey any license under its patent rights nor the patent rights of others. ZyXEL further reserves the right to make changes in any products described herein without notice. This publication is subject to change without notice.

Trademarks

ZyNOS (ZyXEL Network Operating System) is a registered trademark of ZyXEL Communications, Inc. Other trademarks mentioned in this publication are used for identification purposes only and may be properties of their respective owners.

Dolby

“Dolby” and the double-D symbol are trademarks of Dolby Laboratories.

Manufactured under license from Dolby Laboratories.

Certifications

Federal Communications Commission (FCC) Interference Statement

The device complies with Part 15 of FCC rules. Operation is subject to the following two conditions:

- This device may not cause harmful interference.
- This device must accept any interference received, including interference that may cause undesired operations.

This device has been tested and found to comply with the limits for a Class B digital device pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This device generates, uses, and can radiate radio frequency energy, and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this device does cause harmful interference to radio/television reception, which can be determined by turning the device off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- 1 Reorient or relocate the receiving antenna.
- 2 Increase the separation between the equipment and the receiver.
- 3 Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- 4 Consult the dealer or an experienced radio/TV technician for help.

Notices

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This Class B digital apparatus complies with Canadian ICES-003.

Cet appareil numérique de la classe B est conforme à la norme NMB-003 du Canada.

Viewing Certifications

- 1 Go to <http://www.zyxel.com>.
- 2 Select your product on the ZyXEL home page to go to that product's page.
- 3 Select the certification you wish to view from this page.

ZyXEL Limited Warranty

ZyXEL warrants to the original end user (purchaser) that this product is free from any defects in materials or workmanship for a period of up to two years from the date of purchase. During the warranty period, and upon proof of purchase, should the product have indications of failure due to faulty workmanship and/or materials, ZyXEL will, at its discretion, repair or replace the defective products or components without charge for either parts or labor, and to whatever extent it shall deem necessary to restore the product or components to proper operating condition. Any replacement will consist of a new or re-manufactured functionally equivalent product of equal or higher value, and will be solely at the discretion of ZyXEL. This warranty shall not apply if the product has been modified, misused, tampered with, damaged by an act of God, or subjected to abnormal working conditions.

Note

Repair or replacement, as provided under this warranty, is the exclusive remedy of the purchaser. This warranty is in lieu of all other warranties, express or implied, including any implied warranty of merchantability or fitness for a particular use or purpose. ZyXEL shall in no event be held liable for indirect or consequential damages of any kind to the purchaser.

To obtain the services of this warranty, contact ZyXEL's Service Center for your Return Material Authorization number (RMA). Products must be returned Postage Prepaid. It is recommended that the unit be insured when shipped. Any returned products without proof of purchase or those with an out-dated warranty will be repaired or replaced (at the discretion of ZyXEL) and the customer will be billed for parts and labor. All repaired or replaced products will be shipped by ZyXEL to the corresponding return address, Postage Paid. This warranty gives you specific legal rights, and you may also have other rights that vary from country to country.

Registration

Register your product online to receive e-mail notices of software upgrades and information at www.zyxel.com for global products, or at www.us.zyxel.com for North American products.

Customer Support

Please have the following information ready when you contact customer support.

Required Information

- Product model and serial number.
- Warranty Information.
- Date that you received your device.
- Brief description of the problem and the steps you took to solve it.

“+” is the (prefix) number you dial to make an international telephone call.

Corporate Headquarters (Worldwide)

- Support E-mail: support@zyxel.com.tw
- Sales E-mail: sales@zyxel.com.tw
- Telephone: +886-3-578-3942
- Fax: +886-3-578-2439
- Web: www.zyxel.com, www.europe.zyxel.com
- FTP: ftp.zyxel.com, ftp.europe.zyxel.com
- Regular Mail: ZyXEL Communications Corp., 6 Innovation Road II, Science Park, Hsinchu 300, Taiwan

Costa Rica

- Support E-mail: soporte@zyxel.co.cr
- Sales E-mail: sales@zyxel.co.cr
- Telephone: +506-2017878
- Fax: +506-2015098
- Web: www.zyxel.co.cr
- FTP: ftp.zyxel.co.cr
- Regular Mail: ZyXEL Costa Rica, Plaza Roble Escazú, Etapa El Patio, Tercer Piso, San José, Costa Rica

Czech Republic

- E-mail: info@cz.zyxel.com
- Telephone: +420-241-091-350
- Fax: +420-241-091-359
- Web: www.zyxel.cz

- Regular Mail: ZyXEL Communications, Czech s.r.o., Modranská 621, 143 01 Praha 4 - Modrany, Česká Republika

Denmark

- Support E-mail: support@zyxel.dk
- Sales E-mail: sales@zyxel.dk
- Telephone: +45-39-55-07-00
- Fax: +45-39-55-07-07
- Web: www.zyxel.dk
- Regular Mail: ZyXEL Communications A/S, Columbusvej, 2860 Soeborg, Denmark

Finland

- Support E-mail: support@zyxel.fi
- Sales E-mail: sales@zyxel.fi
- Telephone: +358-9-4780-8411
- Fax: +358-9-4780-8448
- Web: www.zyxel.fi
- Regular Mail: ZyXEL Communications Oy, Malminkaari 10, 00700 Helsinki, Finland

France

- E-mail: info@zyxel.fr
- Telephone: +33-4-72-52-97-97
- Fax: +33-4-72-52-19-20
- Web: www.zyxel.fr
- Regular Mail: ZyXEL France, 1 rue des Vergers, Bat. 1 / C, 69760 Limonest, France

Germany

- Support E-mail: support@zyxel.de
- Sales E-mail: sales@zyxel.de
- Telephone: +49-2405-6909-69
- Fax: +49-2405-6909-99
- Web: www.zyxel.de
- Regular Mail: ZyXEL Deutschland GmbH., Adenauerstr. 20/A2 D-52146, Wuerselen, Germany

Hungary

- Support E-mail: support@zyxel.hu
- Sales E-mail: info@zyxel.hu
- Telephone: +36-1-3361649
- Fax: +36-1-3259100
- Web: www.zyxel.hu
- Regular Mail: ZyXEL Hungary, 48, Zoldlomb Str., H-1025, Budapest, Hungary

India

- Support E-mail: support@zyxel.in
- Sales E-mail: sales@zyxel.in
- Telephone: +91-11-30888144 to +91-11-30888153
- Fax: +91-11-30888149, +91-11-26810715
- Web: <http://www.zyxel.in>
- Regular Mail: India - ZyXEL Technology India Pvt Ltd., II-Floor, F2/9 Okhla Phase -1, New Delhi 110020, India

Japan

- Support E-mail: support@zyxel.co.jp
- Sales E-mail: zyp@zyxel.co.jp
- Telephone: +81-3-6847-3700
- Fax: +81-3-6847-3705
- Web: www.zyxel.co.jp
- Regular Mail: ZyXEL Japan, 3F, Office T&U, 1-10-10 Higashi-Gotanda, Shinagawa-ku, Tokyo 141-0022, Japan

Kazakhstan

- Support: <http://zyxel.kz/support>
- Sales E-mail: sales@zyxel.kz
- Telephone: +7-3272-590-698
- Fax: +7-3272-590-689
- Web: www.zyxel.kz
- Regular Mail: ZyXEL Kazakhstan, 43 Dostyk Ave., Office 414, Dostyk Business Centre, 050010 Almaty, Republic of Kazakhstan

Malaysia

- Support E-mail: support@zyxel.com.my
- Sales E-mail: sales@zyxel.com.my
- Telephone: +603-8076-9933
- Fax: +603-8076-9833
- Web: <http://www.zyxel.com.my>
- Regular Mail: ZyXEL Malaysia Sdn Bhd., 1-02 & 1-03, Jalan Kenari 17F, Bandar Puchong Jaya, 47100 Puchong, Selangor Darul Ehsan, Malaysia

North America

- Support E-mail: support@zyxel.com
- Support Telephone: +1-800-978-7222
- Sales E-mail: sales@zyxel.com
- Sales Telephone: +1-714-632-0882
- Fax: +1-714-632-0858
- Web: www.zyxel.com

- Regular Mail: ZyXEL Communications Inc., 1130 N. Miller St., Anaheim, CA 92806-2001, U.S.A.

Norway

- Support E-mail: support@zyxel.no
- Sales E-mail: sales@zyxel.no
- Telephone: +47-22-80-61-80
- Fax: +47-22-80-61-81
- Web: www.zyxel.no
- Regular Mail: ZyXEL Communications A/S, Nils Hansens vei 13, 0667 Oslo, Norway

Poland

- E-mail: info@pl.zyxel.com
- Telephone: +48-22-333 8250
- Fax: +48-22-333 8251
- Web: www.pl.zyxel.com
- Regular Mail: ZyXEL Communications, ul. Okrzei 1A, 03-715 Warszawa, Poland

Russia

- Support: <http://zyxel.ru/support>
- Sales E-mail: sales@zyxel.ru
- Telephone: +7-095-542-89-29
- Fax: +7-095-542-89-25
- Web: www.zyxel.ru
- Regular Mail: ZyXEL Russia, Ostrovityanova 37a Str., Moscow 117279, Russia

Singapore

- Support E-mail: support@zyxel.com.sg
- Sales E-mail: sales@zyxel.com.sg
- Telephone: +65-6899-6678
- Fax: +65-6899-8887
- Web: <http://www.zyxel.com.sg>
- Regular Mail: ZyXEL Singapore Pte Ltd., No. 2 International Business Park, The Strategy #03-28, Singapore 609930

Spain

- Support E-mail: support@zyxel.es
- Sales E-mail: sales@zyxel.es
- Telephone: +34-902-195-420
- Fax: +34-913-005-345
- Web: www.zyxel.es
- Regular Mail: ZyXEL Communications, Arte, 21 5ª planta, 28033 Madrid, Spain

Sweden

- Support E-mail: support@zyxel.se
- Sales E-mail: sales@zyxel.se
- Telephone: +46-31-744-7700
- Fax: +46-31-744-7701
- Web: www.zyxel.se
- Regular Mail: ZyXEL Communications A/S, Sjöporten 4, 41764 Göteborg, Sweden

Thailand

- Support E-mail: support@zyxel.co.th
- Sales E-mail: sales@zyxel.co.th
- Telephone: +662-831-5315
- Fax: +662-831-5395
- Web: http://www.zyxel.co.th
- Regular Mail: ZyXEL Thailand Co., Ltd., 1/1 Moo 2, Ratchaphruk Road, Bangrak-Noi, Muang, Nonthaburi 11000, Thailand.

Ukraine

- Support E-mail: support@ua.zyxel.com
- Sales E-mail: sales@ua.zyxel.com
- Telephone: +380-44-247-69-78
- Fax: +380-44-494-49-32
- Web: www.ua.zyxel.com
- Regular Mail: ZyXEL Ukraine, 13, Pimonenko Str., Kiev 04050, Ukraine

United Kingdom

- Support E-mail: support@zyxel.co.uk
- Sales E-mail: sales@zyxel.co.uk
- Telephone: +44-1344-303044, 08707-555779 (UK only)
- Fax: +44-1344-303034
- Web: www.zyxel.co.uk
- FTP: ftp.zyxel.co.uk
- Regular Mail: ZyXEL Communications UK Ltd., 11 The Courtyard, Eastern Road, Bracknell, Berkshire RG12 2XB, United Kingdom (UK)

Index

Numerics

1080i [71](#)
 16 by 9 format [71](#)
 2 channel (stereo) [72](#)
 4 by 3 format [71](#)
 480i [71](#)
 480p [71](#)
 5.1 channel [72](#), [91](#)
 720p [71](#)

A

AAC [72](#), [73](#)
 A-B button [26](#), [41](#)
 A-B function [41](#), [90](#)
 AC-3 [73](#), [74](#)
 Acoustic Coder 3 [74](#)
 Advanced Audio Coding, See AAC [73](#)
 Advanced Codec 3 [74](#)
 album [50](#)
 analog input [71](#)
 analog output [72](#)
 application [23](#), [129](#)
 arrow buttons [26](#)
 ascending sort order [36](#)
 ATSC A/52 [74](#)
 ATSC A/52 Rev. B [74](#)
 audio [91](#)
 2 channel [72](#)
 channels [73](#)
 AUDIO button [26](#)
 Audio Codec 3 [74](#)
 audio output [26](#)
 auto volume control [73](#)

B

BACK button [26](#)
 button [26](#), [50](#)
 A-B [26](#), [41](#)

arrow [26](#)
 AUDIO [26](#)
 BACK [26](#)
 Fast Forward [26](#), [50](#)
 HOME [26](#)
 INFO [26](#)
 MUSIC [26](#), [43](#)
 MUTE [26](#)
 Next [26](#), [50](#)
 OK [26](#)
 OPTION [26](#)
 PAGE up/down [26](#)
 Pause [26](#), [50](#)
 PHOTO [26](#), [49](#)
 Play [26](#), [50](#)
 Power [26](#), [42](#), [44](#)
 REPEAT [26](#)
 Reverse [26](#), [50](#)
 ROTATE [26](#), [50](#)
 SERVER [26](#)
 SHUFFLE [26](#)
 Skip [26](#)
 Slow motion [26](#)
 Stop [26](#), [50](#)
 TOOL [26](#), [41](#)
 USB [26](#), [61](#)
 VIDEO [26](#), [39](#)
 VOLUME [26](#)

C

certifications [183](#)
 notices [184](#)
 viewing [184](#)
 channels [26](#)
 audio [73](#)
 codecs [99](#)
 contact information [187](#)
 copyright [183](#)
 current function [40](#)
 customer support [187](#)

D

DD 5.1 [74](#)

DD, [74](#)
default settings [75](#)
descending sort order [36](#)
device name [79](#)
dialog box [26](#)
digital input [71](#)
Digital Living Network Alliance, See DLNA [81, 98](#)
digital output [72](#)
dimensions [97](#)
disclaimer [183](#)
display information [78](#)
display photos [50](#)
DLNA [81, 98](#)
DNS server
 address assignment [69](#)
Dolby Digital [73](#)
Dolby Laboratories [73](#)
Dolby SR-Digital [74](#)
Dolby Stereo Digital [74](#)
Dolby Surround AC-3 Digital [74](#)
Domain Name System. See DNS.
down button [26](#)
down VOLUME button [26](#)

E

ease of use [75](#)
elapsed time [41](#)

F

factory defaults [75](#)
Fast Forward button [26, 50](#)
favorite [26, 36, 37, 42, 44, 51, 53, 54, 55](#)
favorites [90](#)
FCC interference statement [183](#)
file
 organization [50](#)
 search [36](#)
filter [36](#)
firmware
 upload [78](#)
 version [79](#)
formats supported [99](#)
function [40](#)
 A-B [41](#)
 current [40](#)

H

HDMI [90, 98](#)
HDTV [71](#)
High Definition Multimedia Interface, See HDMI [98](#)
High Definition Television, See HDTV [71](#)
HOME button [26](#)
HOME menu [39, 43, 49, 61, 65](#)
home networks [81, 98](#)
humidity, operation and storage [97](#)

I

i [71](#)
icon
 A-B [41](#)
 MUSIC [43](#)
 OPTION [65](#)
 PHOTO [49](#)
 USB [61](#)
 VIDEO [39](#)
IEC 958 type II [73](#)
IEC-60958 [73](#)
INFO button [26](#)
information [78](#)
inputting
 lower-case letters [37](#)
 numbers [37](#)
 upper-case letters [37](#)
inputting symbols [37](#)
inputting text [36](#)
interlaced scan [71](#)
interval repeat [26, 41](#)

K

keyboard [36](#)

L

language settings [74](#)
languages [74](#)
LEDs [27](#)
 troubleshooting [87](#)
left output [26](#)

letters [37](#)
 inputting [37](#)
 lights [27](#)
 lines of vertical resolution [71](#)
 loop [26](#)

M

MAC address [69](#), [79](#)
 Media Access Control. See MAC address.
 media server [81](#), [98](#)
 access [88](#)
 configuration [82](#)
 software [81](#), [98](#)
 tool [81](#)
 menu [31](#)
 item number [33](#)
 MUSIC [43](#)
 navigation [31](#)
 OPTION [65](#)
 PHOTO [49](#)
 TOOL [41](#)
 USB [61](#)
 video playback TOOL [41](#)
 Moving Pictures Experts Group, See MPEG [73](#)
 MPEG [73](#)
 MPEG-4 AAC [73](#)
 MUSIC
 button [26](#), [43](#)
 icon [43](#)
 menu [43](#)
 music
 play [44](#)
 MUTE button [26](#)

N

network settings [69](#)
 Next button [26](#), [50](#)
 number
 menu item [33](#)

O

OK button [26](#)
 on-screen keyboard [36](#)
 OPTION

 button [26](#)
 icon [65](#)
 menu [65](#)
 organization
 of photos [50](#)
 output type [71](#)

P

PAGE buttons [26](#)
 Pause button [26](#), [50](#)
 PHOTO
 button [26](#), [49](#)
 icon [49](#)
 menu [49](#)
 photo [26](#), [50](#)
 display [50](#)
 organization [50](#)
 rotation [26](#), [50](#)
 play
 music [44](#)
 photos [50](#)
 video file [39](#)
 Play button [26](#), [50](#)
 playback menu [41](#)
 playlist [36](#), [37](#), [42](#), [44](#), [51](#), [53](#), [54](#), [55](#)
 popup screen [26](#)
 Power button [26](#), [42](#), [44](#)
 power specification [97](#)
 Previous button [26](#), [50](#)
 problems [87](#)
 product registration [185](#)
 progressive scan [71](#)

R

random play [26](#)
 rear left speaker [91](#)
 rear right speaker [91](#)
 registration
 product [185](#)
 related documentation [3](#)
 remote control [39](#), [41](#), [61](#)
 REPEAT button [26](#)
 repeat interval [26](#), [41](#)
 reset [75](#)
 resolution [71](#)
 Reverse button [26](#), [50](#)

right output [26](#)
ROTATE button [26](#), [50](#)

S

S/PDIF [73](#)
safety warnings [6](#)
scan
 interlaced [71](#)
 progressive [71](#)
screen
 resolution [71](#)
 size [71](#)
screen saver [79](#)
screws [103](#)
search [36](#), [42](#), [44](#)
 for files [36](#)
 for time [42](#), [44](#)
SERVER
 button [26](#)
Settings For Ease of Use [75](#)
SHUFFLE button [26](#)
Skip button [26](#)
slideshow [50](#)
Slow motion button [26](#)
software
 upload [77](#)
software update [77](#)
Sony/Philips Digital Interface Format, See S/PDIF [73](#)
sort order [36](#)
speakers [26](#), [91](#)
SR-D, Adaptive Transform Coder 3 [74](#)
standard definition [71](#)
stereo [72](#)
stereo output [26](#)
Stop button [26](#), [50](#)
supported
 codecs [99](#)
 formats [99](#)
S-Video [90](#)
symbols [37](#)
 inputting [37](#)
syntax conventions [4](#)

T

television [71](#)
 analog input [71](#)

digital input [71](#)
high definition [71](#)
standard definition [71](#)
two [90](#)
temperature, operation and storage [97](#)
text input [36](#)
 lower-case letters [37](#)
 numbers [37](#)
 symbols [37](#)
 upper-case letters [37](#)
time [41](#)
 elapsed [41](#)
 search [42](#), [44](#)
TOOL
 button [26](#)
 menu [26](#)
TOOL button [41](#)
TOOL menu [26](#), [41](#)
trademarks [183](#)
troubleshooting [87](#)
 5.1 channel speakers [91](#)
 A-B function [90](#)
 DMA usage [88](#)
 favorites [90](#)
 files [89](#)
 files not in proper folders [33](#)
 files on USB devices [90](#)
 LEDs [87](#)
 media server access [88](#)
 number of files [89](#)
 thumbnails [90](#)
 TV display [88](#), [90](#)

U

up VOLUME button [26](#)
up/down buttons [26](#)
updating software [77](#)
uploading software [77](#)
USB
 button [26](#), [61](#)
 device [23](#)
 for firmware upload [78](#)
 icon [61](#)
 LED [27](#)
 menu [61](#)
 troubleshooting [90](#)

V

version [79](#)

- firmware [79](#)
- VIDEO
 - button [39](#)
 - icon [39](#)
- video
 - playback [39](#)
 - playback TOOL menu [41](#)
- VIDEO button [26](#)
- video modes [71](#)
- VOLUME button [26](#)
- volume control [73](#)

W

- warranty [184](#)
 - note [185](#)
- weight [97](#)
- widescreen format [71](#)
- Windows Media Audio, See WMA [74](#)
- Windows Media Center [89](#)
- wired LAN
 - MAC address [79](#)
 - settings [69](#)
- WMA [74](#)

